

# Table of Contents

Chapter 1 EasyBuilder 8000 Installation and Startup Guide .....	11
1.1 EasyBuilder 8000 Installation.....	11
1.2 Steps to Install EasyBuilder 8000 .....	11
Chapter 2 Project Manager Operations.....	16
2.1 HMI IP, Password.....	17
2.2 Editor.....	18
2.2.1 Step by Step to Download Project Via USB or CF Card.....	19
2.3 Transfer .....	20
2.3.1 Download.....	20
2.3.2 Upload.....	21
2.4 Simulation .....	22
2.4.1 On-line Simulation/Off-line Simulation .....	22
2.5 Pass-Through .....	23
2.5.1 Ethernet Mode.....	23
2.5.2 COM Port Mode .....	24
Chapter 3 Create a EasyBuilder 8000 Project.....	25
3.1 Create a New Project .....	25
3.2 Save and Compile the Project.....	28
3.3 Simulate the Project Either On-line or Off-line.....	29
3.3.1 Off-line Simulation .....	29
3.3.2 On-line Simulation.....	30
3.4 Download the Project.....	30
Chapter 4 Hardware Settings .....	32
4.1 I/O Ports of HMI.....	32
a. USB Host .....	32
b. Ethernet Port .....	32
c. Compact Flash Card.....	32
d. Serial I/O Port .....	32
4.2 HMI System Settings .....	33
4.2.1 System Reset.....	33
4.2.2 Tool bar.....	35
4.3 HMI Download Settings .....	45
Chapter 5 System Parameters .....	49
5.1 Device .....	50
5.1.1 How to Control a Local PLC .....	50
5.1.2 How to Control a Remote PLC.....	53

5.1.3 How to Control a Remote HMI .....	55
5.2 Model .....	57
5.3 General .....	60
5.4 Security .....	63
5.5 Font .....	65
5.6 Extended Memory .....	66
5.7 Printer Server .....	67
Chapter 6 Window Operations.....	69
6.1 Window Types .....	69
6.1.1 Base Window .....	69
6.1.2 Common Window .....	70
6.1.3 Fast Selection Window .....	70
6.1.4 System Message Window .....	72
6.2 Create, Delete and Set a Window .....	73
6.2.1 Create a Window.....	73
6.2.2 Window Settings .....	77
6.2.3 Open, Close and Delete a Window .....	77
Chapter 7 Event Log .....	78
7.1 Event Log Management.....	78
7.1.1 Excel Editing.....	81
7.2 Create a New Event Log .....	84
Chapter 8 Data Sampling .....	91
8.1 Data Sampling Management.....	91
8.2 Create a New Data Sampling.....	92
Chapter 9 Object General Properties .....	97
9.1 Selecting the Connection PLC Device.....	97
9.1.1 Setting the Reading and Writing Address.....	97
9.2 Using Shape Library and Picture Library .....	99
9.2.1 Settings of Shape Library.....	100
9.2.2 Settings of Picture Library .....	101
9.3 Setting Text Content .....	105
9.3.1 Adjusting Profile Size .....	109
9.4 Station Number's Variable .....	110
9.4.1 Broadcast Station No. ....	111
Chapter 10 Security.....	112
10.1 Settings of Password and Classes .....	112
10.2 Object's Security.....	114
10.3 Example of Security.....	118

Chapter 11 Index Register .....	124
11.1 Introduction.....	124
11.2 Example of Index Register.....	124
Chapter 12 Keypad Design and Usage .....	128
12.1 Steps to Design a Pop-up Keypad.....	128
12.2 Steps to Use Keypad without Title Bar.....	131
12.3 Steps to Use Fixed Keypad .....	134
Chapter 13 Object .....	137
13.1 Bit Lamp Object.....	137
13.1.1 Overview.....	137
13.1.2 Configuration .....	137
13.2 Word Lamp Object .....	140
13.2.1 Overview.....	140
13.2.2 Configuration .....	140
13.2.3 Restrictions .....	143
13.3 Set Bit Object.....	144
13.3.1 Overview.....	144
13.3.2 Configuration .....	144
13.4 Set Word Object.....	148
13.4.1 Overview.....	148
13.4.2 Configuration .....	148
13.5 Function Key Object.....	155
13.5.1 Overview.....	155
13.5.2 Configuration .....	155
13.5.3 Non-ASCII character input.....	158
13.6 Toggle Switch Object .....	162
13.6.1 Overview.....	162
13.6.2 Configuration .....	162
13.7 Multi-Switch Object.....	165
13.7.1 Overview.....	165
13.7.2 Configuration .....	165
13.8 Slide Object.....	168
13.8.1 Overview.....	168
13.8.2 Configuration .....	168
13.9 Numeric Input and Numeric Display Objects.....	173
13.9.1 Overview.....	173
13.9.2 Configuration .....	173
13.10 ASCII Input and ASCII Display Objects.....	181

13.10.1 Overview .....	181
13.10.2 Configuration .....	181
13.11 Indirect Window Object.....	187
13.11.1 Overview .....	187
13.11.2 Configuration .....	187
13.11.3 Example to use indirect window .....	189
13.12 Direct Window Object .....	192
13.12.1 Overview .....	192
13.12.2 Configuration .....	192
13.12.3 Example .....	194
13.13 Moving Shape Object .....	196
13.13.1 Overview .....	196
13.13.2 Configuration .....	196
13.14 Animation Object.....	201
13.14.1 Overview .....	201
13.14.2 Configuration .....	201
13.15 Bar Graph Object .....	206
13.15.1 Overview .....	206
13.15.2 Configuration .....	206
13.16 Meter Display Object.....	213
13.16.1 Overview .....	213
13.16.2 Configuration .....	213
13.17 Trend Display Object.....	221
13.17.1 Overview .....	221
13.17.2 Configuration .....	221
13.17.3 Example .....	230
13.18 History Data Display.....	232
13.18.1 Overview .....	232
13.18.2 Configuration .....	232
13.18.3 Note.....	238
13.19 Data Block Display .....	239
13.19.1 Overview .....	239
13.19.2 Configuration .....	240
13.19.3 On line operation.....	245
13.20 XY Plot .....	251
13.20.1 Overview.....	251
13.20.2 Configuration .....	251
13.21 Alarm Bar and Alarm Display Objects.....	263

13.21.1 Overview .....	263
13.21.2 Configuration .....	263
13.22 Event Display Object .....	267
13.22.1 Overview .....	267
13.22.2 Configuration .....	267
13.23 Data Transfer (Trigger-based) Object.....	274
13.23.1 Overview .....	274
13.23.2 Configuration .....	274
13.24 Backup .....	277
13.24.1 Overview .....	277
13.24.2 Configuration .....	277
13.25 Media Player Object .....	281
13.25.1 Overview .....	281
13.25.2 Configuration .....	281
13.25.3 Start / Stop playing video.....	284
13.25.4 Media player setting guide.....	286
13.25.5 Restrictions .....	291
13.26 Data Transfer (Time-based) Object .....	292
13.26.1 Overview .....	292
13.26.2 Configuration .....	292
13.27 PLC Control Object .....	295
13.27.1 Overview .....	295
13.27.2 Configuration .....	295
13.28 Schedule Object .....	302
13.28.1 Overview .....	302
13.28.2 Configuration .....	302
13.28.3 Restrictions .....	320
13.29 Option List .....	321
13.29.1 Overview .....	321
13.29.2 Configuration .....	321
Chapter 14 Shape Library and Picture Library .....	325
14.1 Creating Shape Library .....	325
14.2 Creating Picture Library .....	332
Chapter 15 Label Library and Using Multi-Language .....	340
15.1 Introduction.....	340
15.2 Settings of Label Library's Font .....	341
15.3 How to Create a Label Library .....	343
15.4 Using Label Library.....	345

15.5 Use of Multi-Language .....	345
Chapter 16 Address Tag Library.....	347
16.1 Creating Address Tag Library .....	347
16.2 Using Address Tag Library.....	350
Chapter 17 Transferring Recipe Data .....	351
17.1 Updating Recipe Data by Using Ethernet or USB cable .....	351
17.2 Updating Recipe Data by Using CF Card or USB Stick .....	352
17.3 Transferring Recipe Data.....	353
17.4 Saving Recipe Data Automatically .....	353
Chapter 18 Macro Reference .....	355
18.1 Macro Construction .....	355
18.2 Syntax .....	356
18.2.1 Constants and Variables.....	356
18.2.2 Operators.....	358
18.3 Statement.....	360
18.3.1 Definition Statement .....	360
18.3.2 Assignment Statement .....	361
18.3.3 Logical Statements.....	361
18.3.4 Reiterative Statements .....	363
18.4 Function Blocks .....	365
18.5 Build-In Function Block .....	366
18.5.1 Mathematical Functions.....	366
18.5.2 Data Transformation .....	371
18.5.3 Data Manipulation.....	374
18.5.4 Bit Transformation.....	377
18.5.5 Communication.....	379
18.6 How to Create and Execute a Macro .....	390
18.6.1 How to Create a Macro .....	390
18.6.2 Execute a Macro .....	395
18.7 Some Notes about Using the Macro .....	395
18.8 Use the Free Protocol to Control a Device .....	396
18.9 Compiler Error Message .....	401
18.10 Sample Macro Code.....	408
Chapter 19 How to Set HMI as a MODBUS Server .....	413
19.1 How to Set HMI as MODBUS Device.....	413
19.1.1 Creating a MODBUS Server .....	413
19.1.2 How to Read From / Write to MODBUS Server.....	415
19.2 How to Change the Station Number of a MODBUS Server in Runtime.....	417

Chapter 20 How to Connect a Barcode Device .....	418
20.1 How to Connect a Barcode Device .....	418
Chapter 21 Ethernet Communication and Multi-HMIs Connection.....	422
21.1 HMI to HMI Communication .....	423
21.2 PC to HMI Communication .....	425
21.3 Operate the PLC Connected with other HMIs.....	429
Chapter 22 System Reserved Words / Bits .....	432
22.1 System Status and Control .....	432
22.2 States of Data Input.....	433
22.3 Recipe Data .....	433
22.4 Task Button and Fast Selection Window .....	434
22.5 Event Logging.....	434
22.6 Data Logging .....	435
22.7 Password and Operation Level .....	435
22.8 Time of HMI .....	437
22.9 Hardware of HMI.....	437
22.10 The States of Communicating with Remote HMI(s) .....	438
22.11 The States of Communicating with PLC .....	438
22.12 Client Connected to Server .....	440
22.13 MODBUS Server Station no.....	441
22.14 COM Communication.....	441
22.15 File Manager .....	443
22.16 PLC & Remote HMI IP Address Setting.....	443
22.17 Printer Server Setting.....	443
22.18 Address Index Function .....	444
22.19 The Address Ranges of Local HMI Memory .....	444
22.19.1 Bits .....	444
22.19.2 Words.....	445
22.20 Touch Screen X and Y Position.....	446
22.21 Variable Station no. ....	446
Chapter 23 PLC Connection Guide .....	447
AIBUS.....	447
Allen-Bradley CompactLogix / FlexLogix.....	450
Allen-Bradley DF1.....	455
Allen-Bradley DH485 .....	457
Allen-Bradley EtherNet/IP CompactLogix.....	460
Allen-Bradley EtherNet/IP (DF1).....	463
Allen Bradley PLC5.....	466

Baumuller Servo .....	468
Copley Controls .....	470
DELTA DVP .....	472
FATEK FB series.....	474
GE Fanuc SNP-X.....	477
GE Fanuc Series 90-30 (Ethernet) .....	480
HAN YOUNG .....	483
Heng Yuan Sensor .....	484
HITACHI H series (CPU port) .....	485
IDEC .....	490
KEYENCE KV series .....	492
KEYENCE KV-1000.....	494
Korenix 6550 / 6520 .....	496
KOYO DirectLogic.....	498
LS MASTER-K Cnet.....	502
LS MASTER-K300S CPU .....	504
LS XGB/XGT .....	506
LS XGB/XGT TCP/IP series .....	508
LIYAN EX series.....	510
Master (Master-Slave Protocol).....	512
Memobus (YASKAWA MP Series controllers).....	515
MITSUBISHI AJ71 .....	517
MITSUBISHI FX0n/FX2 .....	519
MITSUBISHI FX2n.....	521
MITSUBISHI FX232/485BD .....	523
MITSUBISHI FX3U.....	526
MITSUBISHI FX3U-ETHERNET.....	528
MITSUBISHI Q02H.....	535
MITSUBISHI Q06H.....	537
MITSUBISHI QJ71 .....	539
MITSUBISHI QJ71E71.....	543
MODBUS ASCII.....	550
MODBUS RTU .....	552
MODBUS RTU (zero-based addressing) .....	555
MODBUS SERVER (Modbus RTU Slave) .....	559
MODBUS TCP/IP .....	561
MODBUS TCP/IP (zero-based) .....	563
Modicon Twido.....	565

OMRON C/CQM1 series.....	567
OMRON CJ1/CS1 .....	569
OMRON CJ1/CS1 Ethernet.....	571
OMRON E5CN.....	574
Panasonic FP.....	576
Parker Compax3.....	580
SAIA PCD PGU mode.....	584
SAIA PCD S-Bus mode.....	586
SEW Eurodrive MOVITRAC.....	588
SIEMENS S7/200 .....	589
SIEMENS S7/200 Ethernet.....	591
SIEMENS S7/300 .....	593
SIEMENS S7/300 Ethernet.....	595
SIMATIC TI505 .....	597
Telemecanique UniTelWay .....	599
TOSHIBA T series.....	601
TOSHIBA TC mini series.....	603
TOSHIBA VF-S11.....	605
VIGOR.....	607
Yokogawa FA-M3 .....	609
Yokogawa FA-M3 (Ethernet).....	615
Chapter 24 MT8000 Supports Printers .....	617
Appendix A. Recipe Editor.....	619
A.1 Introduction.....	619
A.2 Setting of Recipe Editor.....	621
Appendix B. EasyConverter .....	623
B.1 Introduction.....	623
B.2 Setting of EasyConverter .....	623
B.2.1 How to Export to Excel.....	623
B.2.2 How to Use Scaling Function.....	626
B.2.3 How to Use Multi-File Conversion.....	628
B.3 Enable Setting File .....	629
B.3.1 For “Combination” and “Enable Setting File” .....	632
B.4 Command Line.....	634
Appendix C. EasyPrinter .....	635
C.1 Using EasyPrinter as a Printer Server .....	636
C.1.1 Setup Procedure in EasyPrinter.....	636
C.1.2 Setup Procedure in EasyBuilder8000.....	637

C.2 Using EasyPrinter as a Backup Server .....	639
C.2.1 Setup Procedure in EasyPrinter .....	639
C.2.2 Setup Procedure in EasyBuilder8000.....	641
C.3 EasyPrinter Operation Guide .....	643
C.3.1 Appearance.....	643
C.3.2 Operation Guide .....	644
C.4 Convert Batch File .....	650
C.4.1 The Default Convert Batch File .....	650
C.4.2 Specialized Criteria .....	651
C.4.3 The Format of a Convert Batch File.....	652
C.4.4 The Order of Examining Criteria .....	652
Appendix D. EasySimulator .....	654
D.1 Prepare Files.....	654
D.2 Modify the Content of xob_pos.def .....	654
Appendix E. Multi-HMIs Intercommunication (Master-Slave Mode).....	656
E.1 How to Create a Project of Master HMI .....	656
E.2 How to Create a Project of Slave HMI.....	657
Appendix F. Pass-Through Function .....	660
F.1 Ethernet Mode .....	660
F.1.1 How to Change the Virtual Serial Port.....	662
F.1.2 How to Use Ethernet Mode .....	664
F.2 COM Port Mode .....	667
F.2.1 Settings of COM Port Mode.....	667
F.2.2 HMI Work Mode .....	669
F.3 Using System Reserved Addresses to Enable Pass-Through Function .....	672

# Chapter 1 EasyBuilder 8000 Installation and Startup Guide

## 1.1 EasyBuilder 8000 Installation

### Software:

Download EasyBuilder 8000 configuration software from EasyBuilder 8000 CD or visiting Weintek Labs, Inc.'s website at <http://www.weintek.com> to obtain all software versions available (including Simplified Chinese, Traditional Chinese, French, Korean, Italian, Spanish and English version) and latest upgraded files.

### Hardware Requirements (Recommended):

CPU: INTEL Pentium II or above

Memory: 64MB or above

Hard Disk: 2.5GB or above (Disc space available at least 10MB)

CD-ROM: 4X or above

Display: 256 color SVGA with 800 x 600 resolution or greater

Keyboard and Mouse

Ethernet: for project downloading/uploading

RS-232 COM: At least one available RS-232 serial port required for on-line simulation

Printer

### Operating System:

Windows 2000/Windows NT/Windows XP/Windows Vista


## 1.2 Steps to Install EasyBuilder 8000

### 1. Installing EasyBuilder 8000:


Put the EasyBuilder Installation CD into the CD drive. The autorun should bring up a screen showing an area to click to begin the Easybuilder installation. If the Autorun sequence does not start, browse the CD, find the root directory of [Autorun.exe] manually.




2. Choose [Install] and click “Next” to follow the installation instructions.




3. Designate the folder for EB8000 installation or choose the folder recommended and then click “Next”.




4. Click “Next” to confirm the installation.




5. Installation processing.



6. Click "Close" to complete the installation.



7. From menu [Start] / [Programs] / [EasyBuilder8000] to start a EB8000 project.




The definition of each menu under EB8000 catalog:

 EasyBuilder8000	EB8000 editing software
 EasyConverter	Conversion tool for Data sampling and Event Log
 EasyPrinter	Remote printer server
 Project Manager	EB8000 project management
 ReleaseNote.pdf	Note of EB8000 version and latest information
 EasyDiagnoser	Communication monitoring tool via online simulation
 EasySimulator	Tool for executing simulation without installing EB8000
 EasyAddressViewer	Review the register range of device types for each PLC supported


## Chapter 2 Project Manager Operations

The Project Manager is a software shell for launching several utilities. Some functions are duplicated in the EasyBuilder 8000 screen-editing program. Project Manager program can be run as a stand-alone program.

In this chapter, each function will be introduced respectively.



## 2.1 HMI IP, Password




When operating HMI by Ethernet, users need to designate the correct IP address and password in HMI. “Reset” and “Download” functions share a set of password while “Upload” function uses another set.


The password provides protection against unauthorized access to the HMI. Be sure to record any password change. If resetting password to default, the project and data on the HMI will be completely erased.

### Reboot HMI

The "Reboot HMI" feature is designed for users to reboot the project.




Set the correct IP address when operate HMI via Ethernet.



## 2.2 Editor

EasyBuilder 8000	To launch the EasyBuilder 8000 screen editor
EasyConverter	Conversion tool for Data Sampling and Event Log
EasyPrinter	Remote printer server.
Recipe / Extend Memory Editor	Provide file format conversion and data editing function for Recipe/Extend Memory
EasyAddressViewer	Review the register range of device types for each PLC supported
Build Download Data for CF Card/USB Disk	Except for Ethernet and USB cable, the project and data can be downloaded to the HMI by CF card or USB memory stick

**\* Build Download Data for CF Card/USB Disk**



Select the folder to save download data	Insert CF card or USB stick to PC and press <b>[Browse...]</b> to assign the file path (or directory name) and then press <b>[Build]</b> . The whole content of the source files will be downloaded to USB stick or CF card
Project	Press <b>[Browse...]</b> to assign the desired specific files for downloading.
Recipe (RW)	
Recipe A (RW_A)	
Data log	

The path of download data should be the name of directory and avoid designating only root directory. For example, either “c:\” or “f:\” is illegal name.

**2.2.1 Step by Step to Download Project Via USB or CF Card**

Take downloading data to the folder named as “**123**” (**K:\123**) in USB stick for example.

When USB stick (project or recipe included) is inserted to the HMI, a pop-up Download / Upload dialog will appears after few seconds. Please select Download and input Download Password.


Check Download project files and Download historical files on Download Settings dialog, and then press OK. After that, Pick a Directory dialog will appear. Please select directory: *usbdisk/device-0/123* and then press OK. Project will be automatically updated.

**Note:** It's necessary to reboot HMI even if historical file is downloaded only.

## 2.3 Transfer

### 2.3.1 Download

Download source files to the HMI through Ethernet or USB cable. Press the [Download] button and the dialog displays as below:




Firmware	Check [Firmware] to update all of the kernel programs of HMI.
----------	---

	Note: It is necessary when the latest EB8000 version is first-time download.
Project	To assign the desired specific path for file downloading
RW	
RW_A	
Data log	
Install X-series media-player drivers	It is necessary when the EB8000 is first-time download to X series.
Reboot HMI after download	Automatically reboot HMI after downloading
Reset recipe	Check the box to erase the specific files in HMI before downloading process
Reset event log	
Reset data log	

### 2.3.2 Upload

Upload files from HMI to PC by Ethernet or USB cable and the dialog box shows as below:



Project	To assign the desired path for file storage before uploading.
RW	
RW_A	


## 2.4 Simulation

### 2.4.1 On-line Simulation/Off-line Simulation

There are two types of simulations: Off-line simulation & On-line simulation.

By virtual device, PC simulates the operations of PLC without connecting to PLC. On the contrary, On-line simulation is executed by connecting PC with PLC and accurately setting the communication parameters. When simulating on PC, if the control target is a local PLC (i.e. the PLC directly connected to PC), there is **10 mins simulation limit**.

When using On-line/Off-line Simulation feature, select the source of \*.xob file before executing the function.



## 2.5 Pass-Through

The pass-through function is allowed the PC application to connect PLC via HMI. In the pass-through function, the HMI is acting as a converter.

Pass-through provides two types of modes: Ethernet and COM port. Click Pass-through button on Project Manager to start the settings.

### 2.5.1 Ethernet Mode



## 2.5.2 COM Port Mode

The image shows a software window titled "Pass-through" with a close button in the top right corner. At the top, there are two radio buttons: "Ethernet" (unselected) and "COM port" (selected). Below this, there is a field for "HMI IP:" with a dropdown menu showing "192.168.1.111" and a "Get HMI Communication Parameters" button. A status box below indicates "HMI work mode : Unknown".

The "Source COM Port (PC -> HMI)" section contains the following settings:

- COM 1 (dropdown)
- RS232 (dropdown)
- Baud rate : 19200 (dropdown)
- Data bits : 8 Bits (dropdown)
- Parity : Odd (dropdown)
- Stop bits : 1 Bit (dropdown)

The "Destination COM Port (HMI -> PLC)" section contains the following settings:

- COM 3 (dropdown)
- RS485 2W (dropdown)
- Baud rate : 19200 (dropdown)
- Data bits : 8 Bits (dropdown)
- Parity : Odd (dropdown)
- Stop bits : 1 Bit (dropdown)


At the bottom, there are three buttons: "Start Pass-through", "Stop Pass-through", and "Exit".

## Chapter 3 Create a EasyBuilder 8000 Project


In this Chapter, we will take Mitsubishi PLC as an example to illustrate how to create and compile a new EB8000 project, do the simulation on PC and download the project to the HMI.

### 3.1 Create a New Project


First of all, click [New] icon on the toolbar to create a new project.




Select HMI Model, check Use template and then click OK.



Under **Device** Tab, click [New...] button to correctly set up the device property for communicating to the PLC.




Device “MISUBISHI FX0n/FX2” is added to the Device Table after click OK.




Now, if users would like to add a new object, such as Toggle Switch, click the icon on the tool bar.



A new Toggle Switch Object dialog will display as the illustration. Correctly set the parameters of the object, click OK and place the object to the desired position of the screen.



A project with an object is completed.




### 3.2 Save and Compile the Project

In the menu, select **File/Save** to save the project. After the .mtp file is saved, select **Tools/Compile** or click **[Compile]** icon to compile the project and check if the screen configuration is correct. A .xob file will be obtained after compiling.



A successfully compiled file will get the dialog as below:



### 3.3 Simulate the Project Either On-line or Off-line

There are two types of simulation: Off-line simulation & On-line simulation. By virtual device, PC simulates the operations of PLC without connecting to PLC. On the contrary, On-line simulation is executed by connecting PC with PLC and accurately setting the communication parameters. When simulating on PC, if the control target is a local PLC (i.e. the PLC directly connected to PC), there's a **10 minutes** limit.

#### 3.3.1 Off-line Simulation

Click [**Off-line Simulation**] icon to execute the Off-line Simulation.



From this example, we got the Off-line simulation screen as below.



### 3.3.2 On-line Simulation


Click [On-line Simulation] icon to do the on-line simulation after correct connecting the device.



### 3.4 Download the Project

In the menu, select **Tool/Download...** or click [**Download**] icon from tool bar to load the image file into the HMI. Before downloading, be sure to check the selections in the dialog correctly.






HMI IP	Assign the IP address of HMI
Password	Input the password
Firmware	It's necessary if update the firmware or download the project at first time
Reset recipe	If the selection is checked, the file will be erased before downloading
Reset event log	
Reset data log	
Reboot HMI after download	If the selection is checked, HMI will reboots after downloading is done

Click Download button to start downloading the project.

## Chapter 4 Hardware Settings

### 4.1 I/O Ports of HMI



#### a. USB Host

Support devices with USB interfaces, such as mouse, keyboard, USB stick, printer...etc.

#### b. Ethernet Port

Connect devices with Ethernet communication interface, such as PLC, laptop...etc; support exchanging data via Network.

#### c. Compact Flash Card

Support the download/ upload of a project, including recipe transfer, Event Log Data...etc.

#### d. Serial I/O Port

COM ports, RS-232, RS485-2w/4w, can be connected to PLC or other peripheral devices. Here we view RS-422 as the same as RS-485 (4 wire). Please refer to the PLC connecting guide appendix in the manual to make sure the correct connection between PLC and HMI. Meanwhile, please make sure all DIP switches are on “OFF” (down) position (default value) in HMI operations.

In addition, Weintek provides [MT8-COM1 Multi-Connector cable] and [MT8-COM3 Multi-Connector cable] to expand one COM port to multiple independent COM ports so that the efficiency of the operation will be improved.


## 4.2 HMI System Settings

Before operating HMI, users have to complete the HMI system settings. After the setup, use EB80000 editing software to develop a personal operation interface. The following illustrates each system setting respectively.

### 4.2.1 System Reset

Each HMI is equipped with a set of reset button and DIP switch. When users use DIP switch to change modes, corresponding functions will be triggered.

If losing or forgetting the system password, users can set DIP Switch 1 to “ON” and the rest DIPs remain “OFF”. Then reboot HMI.



HMI will jump to Touch Adjust (Touch screen calibration) mode. After calibration, the pop-up window appears as the illustration below. Users will be inquired if they would like to restore the system password to the default.




When “YES” is chosen, another pop-up dialog appears as below. Users will be confirmed again if restoring the system password to the default is correct by inputting ”yes”. Then click OK. (The default password is 111111. However, other passwords, including download and upload password, have to be reset.)



**Note: The project and data in the HMI will all be erased if the reset action is proceeded.**


### Dip Switch



SW1	SW2	SW3	SW4	Mode
ON	OFF	OFF	OFF	Touch Screen Calibrate mode
OFF	ON	OFF	OFF	Reserve
OFF	OFF	ON	OFF	Boot Loader mode
OFF	OFF	OFF	ON	Reserve
OFF	OFF	OFF	OFF	Normal

## 4.2.2 Tool bar

When the HMI is booted, user can set the system by using the mouse to click tool bar at the bottom of the screen. Normally, tool bar is hidden automatically. Only by touching the target at the corner of the right-bottom will the tool bar pops up.



### 4.2.2.1 Large Keyboard



Use large keyboard to input the text information.




### 4.2.2.2 Small Keyboard

Use small keyboard to input the numerical information.




### 4.2.2.3 System Information

Network: Display Network information, including HMI IP address and other network information.



Version: Display information of the system version.




#### 4.2.2.4 System Setting

Set or modify system parameters. Password has to be confirmed in view of security.



### a. Network


A project can be downloaded to HMI via Ethernet. The IP address of target (HMI) must be correctly set. If “Auto Get IP Address” is selected, IP address will be automatically assigned from local DHCP network. While if “IP address get from below” is selected, IP address and other network information have to be inputted.



### b. Time/Date

System time/date will be displayed at the corner of the bottom-right after being set up.





### c. Security

The default of the password is 111111. EB8000 provides strict security protection for the HMI.



Local Password

Password for entering the system

Upload Password

Password for uploading the project

Download Password

Password for downloading the project

Upload (History) Password

Password for uploading the historical data

Password confirmation:



Please enter you new password

Password:


Comfirm:

Pass word match

Ok Cancel


#### **d. History**

The tab to clear the historical data in the HMI: Recipe, Event log and Data log.




### e. Miscellaneous

Use the rolling bottom on the screen to adjust the brightness of the LCD.



## f. Upgrade firmware

The function for users to upgrade the firmware.



## g. CF card Status

When new CF card device is detected, this function will be enabled.




## h. VNC server (for X series and i series)

The function is to monitor and control the remote HMI through Ethernet.



1. Enable VNC server and set the password.
2. Install Java for Internet Explorer or install VNC viewer.

For IE, enter HMI IP: <http://192.168.1.28>



For VNC viewer, enter HMI IP address and the password.






**Note:**

- (1) Only allow one user to log in to VNC at one time.
- (2) HMI will reject VNC connection after one hour without operations.

**4.3 HMI Download Settings**


A project or data can be downloaded to HMI via CF card or USB stick. Insert CF card or USB stick and designate the directory path. All contexts under the directory will be downloaded to the HMI. When HMI detects new peripheral devices, the following screen appears:



Several functions can be selected at this time and some of them need password confirmation. Please refer to the illustration below:



After the password is confirmed, directory names of the CF card...etc will be displayed. (PCcard: CF Card ; USB disk: USB device)



Select the download path and click OK for downloading.

**Note:** Users have to create download data from [Build Download Data for CF/USB Disk] from Project Manager.

Generally speaking, Project Manager divides the downloaded files into two directories:

## MT8000

Project storage


## History

When users download the historical data, the directory will be created.

In other words, if the directory of the target file as below,



The data structure is like below diagram:



Users have to select the upper layer of the directory of the target file when downloading. In other words, take the structure above as an example, **download** must be selected. Choosing **mt8000** or **history** is invalid.

Take the illustration below as another example: USB disk only store mt8000 directory but don't includes history. In this case, user must choose **device-0** to correctly download the file.




The startup screen appears after a successful project downloading.



## Chapter 5 System Parameters

In the EB8000, select menu [Edit] / [System Parameters...] and the **System Parameter Settings** dialog appears:



System Parameter Settings are divided into seven parts: **[Device]**, **[Model]**, **[General]**, **[Security]**, **[Font]**, **[Extend Memory]** and **[Printer Server]**, which are introduced respectively in this chapter.

## 5.1 Device

[Device] parameters determine all of the characteristics of each device controlled by a HMI. The device can be a PLC, remote HMI or PC. When opening a new \*.mtp file, a default device: “Local HMI” is shown in the table. That is to say the device table must have a “Local HMI” at least, and it is used to identify current HMI.


**The procedure to create a new device:**

### 5.1.1 How to Control a Local PLC






So-called “local PLC” means a PLC which is connected to a local HMI directly. To control a local PLC, users need to add this type of device first. Click [New...] and the [Device Properties] dialog appears. Correctly filling in all of the properties is required.

Here is an example of MITSUBISHI FX0n/FX2 local PLC:



<b>Name</b>	The name of the device
<b>HMI or PLC</b>	Device type. Select [PLC] in this case.
<b>Location</b>	Position of the device. Select [Local] in this case.
<b>PLC type</b>	Type of PLC. Select MITSUBISHI FX0n/FX2 in this case
<b>PLC I/F</b>	<p>Four PLC interfaces are available: [RS-232], [RS-485 2W], [RS-485 4W], and [Ethernet].</p> <p>If the interface is [RS-232], [RS-485 2W], or [RS-485 4W], click [Settings...] and then [Com Port Settings] dialog appears. Users need to correctly set the COM port communication parameters.</p>



	<p><b>[Timeout]</b> Window No.5 will pop up and appear the “PLC No Response” message once the response time from PLC to HMI over timeout setting.</p> <p><b>[Turn around delay]</b> The delayed interval of two commands. i.e. the next command will be delayed as the setting required to be sent out after the previous command is sent. If no specific request, the default setting is 0.</p> <p>If the interface is [Ethernet], click [Settings...] and then [IP Address Settings] appears. Users need to correctly set IP address and Port No. of the PLC.</p> 
<p><b>PLC default station no.</b></p>	<p>If the device address of the object doesn't include station no., EB8000 will use PLC default setting no. as PLC station no.</p> <p>In addition, PLC station no. can put in device address directly, for example, 1#20</p>  <p>“1” means PLC station no, and has to be named more than 0 and less than 255. “20” means PLC address, the “#” sign is to separate station no. and address.</p>
<p><b>Use broadcast</b></p>	<p>For example, set broadcast value as 255.For device address of 255#20, the</p>

<b>command</b>	HMI will send command to PLC but PLC won't deliver any response to HMI.
<b>Interval of block pack (words)</b>	<p>If the interval of read out address between different commands is less than this value, these commands can be combined to one. But combination function is disabled if this value is 0.</p> <p>For example, the interval value is set as 5 and users would like to read out 1 word from LW3 and 2 words from LW6 respectively. Since the interval of addresses between LW3 and LW6 is less than 5, these two commands can be combined to one. The contents of combination command therefore becomes 5 consecutive words from LW3 (read out from LW3~LW7).</p> <p>Note: Max. combination command must less than [Max. read-command size].</p>
<b>Max. read-command size (words)</b>	The Max. data size to be read out from device at one time. Unit: word
<b>Max. write-command size (words)</b>	The Max. data size to be wrote in to device at one time. Unit: word.

After all settings are completed, a new name “Local PLC” device is listed on the table.


Device list :					
No.	Name	Location	Device type	Interface	I/F Protoc
Local HMI	Local HMI	Local	MT8121T (800 x 600)	Disable	N/A
Local PLC 1	mitsubishi fx0...	Local	mitsubishi fx0n/...	COM1 (9600,E,7,1)	RS485 4W

### 5.1.2 How to Control a Remote PLC




So-called “remote PLC” means a PLC connected to a remote HMI. To control a remote PLC, users need to add this type of device. Click [New...] and the following [Device Properties] dialog appears. Correctly fill in all of the properties are required.

Here take a remote PLC, SIEMENS S7/200, as an example:



Each of parameters is introduced as follows:

<p><b>Location</b></p>	<p>Select [Remote] in this case and set the IP address of the remote HMI which is connected to SIEMENS S7/200 PLC. Click [Settings...] to set the IP address of the remote HMI</p> 
<p><b>PLC Type</b></p>	<p>Type of PLC. Select SIEMENS S7/200 in this case.</p>

<b>PLC I/F</b>	The setting defines which interface the remote PLC uses.
<b>COM</b>	The setting defines which COM port the remote PLC uses.
<b>PLC default station no.</b>	The setting defines which the PLC default station the remote PLC uses.


After all settings are completed, a new name “Remote PLC” device is listed on the table.

Device list :				
No.	Name	Location	Device type	Interface
Local ...	Local HMI	Local	MT8121T (800 x 600)	Disable
Local ...	MITSUBISHI FX0n/FX2n	Local	MITSUBISHI FX0n/FX2n	COM1 (9600,E,7,1)
Remo...	SIEMENS S7/200	Remote(IP:192.168.1...	SIEMENS S7/200	COM1 (9600,E,8,1)

### 5.1.3 How to Control a Remote HMI



So-called “a remote HMI” means through network, the HMI is controlled by a local HMI or a PC running on-line simulation. To control a remote HMI, users should add this type of device. Click [New...] and the following [Device Properties] dialog appears. Correctly fill in all of the properties are required.



Each of settings is introduced as follows:

<b>HMI or PLC</b>	Type of device. Select HMI in this case.
<b>Location</b>	<p>Select [Remote] in this case and click [Settings...] to set IP address of remote HMI and Port no. The port no. of remote HMI and local HMI must be same.</p> <div data-bbox="592 1352 1283 1664" style="border: 1px solid black; padding: 5px;"> </div>

After all settings are completed, a new name “Remote HMI” device is listed on the table.


No.	Name	Location	Device type	Interface	I/F ...	St...
Local...	Local HMI	Local	MT8xxx	N/A	N/A	N/A
Local...	MITSUBISHI F...	Local	MITSUBISHI F...	COM1(96...	RS4...	0
Rem...	SIEMENS S7/200	Remote(IP:192.168.1.10, P...	SIEMENS S7/2...	COM1(96...	RS4...	2
Rem...	Remote HMI	Remote(IP:192.168.1.11, P...	MT8xxx	Ethernet	TC...	N/A


## 5.2 Model

Parameters on [Model] tab determine the HMI model, timer source and printer.

The screenshot shows the 'System Parameter Settings' dialog box with the 'Model' tab selected. The dialog is divided into several sections:

- HMI Model Section:**
  - HMI model: MT6056T/MT8056T (320 x 234)
  - HMI station no: 0
  - Port no.: 8000 (used as MODBUS server's port no.)
- Timer Section:**
  - Clock source: External device
  - PLC name: Local HMI
  - Device type: LW
  - Address: 0
  - 16-bit Unsigned (checked)
  - System tag (unchecked)
  - Index register (unchecked)
- Printer Section:**
  - Type: SP-M, D, E, F
  - COM: COM 3
  - Baud rate: 19200
  - Data bits: 8 Bits
  - Parity: None
  - Stop bits: 1 Bit
  - Pixels of width: 100 pixel(s)
  - Screen hard copy scale: 100%
  - \* 100 pixels (for 1610 type) or 220 pixels (for 2407, 4004 type)
- Storage space management Section:**
  - History data space: 4.0M
  - Max. XOB file size: 8.0M
  - \*Hint: If change storage space, please reset HMI's data logs and event logs.


<p><b>HMI model</b></p>	<p>Select current HMI model as illustration below.</p>  <p>Users are able to resize pop-up windows or objects when configuring the project.</p> 
<p><b>HMI station no.</b></p>	<p>Set the no. of HMI station. If with no particular purpose, select default.</p>
<p><b>Port no.</b></p>	<p>Set the port no. for HMI. It is used as MODBUS server's port no. If with no particular purpose, select default.</p>
<p><b>Timer</b></p>	<p><b>[Clock source]</b></p>  <p>Set the source of timer. The timer is used by such as [Data Log], [Event Log] ....etc. objects which need the time records.</p> <p>a. “HMI RTC” means the time signal comes from internal clock of the HMI.</p> <p>b. “External device” means the time signal comes from external device. The correct address of time source is necessary. Take the illustration below as</p>

	<p>an example: “TV” indicates the time from Local PLC. The context of 6 consecutives addresses starting from 0 shows as follows:</p> <p>TV 0 → Sec.  TV 1 → Min.  TV 2 → Hr.  TV 3 → Day  TV 4 → Month  TV 5 → Year</p> 
<p><b>Printer</b></p>	<p><b>[Type]</b>  Display printer supported. For HP PCL Series, it has to use USB interface while other printers have to use COM interface. For more details, please refer to the “MT8000 support printer” chapter.</p>  <p>Using COM port to connect printer has to set accurate parameters. When the type of printer is SP-M, D, E, F, the [pixels of width] has to set accurately, i.e. the setting can not exceed printer’s default setting. Otherwise the printing result will be incorrect.</p> 
<p><b>Storage space</b></p>	<p>1. Storage space available for the project and historical data is 12MB. By</p>

<p><b>management ( For T series only)</b></p>	<p>adjusting the space of two parts, users can reach their memory requirements. For example, for smaller project, it can get bigger memory space for historical data.</p> <ol style="list-style-type: none"> <li>2. Minimum Project size is 6MB; Maximum Project size is 10 MB (default is 8MB).Minimum Historical data size is 2MB; Maximum Historical data size is 6 MB (default is 4MB).</li> <li>3. Users have batter to copy and erase the original historical data in HMI before the storage space is changed.</li> </ol> <div data-bbox="539 689 1342 846" style="text-align: center;">  </div>
---	--

### 5.3 General

Parameters in [General] tab determine all properties related to screen operations.




<p><b>Fast selection button</b></p>	<p>Define the settings of all attributes for fast selection window which is designated as window number 3.</p> <p><b>[Attribute]</b> Enable or disable fast selection window. Select “Enable” and click [Settings...] to set the attributes of the button, including color and text.</p> <p><b>[Position]</b> Select the location of the fast select button. If “Left” is chosen, the button will show up at the corner of the left-bottom; if “Right” is chosen, the button will show up at the corner of the right-bottom.</p>
<p><b>Screen saver</b></p>	<p><b>[Back light saver]</b> If the duration of no touch operation on screen is equal to this value, back light will be turned off. The setting unit is minute. Back light will be turned on when the screen is touched again.</p>

	<p><b>[Screen saver]</b>  If the duration of no touch operation on screen is equal to this value, the current screen automatically switches to the assigned [Saver window no.]. The setting unit is minute. If “none” value is selected, [Saver window no.] function is disabled.</p>
<p><b>Option</b></p>	<p><b>[Startup window no.]</b>  Designate the window no. after HMI is started up.</p> <p><b>[Extra no. of events]</b>  The default number of the event in the system is 1000. If users would like to add more records, the setting value can be modified up to 10000.</p> <p><b>[Common window]</b></p> <div data-bbox="775 819 1058 913" data-label="Image"> </div> <p>The objects on the common window (window 4) will be shown on each base window. This selection determines the layers these objects are placed above or below the objects of the base window.</p> <p><b>[Keyboard caret color]</b>  Set the color of input caret.</p> <p><b>[Object layout]</b></p> <div data-bbox="796 1368 1032 1462" data-label="Image"> </div> <p>If “Control” mode is selected, when HMI is operated, [Animation] and [Moving Shape] will display above other kinds of objects which is with no relation to the sequence of the object created. If “Nature” mode is selected, the display sequence of objects will follow the creation sequence of the objects.</p> <p><b>[RW_A enabled]</b>  Enable or disable the recipe data RW_A. After activating RW_A, an object can control the content of RW_A. The size of RW_A is 64K.</p>

<p><b>Keyboard</b></p>	 <p>If users would like to create a new keyboard, keyboard should be configured on the existing window. Select [Add...] to add these windows to the list.</p> <p>Please refer to the “designing and using keypad” chapter for details.</p>
------------------------	--


## 5.4 Security

Parameters in [Security] tab determine the classes accessible for each user and users' passwords. Up to twelve passwords can be set. Only numerals are acceptable for the password and the range is from 0~999999999.



According to the security setting, EB8000 will control the classes accessibility for each user.

In EB8000, “None” and “class A to class F”, 7 class choices in total, are provided.




For example, when the security of User 1 is set as below, only can he/she access to None, A, C, and E class.



Please refer to the “Object’s Security Guard” chapter for more details.

## 5.5 Font

Parameters in [Font] tab determine the font of no-ASCII which is used on EB8000




### [Fonts for no-ascii strings]

Fonts for no-ascii strings are listed above. When users use a no-ascii font which isn't listed on [Fonts for no-ascii strings] table, EB8000 will select a font in the list to substitute the front automatically.


User also can test which no-ASCII strings of Windows can be used in HMI and add them to [Fonts for no-ascii strings] table.

## 5.6 Extended Memory

Parameters in [Extended Memory] tab determine the file path of the extended memory.



Extended Memory is numbered from EM1 to EM9. Method to use in extended memory is similar to that in other devices (i.e. Lw or RW address type). Size of each extended memory is up to 2G word.



Data in extended memory is in the form of a file and stores in CF card, USB1 or USB2. The file name of EM0~EM9 are entitled as em0.emi~em9.emi. Users can use RecipeEditor.exe to open the file and edit the data in the extended memory.


External devices such as CF Card and USB memory stick are not affected by power loss. Data stored in these devices is retained regardless of HMI power conditions.

If users would like to read out the data from external device when the external device is removed, the content will be viewed as 0; if users would like to write in the data to external device when the external device is removed, the "PLC no response" message will appear.

The HMI supports "hot swapping" of CF Card and USB devices. There is no need to interrupt operations to change CF Card or USB devices.

## **5.7 Printer Server**

Parameters in [Printer Server] tab are to set up a MT remote printer.



<p><b>Output settings</b></p>	<p>[Orientation] Set the orientation of the words or pictures to be printed out.</p> <p>[Printer size] Set the paper size to be original or to fit the printer margin.</p> <p>[Margin] Set the borderline of the paper, including top, bottom, right and left.</p>
<p><b>Communication settings</b></p>	<p>[IP address] Assign the IP address of a remote printer via network.</p> <p>[Port], [User name], [Password] Assign the access information. Port can be set from 1 to 65535. Max. length of user name or password is 12 characters.</p>

※ Please refer to the appendix Easy Printer for details.

## Chapter 6 Window Operations

### 6.1 Window Types

The basic component of a HMI screen is a Window. Users are able to configure 1997 windows or screens. According to function and usage, there are 4 types of windows in the EB8000.

- a. Base Window
- b. Common Window
- c. Fast Selection Window
- d. System Message Window

#### 6.1.1 Base Window

Base window is the frequently-used type of window.

Except for primary screen, it is also used on:


- a. Foundation base: used as the background for other windows
- b. Keyboard window
- c. Pop-up window for function key object
- d. Pop-up window for direct and indirect window
- e. Screen saver

The illustration below shows the startup screen which uses base window.




## 6.1.2 Common Window

Window 4 is the default of common window. Objects on this window will be displayed on all of other windows so that users always place the shared objects on the common window. When system is in the operation, [Change common window] mode of the function key can be used to change the source of the common window. For example, users can change the common window from window 4 to window 20.




## 6.1.3 Fast Selection Window

Window 3 is defined as the Fast Selection Window. This window can coexist with base window. Generally speaking, it is used by the frequently-used operation buttons as the picture below:



When using the Fast Selection Window, except to create window 3 first, users need to set each function of Fast Selection. The [Startup] on the picture above is the Fast Selection button which is used to enable/disable the Fast Selection. Every setting of the Fast Selection button is in System Parameter Settings. Please refer to the dialog below.



Except switching the attribute of the Fast Selection by Fast Selection button, system register also provides the following addresses for users to designate the values in the address to control Fast Selection and Fast Selection button. Please refer to “system register” for more details.

[LB9013] FS window control [Enable (ON) / Disable (OFF)]

[LB9014] FS button control [Enable (ON) / Disable (OFF)]

[LB9015] FS window / button control [Enable (ON) / Disable (OFF)]

### 6.1.4 System Message Window

Window 5, Window 6, Window 7 and Window 8 are the defaults of system message windows.


Window 5 is the “ <b>PLC Response</b> ” message window	When the communication between PLC and HMI discontinues, the message window will pop up automatically
Window 6 is the message window for “ <b>HMI connection</b> ”	When connection of remote HMI fails, the message window will pop up automatically
Window 7 is set for “ <b>Password Restriction</b> ” message window	If the user who doesn’t have enough authority to access the object, window 7 will pop up according to the security setting content.
Window 8 is set for “ <b>Free Space Insufficient</b> ” message window	<p>When HMI built-in memory, USB memory stick or CF card runs out of storage space, the message window will pop up automatically.</p> <p>Users can use system tag to review the free memory space of HMI, CF card and USB device.</p> <p>[LW 9072] HMI current free space (K bytes) [LW 9074] CF current free space (K bytes) [LW 9076] USB 1 current free space (K bytes) [LW 9078] USB 2 current free space (K bytes)</p> <p>EB8000 also provides warning message to review the memory space insufficient.</p> <p>[LB 9035] HMI free space insufficiency alarm (when ON) [LB 9036] CF free space insufficiency alarm (when ON) [LB 9037] USB 1 free space insufficiency alarm (when ON) [LB 9038] USB 2 free space insufficiency alarm (when ON)</p>

**Note:**

- (1) A screen can display max. 16 pop-up windows simultaneously which include System Message Window, Direct window and Indirect window.
- (2) A window only can be display once simultaneously. It is illegal by using many direct/indirect windows to display the same window in the base window.
- (3) Windows 0~9 are for system use only while windows 10~1999 are for user operation.

## 6.2 Create, Delete and Set a Window

The picture below shows the window information in the EB8000. The following section introduces how to create and set these windows.




### 6.2.1 Create a Window


There are two ways to create a window:

One is selecting a window number on the window tree and right click. Select [New] on the message dialog and click OK after the completion of all settings. Please refer to the example as below:


- + \*10: Main Menu
- 11: Show Toolbar
- 12: **12**
- 13: C New
- 14: F Open
- 15: S Close
- 16: C Delete
- 17: S Settings
- 18
- 19
- 20: Text Object




<b>Name</b>	The name of the window
<b>Window no.</b>	The number of the window, from 3 to 1999
<b>Size</b>	The [Width] and [Height] of the window
<b>Frame</b>	[Width] The width of the frame [Color] The color of the frame

	
<b>Background</b>	<p>[Color] The color of the background</p> <p>[Pattern] The pattern of the background</p> <p>[Pattern color] The color of the pattern</p> <p>[Filled] The option to determine if a window is filled with the color and pattern of the background</p>
<b>Underlay window</b>	<p>[Bottom], [Middle], [Top] Up to three windows can be specified as underlay windows for each base window, from [Bottom] to [Top]. The objects on the underlay windows are displayed in order on the base window.</p>
<b>Popup window</b>	<p>[X], [Y] Base window can also be used as pop-up window. Use [X] and [Y] to set the location of the popup window in the base window</p> <p>[Monopoly] If the option is checked, when a base window used as a pop-up window appears, users are not allowed to operate other windows before the base window is closed. If a base window is used as a keyboard window,” Monopoly “property is automatically enabled.</p>

Another way to create a window is select [Open Window] from menu and [Open Window] dialog appears. Please refer to the illustration below.





Window No., Window Name and Window Size are listed on the message table.

Click [New...] and choose window type from [Select Window Style] dialog. New window can be created after click OK.



## 6.2.2 Window Settings

EB8000 provides two methods to modify window attributes:

- a. Right click on the assigned window from window tree and select [Settings] to change the window properties.



- b. Select [Open Window] from menu and [Open Window] dialog appears. Select [Settings] to change the window properties.

## 6.2.3 Open, Close and Delete a Window

To open an existing window, except double click the window No. from the window tree, users can right click the assigned window from the window tree and choose [Open] to open the window.

Similarly, close or delete an existing window as the procedure above. Please note that the window to be deleted has to be in close status.

## Chapter 7 Event Log

“Event log” is used to identify the content of an event and the conditions triggering this event. In addition, the triggered event (also called as “alarm”) and the processing procedure of the event can be saved to the designate areas (such as HMI memory or external storage devices) in the form of EL\_yyyymmdd.evt where yyyymmdd indicates the time of the file created set by the system automatically. For example, a file name of event, EL\_20061127.evt, means the file was created on Nov. 27<sup>th</sup>, 2006.

EB8000 also provides the following system registers to manage the event log:

[LB 9021] reset current event log (set ON)

[LB 9022] delete the oldest event log file (set ON)

[LB 9023] delete all event log files (set ON)

[LB 9024] refresh event log statistic information (set ON)

[LW 9060] total number of the event log files


[LW 9061] total size of the event log files

### 7.1 Event Log Management

Used with [alarm bar], [alarm display] and [event display]...etc., users are able to clearly understand the life cycle of the whole event from happening, waiting for processing, alarm cleared. Before using these objects, the content of an event has to be identified first.

Click the [Alarm (Event Log)] icon, and [Event Log] dialog appears as below:






**[Category]**

EB8000 provides classification feature. All events can be divided into 0~255 classifications. Alarm Bar, Alarm Display and Event Display can be assigned to be displayed in certain classifications.

[Category] determines the event log catalog of current event.



The [2] of 0[2] in the above illustration demonstrates two existing identified events in the category 0.

**[History files]**

Determine the storage device of an event log. However, when users simulate the project on PC, files will be saved on the same event log subdirectory as EasyBuilder8000.exe.

**[Save to HMI memory]**

Save the event log data to MT8000 memory.

**[Save to CF card]**

Save the event log data to CF card.

**[Save to USB 1]**

Save the event log data to USB disk 1. Numbering rule of USB disk is: the disk inserted to the USB interface in the first place is numbered 1, next is numbered 2 and the last is numbered 3. There's no relation to the interface position.


**[Save to USB 2]**

Save the event log data to USB disk 2.

**[Preservation limit]**


After choosing the device to save the Event log, you can see the "Preservation limit" selection. This setting determines the days of the data preserved. As below picture, the preservation time is two days, which means HMI memory will keep the data of yesterday and the day before yesterday. The data out of this time range will be deleted automatically to prevent the storage space from using up.

For example, today is 7/1, the HMI will keep 6/30, 6/29 data in the memory and 6/28 will be deleted from the memory.



<b>Print</b>	Users need to set Printer on system parameter/model, and message will print out when alarm occurs in order.
<b>New</b>	Create a new event.
<b>Delete</b>	Delete a specific event.
<b>Settings</b>	Modify the definition of a specific event.

### 7.1.1 Excel Editing



There is an Excel icon on the up-right corner of the Alarm (Event Log) dialog for users to edit an Event log. An editing design procedure includes: Excel Edit, Import from Excel and Export to Excel.


### 7.1.1.1 Excel Edit

Weintek provides a standard Excel template in C:\EB8000\EventLogExample.xls for users to edit alarm (event) log. The template includes some dropdown lists for easily usage.

	A	B	C	D	E	F	G	H	I	J	K
1	Category	Priority level	Address type	PLC name	Device type	System tag	User-defined tag	Address	Index	Data Format	Enab
2	0	Middle	Word	Local HMI	EM0	False	False	22	null	32-bit Signed	True
3	1	Low	Bit	Local HMI	LB-9009 : initialized as ON	True	True	122	IDX 1	16-bit BCD	False
4	2	High	Word	Local HMI	RWI	False	False	2222	IDX 4	32-bit BCD	ue
5										16-bit BCD	
6										32-bit BCD	
7										16-bit Unsigned	
										16-bit Signed	
										32-bit Unsigned	
										32-bit Signed	

#### Caution:

1. System tag and User-defined tag can not be set as true simultaneously. If both of them are set as true, the system will view System tag to be true and User-defined tag to be false. If Device type is set as User-defined tag, please set the System tag to be false.
2. The format of Color is R:G:B where and the values of R,G,B are between integer 0~255 .
3. Click Excel icon to open the EventLogExample.xls



### A . Import to Event Log

Click import button to import excel file.

**Alarm (Event) Log**

Category : All [10] 

No.	Category	Text	Mode	Scan time	Condition	Read address	Notification address	Buzzer
1	0	test1	WORD	500 ms	<> 12.22	EM0-22	?-33	Enable
2	1	test2	BIT	500 ms	ON	LB-9009 : initialized as ON:122	Disable	Enable
3	2	test3	WORD	500 ms	<> 337.89	RWI-2222	RBI:5555	Disable
4	3	test4	BIT	500 ms	ON	RW_Bit:33333	I:66666	Disable
5	4	test5	WORD	500 ms	< 4444.67	EM2-444444	MW:777	Enable
6	5	test6	BIT	500 ms	ON	RW_A_Bit:555555	?-8	Enable
7	6	test7	WORD	500 ms	= 888.54	RBI-66	NONAME:99	Enable
8	7	test8	BIT	500 ms	ON	LW-777	Disable	Disable
9	8	test9	WORD	500 ms	<> 6788.98	RW_A:8888	DB11:3333	Disable
10	9	test10	WORD	500 ms	>= 6778.79	LW:9999	DB90Bit:777777	Enable

History files

Save to HMI memory   
 Save to CF card   
 Save to USB 1   
 Save to USB 2

**Caution:**

1. When user-defined tag is set as true in the Excel, if device type can not match with the user-defined tag, system will set false value in user-defined tag.
2. Before importing library (label library and sound library), please make sure library names exist in the system, otherwise those library will not be imported.

**B. Export to Excel**

Click Export excel button to export data in an excel file.

**Alarm (Event) Log**

Category : All [10] 

No.	Category	Text	Mode	Scan time	Condition	Read address	Notification address	Buzzer
1	0	test1	WORD	500 ms	<> 12.22	EM0-22	?-33	Enable
2	1	test2	BIT	500 ms	ON	LB-9009 : initialized as ON:122	Disable	Enable
3	2	test3	WORD	500 ms	<> 337.89	RWI-2222	RBI:5555	Disable
4	3	test4	BIT	500 ms	ON	RW_Bit:33333	I:66666	Disable
5	4	test5	WORD	500 ms	< 4444.67	EM2-444444	MW:777	Enable
6	5	test6	BIT	500 ms	ON	RW_A_Bit:555555	?-8	Enable
7	6	test7	WORD	500 ms	= 888.54	RBI-66	NONAME:99	Enable
8	7	test8	BIT	500 ms	ON	LW-777	Disable	Disable
9	8	test9	WORD	500 ms	<> 6788.98	RW_A:8888	DB11:3333	Disable
10	9	test10	WORD	500 ms	>= 6778.79	LW:9999	DB90Bit:777777	Enable

History files

Save to HMI memory   
 Save to CF card   
 Save to USB 1   
 Save to USB 2

New ...    Delete    Settings ...    **Export excel ...**    Import excel ...    Close

## 7.2 Create a New Event Log

Click [New...], [Event Log] dialog appears with two tabs.

**[General] tab:**

**Alarm (Event) Log**

General Message

Category : 0 Priority level : High

Address type : Word Scan time : 500 ms  
Delay time when power on : 1 second(s)

**Read address**

PLC name : Local HMI  
Device type : LW  
Address : 30  System tag  
 Index register  
16-bit Unsigned

**Notification**

Enable  Set ON  Set OFF

PLC name : Local HMI  
Device type : LB  
Address : 50  System tag  
 Index register

**Condition**

Trigger if value is : = 30  
In tolerance : 1 Out tolerance : 2

**[Category]**

The category of an event.

**[Priority level]**

The priority of an event: According to the degrees of importance, users can choose "Low", "Middle", "High", or "Emergency". When the number of event log is more than max number available in the system (the default is 1000, please refer to [General] of System Parameters to add additional records), less important events (lower priority) will be deleted and new events will be added in.

**[Address type]**

The type of address—Bit or Word mode.

**[Scan time]**

The time interval an event to be examined. System checks if an event is satisfied with the triggered conditions via scan time.

**[Delay time when power on]**

The delay time an event to be examined. If be set, system delays certain time after rebooting so that it's able to check if an event is satisfied with the triggered condition and avoids the unnecessary event log record.

**[Read address]**


By reading the read address, system obtains the value and check if an event is satisfied with the triggered condition. Please refer to Parts/General Settings for further details.

**[Notification]**

When an event is triggered, the specific message is sent out from Notification address. Select [Set ON] to send ON message out from the address. While select [Set OFF], Off message is sent out. Please refer to Parts/General Settings for further information.

**[Condition]**

The trigger condition of an event. When the condition of [Address type] of an event is a “Bit”, “ON” or “OFF” in Trigger can be selected. The illustration below shows if Trigger [On] is selected, i.e. the status of [Read address] changes from OFF to ON, an event will be triggered and generate an event log record (or an alarm).



When the condition of [Address type] of an event is a “Word”, several selections are available as follows:



Under the condition, system will read values from [Read address] and then compare them with the trigger conditions to decide if an event needs to be triggered. Especially if the trigger condition is set as “==” or “<>”, [In tolerance] and [Out tolerance] need be set where [In tolerance] is used for trigger condition and [Out tolerance] is used for system’s normal condition.

Condition: == 30  
 In tolerance: 1      Out tolerance: 2

From the example, the illustration above indicates that if the value of [Read address] is bigger or equal to 29(=30-1) or smaller or equal to 31(=30+1), the event will be triggered.

$$29 \leq [\text{Read address}] \text{ value} \leq 31$$

After the event is triggered, only when the value of [Read address] is bigger than 32( =30+2) or smaller than 28(=30-2) will the system return to the normal condition.

$$[\text{Read address}] \text{ value} < 28 \text{ or } [\text{Read address}] \text{ value} > 32$$

Condition: <> 30  
 In tolerance: 1      Out tolerance: 2


Take another example above, it indicates that system is triggered when the value of [Read address] is less then 29(=30-1) or greater then 31(=30+1).

$$[\text{Read address}] \text{ value} < 29 \text{ or } [\text{Read address}] \text{ value} > 31$$

When the event is triggered, system returns to normal condition only when the value of [Read address] is bigger or equal to 28(=30-2) and smaller than 32(=30+2).

$$28 \leq [\text{Read address}] \text{ value} \leq 32$$

**[Message] tab:**



## Text

### [Content]

The text content showed on [alarm bar], [alarm display] and [event display].  
Display the content of LW address of being triggered object.

Format:  **%#d**

%: initial sign

# : LW's address

d : end sign

For example, if the content is set as “High Temperature = %20d”, when an event is triggered, the value of LW20 will be displayed. i.e. if the value of LW20 is 13 when an event is trigger, the display content of the [event display] will be “High Temperature = 13”.

Except for LW, it can also show the content of Device type in Read address.

Format:  **\$#d**

\$\$: initial sign

# : PLC's address

d : end sign

For example, if Device type in Read address is MW, when message is set as “High Temperature = \$15d” and the value in MW15 is 42, the display content of the [event display] will be “High Temperature = 42”.

### **[Font][Color]**

Users can set Font and color for each event. The font and color of an alarm display or event display object comes from this setting. As below illustration, these two events use different colors and font styles.



### **[Write value for event display]**

When an event item in an event display object is touched, the value is written to the assigned address. Please refer to event display in [Object] chapter for more details.

### **[Sound]**

The warning alarm can be selected when an event is triggered.

Click “Sound Library” to choose warning sound, and click “Play” to check the sound.

After the completion of each setting, a new event definition can be added as below:

### Alarm (Event) Log

Category : All [3] 

No.	Category	Text	Mode	Scan time	Condition	Read address	Notification address	Buzzer
1	0	Event 0	WORD	500 ms	< 0.00	LW-0	Disable	Disable
2	0	Event 1	WORD	500 ms	== 0.00	LW-100	Disable	Enable
3	0	Event 1	BIT	500 ms	ON	LB-50	Disable	Enable

**History files**

Save to HMI memory  
  Save to CF card  
  Save to USB 1  
  Save to USB 2

## Chapter 8 Data Sampling

“Data Sampling” identifies the method of data sampling, including sampling time and sampling location. In addition, EB8000 saves the sample data to the user assigned location and in the form of [Storage location]\[filename]\yyyymmdd.dtl where [storage location] can be HMI, CF card, USB1 or USB2, [filename] is defined by user as a meaningful name and yyyymmdd is the built time set by the system automatically.

EB8000 provides following system registers for data sampling management:

[LB 9025] delete the oldest data sampling file (set ON)

[LB 9026] delete all data sampling files (set ON)

[LB 9027] refresh data sampling statistic information (set ON)


[LW 9063] the number of data sampling files

[LW 9064] total size of data sampling files

### 8.1 Data Sampling Management




Before using Trend display or History data display to review the content of data sampling, the method of data sampling has to be defined. Click [Data Sampling] from toolbar and then Data Sampling Object dialog appears as below.



<b>New</b>	Add a new “data sampling” definition.
<b>Delete</b>	Delete a specific “data sampling”.
<b>Settings</b>	Modify the definition of a “data sampling”.

## 8.2 Create a New Data Sampling

Click [New...] and the Data Sampling Object setting dialog appears as below:



## Read address

### [Max. data records]

Max data records can be saved to a data sampling definition.

Example:


Condition	Set Max. data records as 10 without check “auto. stop”	Set Max. data records as 10 with check “auto. stop”
Trend display – real time	The data will keep latest 10 records on the screen	Stop displaying
Data sampling	Keep recording and delete the oldest data	Stop recording

### [Data Format ...]

The format of a data sampling: A data sampling may include more than one type of records. EB8000 is able to retrieve different types of records at the same time. After clicking [Data Format], user use “Data Format” dialog to define the content of a record.

Take the following as an example, users define three types of data: “Index” (16-bit Unsigned) 、 “Pressure 1”(16-bit Signed) and “Temperature”(32-bit Float) respectively and 4 word length in total. In other words, EB8000 retrieves the length of 4 words as a record starting from the assign address.

Please refer to Parts—General Settings for more details.



**Caution:**

After executing off-line simulation, if users need to change data format, please delete data log file in the C:\EB8000\datalog and then run off-line simulation again.

**[PLC name]**

Select the target PLC of data sampling.

**[Clear address]**

If the status of the assigned address is ON, obtained data will be cleared and the number of data sampling will be set to zero.


**Caution:** the [clear address] is used for “real time” mode of trend display only.

**[Hold address]**


If the status of the assigned address is ON, sampling will be paused until the status of assigned address returns to OFF. Please refer to Parts—General Settings for other details.

**Sampling mode**

EB8000 provides two methods in data sampling: “Time-based” and “Trigger-based”. If “Time-based” mode is selected, EB8000 samples the data in a fixed frequency. Users have to set the “sampling time interval”.



If “Trigger-based” mode is selected, users can use a status of specific address to trigger the data sampling.



## [Mode]

Conditions to trigger the data sampling:

- “OFF → ON”      If the status of assigned address is from OFF to ON, data sampling is triggered.
- “ON → OFF”      If the status of assigned address is from ON to OFF, data sampling is triggered.
- “ON←→ OFF”      If the status of assigned address is changed, data sampling is triggered.

Please refer to Parts—General Settings for more details.

## [Auto stop]

When the number of data sampling is equal to [Max. data records], if the Auto stop option is selected, HMI will stop doing data sampling automatically.

1. If the data source in the [trend display] is real-time mode, the oldest record will be deleted and new record will be added and displayed in the [trend display] object.
2. If the data source in the [trend display] is historical mode, the data keeps being sampled.

## History files

Assign the storage location. But when users do the simulation on PC, data is saved to the same subdirectory as Easy Builder 8000.exe.

## [Save to HMI memory]

Save the sampling to MT8000 display.

## Caution:

The data can be saved when the size of data is more than 4kb, otherwise, users need to use LB-9034 to force the data to be stored.

## [Save to CF card]

Save the sampling to CF card.

## [Save to USB 1]

Save the sampling to USB stick 1. The USB stick numbering rule is: the device inserted to the USB interface in the first place is numbered 1, next is numbered 2 and the last is numbered 3. There's no relation to the interface position.

## [Save to USB 2]

Save the sampling to USB stick 2.

**[Folder name]**

Set the file name of the data sampling.

**Preservation limit:** decide the days of preservation for sampled data.

If the preservation time is two days as below, USB1 memory stick will keep the data of yesterday and the day before yesterday.

For example, today is July 1<sup>st</sup>, the HMI will keep the data of June 30<sup>th</sup> and June 29<sup>th</sup> in the memory but the data of June 28<sup>th</sup> will be deleted.

History files

Save to HMI memory       Save to CF card

Save to USB 1       Save to USB 2

Folder name :

---

Preservation limit      Days of preservation :  day(s)

## Chapter 9 Object General Properties

The contents of object's general properties setting include:


1. Selecting the connection PLC device
2. Setting the reading and writing address
3. Using shape library and picture library
4. Setting text content
5. Adjusting profile size

### 9.1 Selecting the Connection PLC Device

When using some objects, select the connection PLC device is required. See the picture below, [PLC name] is to assign the name of the connection PLC device. The picture shows that there are two PLC devices available for selection: "Local HMI" and "Allen-Brandley DF1." These listed available PLC devices are sourced from "device table" in "System Parameters."



#### 9.1.1 Setting the Reading and Writing Address



The above picture shows that the following items are contained in reading and writing address settings:

### [Device type]

In selection of device types, when the connection PLC device is different, there will be different device types for selection.




### [Address]

Setting the reading and writing address.

### [System tag]

Address tag includes “system tag” and “user-defined tag.” System tag, including bit address system tag and word address system tag, is to reserve the addresses of particular purposes for the system. When selecting “system tag,” in addition to that [Device type] will show the content of “system tag,” [Address] will indicate the selected system tag. Refer to the picture below.




The following pictures show partial contents of bit address system tag and word address system tag respectively, and for further information, please refer to the illustrations in the “label library” section.

### [Index register]


Refer to the illustrations in “index register” section for information on if it is necessary to select “index register” or not.

The EB8000 supports the following listed numeric types. It is necessary to select the proper numeric type, especially when using address tag.



## 9.2 Using Shape Library and Picture Library

Shape Library and Picture Library are used for an object to enhance its visual effect. Go to the [New Bit Lamp Object]/ [Shape] tab to set up Shape Library and Picture Library.



## 9.2.1 Settings of Shape Library

### [Shape Library...]


Select the shape from the library.

### [Use Shape]

Use the shape from shape library if checked.

### [Inner]

Select the color of an object's color. Click [Color] dropdown to choose the color.



### [Frame]


Select the color of the object's Frame. Click [Color] dropdown to choose the color.

### [Interior Pattern]

Select the style of the interior pattern. Click [Color] dropdown to choose the color.

### [Pattern Style]

Click [Pattern Style] button to select the style of the pattern.



**[Duplicate these attributes to every state]**

Duplicate all attributes of the current state to other states.



## 9.2.2 Settings of Picture Library

**[Picture Library]**

Select the picture from the library.

**How to set [Shape Library...]**


Click [Shape Library...] button, the following dialog appears. The currently selected shape is marked by a red frame.



The above illustration gives information of one of the Shapes in the Shape Library as follows:


0: Untitled	The Shape's name and number in the library.
State no.: 2	The number of the Shape's states. In this case, it shows the Shape possesses two states.
Frame	Indicate that the Shape is set with "frame" only.

The Shape below shows that the Shape is set with "inner" and "frame."





Note: Refer to the illustrations in the “Setting-up and using Shape Library and Picture Library” section for the details about all of the settings in the “Shape Library’s setting dialog box.”

Click [OK] and preview the design of the shape after the complication of the settings.



### How to set [Picture Library...]

Click [Picture Library...] button and picture library dialog appears. The currently selected picture is marked by a “red” frame.




The above illustration gives information of one of the Picture in the Picture Library as follows:

Picture name	0 : PB Red	The name of the Picture
Total states	2	The number of the Picture states
Image size	30054	The size of the Picture
Image format	BMP	The format of the Picture; BMP means bitmap Picture and its format can be JPG or GIF.


Refer to the illustrations in the “Setting-up and using Shape Library and Picture Library” section for the details about all of the settings in the “Picture Library’s setting dialog box.”

Click [OK] and preview the design of the picture after the complication of the settings.



### 9.3 Setting Text Content

Go to the [New Bit Lamp Object]/ [Label] tab to set the text content of the object.




### [Use label]

Check [Use label] and click [Label Library] button to add and edit the text. The EB8000 supports Windows true-font.

### [Use label library]

Check [Use label library] and Label tag dropdown whose resource comes from label library appears.



### [Label Library...]

Refer to the illustrations in the “Setting-up and using Text and Label Library” section to view the usage of label library.

**[Font]**

Select font style in font list.

**[Color]**

Select the font color for the text.

**[Size]**

Select the font size for the text. The EB8000 supports all the text sizes.

**[Align]**

Select the alignment method of the text for multiple lines.

The picture below shows how the text to be aligned when “Left” in [Align] is set.

**111**  
**222222**  
**33333333**

The picture below shows how the text to be aligned when “Center” in [Align] is set.

**111**  
**222222**  
**33333333**


The picture below shows how the text to be aligned when “Right” in [Align] is set.

**111**  
**222222**  
**33333333**

**[Blink]**

Select the blink feature of the text:

Choose [None] to disable the feature or choose blinking period as “1 second” or “0.5 seconds”.



**[Italic]**

Use Italic font.

*Italic Label*

**[Underline]**


Use Underline font.

Underline Label

**[Movement] setting**

**[Direction]**

Set the direction of the movement of the marquee effect.



Two options for the marquee to be displayed:

**[Continuous]**



When [Continuous] isn't be checked, the next text appears only after the previous text disappears completely. See the picture below.



When [Continuous] is selected, the text will be displayed continuously.



### [Speed]

Set the speed of the text movement.

### [Content]

Set the content of the text. If using the Label Library, the content will be sourced from the Label Library.

### [Duplicate this label to other states]


This function is used to duplicate the current text content to the other states.

### [Tracking]

When [Tracking] is selected, moving the text of one state will also move the text of other states.

## 9.3.1 Adjusting Profile Size

When a bit lamp is created, double click the object. Go to the [Bit Lamp Object's properties] / [Profile] tab to adjust the position and size of the object.



### a. Position

Pin the position and size of the object. When checked, the position and size of the object will not be able to be changed. X and Y mean the [X] and [Y] coordinate of the top left-hand corner of the object.

### b. Size

Adjust the width and height of the object.

## 9.4 Station Number's Variable

EB8000 V1.31 or above provides variable settings in PLC station number.

As below picture, the var2 is one of 16 station number variables.



Read address

PLC name : MITSUBISHI FX0n/FX2

Device type : TV

Address : var2#123

The syntax of Station number's variable:

varN#address

The range of N is the integer from 0~15; address is PLC's address.

Examples:

var5#234 (var5 is station number, 234 is PLC's address)

var15#456 (var15 is station number, 456 is PLC's address)

16 station numbers are available : var0 ~ var15. The station variables read values from LW10000~LW10015. The list below is variable and its corresponding system reserved address LW :


var0	LW10000
var1	LW10001
var2	LW10002
var3	LW10003
var4	LW10004
var5	LW10005
var6	LW10006
var7	LW10007
var8	LW10008
var9	LW10009
var10	LW10010
var11	LW10011
var12	LW10012
var13	LW10013

var14        LW10014  
var15        LW10015

For example, var0 reads value from LW10000, when LW10000 is 32, var0#234 = 32#234 (the station number is 32); similarly, var13 reads value from LW10013, when LW10013 is 5, var13#234 = 5#234 ◦

### 9.4.1 Broadcast Station No.

MT6000/8000 provides two ways for users to use broadcast command. First one is to directly set the broadcast in EB8000/Edit/System parameters/Device as below:



Second one is to use system tag to enable or disable broadcast station no and change broadcast station no. Corresponding system tag is listed as below:

LB9065        disable/enable COM 1 broadcast station no.  
LB9066        disable/enable COM 2 broadcast station no.  
LB9067        disable/enable COM 3 broadcast station no.

LW9565        COM 1 broadcast station no.  
LW9566        COM 2 broadcast station no.  
LW9567        COM 3 broadcast station no.


## **Chapter 10 Security**

EB8000 security includes two parts:

1. User security and whose operable classes
2. Object's Security

### **10.1 Settings of Password and Classes**

Go to [Edit]/ [System Parameter Settings]/ [Security] to set user security. There are seven levels of user security, including “none”, and “A~F”. Password are Digital only (0-9) and up to 12 sets of user password available.



After the password is entered, the operable objects for the user are decided by security setting. For example, the security setting of user 1 is as below. That's means the user is permitted to operate the objects with security level of "None", and A, C, E.



In addition to inputting the passwords to the system reserved register [LW9220: password], which is a double words value (32 bits), a correct process of password setting requires users to appoint the users by using [LW9219], single word value (16 bits) where digit 1~12 represents User 1 ~ User 12 respectively.

If the password is wrong, [LB 9060: password error] state will be set to ON; if password is correct, [LB 9060] is set to OFF.

The passwords of from user1 to user 12 can be obtained from system reserved registers [LW9500] to [LW 9522], 24 words in total.

Users can change passwords even when the HMI is in operation. By the system reserved register [LB9061: update password (set ON)], when its state is switched from OFF to ON, the EB8000 will use the data saved in the system reserved registers from [LW9500] to [LW9522] to update the password table and create the new passwords.

**Note:** The user operable class won't be changed due to the change of password.

When the state of [LB9050] (user logout) is changed from ON to OFF, current users will be forced to log out the system. At this time, only the object defined as “None” class can be operated.

[LW9222: classes can be operated for current user] records the operable class for current users: bit0 = 1 means the operable object for current users is class A; bit1=1 means the operable object for current users is class B and so on.

## 10.2 Object's Security

**New Function Key Object**

General Security Shape Label

**Safety control**

Min. press time (sec) : 0

Display confirmation request      Max. waiting time (sec) : 10

**Interlock**

Use interlock function

Hide when disabled

Enable when Bit is ON       Enable when Bit is OFF

PLC name : Local HMI

Device type : LB

Address : 0       System tag

Address format : ddddd [range : 0 ~ 11999]

Index register

**User restriction**

Object class : Class A

Disable protection permanently after initial activation

Display warning message if access denied


Make invisible while protected

**Sound**



Enable      Sound Library ...      Sound Index : Default

Play

<p><b>Safety control</b></p>	<p>“Safety control” is mainly used to prevent operator from mis-operating an object accidentally. There are two methods for protection:</p> <p>[Min. press time (sec)] Only continuous pressing time no less than this value can an object be activated successfully.</p> <p>[Display confirmation request] After pressing the object, a confirm dialog will appear. Users need to click “Yes” to make sure the operation execution. If response to confirm dialog longer than the value of [Max. waiting time (sec)], the dialog will disappear automatically and cancel the operation.</p>
------------------------------	--




Message text ( “Please confirm the operation.” ) in the window is defined in [System Message]. Text can be changed from [System Message] dialog. Click System Message icon from tool bar and then System Message dialog appears where the first part is set for the content of operation confirmation.



**Interlock**

When the feature is applied to an object, whether or not an object is allowed to be operated is decided by the state of appointed bit address (or called “Enable” address). ”Enable” address must be in the form of Bit address. The content of the address is set in the following dialog.


	 <p>For example, supposed “Use interlock function” is checked and the “Enable” bit address is set to [LB0]. The object can be operated only when the state of [LB0] is ON. The “Interlock” feature also provides the following settings.</p> <p><b>[Use interlock function]</b> Enable/disable the interlock function.</p> <p><b>[Hide when disabled]</b> When the state of [interlock] function is OFF, hide the object.</p>
<p><b>User restriction</b></p>	<p>This function is used to set the object’s security: define the users permitted to operate the object. When “Operator class” is selected as ”None”, the object operation is open to the users with all security levels. The following settings are also provided in the function:</p> <p><b>[Disable protection permanently after initial activation]</b> Once the operator’s operation class has ever conformed to the security of the object, the system permanently stop checking the security of the object. Even if the security level of the users is changed will not affect the operation of the object.</p> <p><b>[Display warning message if access denied]</b> When the user’s current security level does not conform to the security level of the object, a warning dialog appears.</p>

	
	<p>Window 7 is set as an alert message for authority security. Users can design the content of the message.</p> <p><b>[Make invisible while protected]</b></p> <p>When a user's security level does not conform to the security level of the object, the object will be hidden.</p>

### 10.3 Example of Security


The following is an example to illustrate the steps of security feature:

**Step1:** First of all, create a new project. Go to System parameter/Security, add three users and set different passwords and classes.




User 1 can operate objects with class A, user 2 can operate objects with class A and B, and user 3 can operate objects with class A, B, and C.

**Step2:** Set objects in Window\_10 as below:



[NE\_0] and [NE\_1] are numeric input objects where address are [LW9219] and [LW9220: password] for inputting user ID and password. [LW9219] is for entering user ID (1~12), with the length of 1 word, in the form of 16-bit Unsigned as below.




[LW9220] is for entering user password with the length of 2 words, in the form of 32-bit Unsigned as below.




[ND\_0] is numeric display object with address [LW9222: classes can be operated for current user] to indicate user's state. The data is in the form of 16-bit Binary.



[SB\_0]~[SB\_2] are Set Bit objects which are set with different classes but selected "Make invisible while protected". i.e. [SB\_0] is class A, [SB\_1] is class B, [SB\_2] is class C. The setting of [SB\_0] object:




The Set Bit object (SB\_3, LB9050: user logout) is for user logout as below:




**Step 3:** After complete the design and settings of the objects, save, compile and do the off-line simulation for the project. The illustration as below is initial screen of off-line simulation. At this time, no password is entered.

[LW9222] shown “0000000000000000” means current user only can use object with “none” class. Moreover, [SB\_0]~[SB\_2] are the objects with the security levels of class A~ class C and at the same time “Make invisible while protected“ is selected, therefore, [SB\_0]~[SB\_2] objects are hidden by the system.




**Step 4:** When the user enters the password “111”, the screen will become:



The user 1 is permitted to use object with class A. Consequently, [SB\_0] appears and allows user to operate. Now, bit 0 in [LW9222] becomes 1.

**Step 5:** Next, when the user enters the user 3's password (333), the screen will become:



The user 3 is permitted to use object with class A,B,C. Now, bit 0 ~ bit 3 in [LW9222] become 1 to confirm the current user is allowed to use objects with class A,B,C.

**Step 6:** At this time, if [LB9050] is pressed and force current user to logout, the system will return to initial state. In other words, current user only can use object with “none” class.

User name :  LW9219

Password :  LW9220

Current status :  LW9222  
bit 15 bit 0

LB9050

# Chapter 11 Index Register

## 11.1 Introduction

The EB8000 provides 32 index registers for users to use addresses more flexible. Via index register, users can update object's read / write address without changing content of the object under the machine in operation.

The addresses of the 32 index registers are as follows:

INDEX 0 [LW9200] (16-bit)  
.....  
.....  
INDEX 15 [LW9215] (16-bit)  
INDEX 16 [LW9230] (32-bit)  
.....  
.....  
INDEX 31 [LW9260] (32-bit)

INDEX 0 ~ INDEX 15 are 16-bit registers with the range up to 65536 words; INDEX 16 ~ INDEX 31 are 32-bit register with the range up to 4G words.

## 11.2 Example of Index Register

Here is an example to describe how to use the index registers.

The "Read address" will be [LW100] when [Index register] is not checked.

Read address

PLC name : Local HMI

Device type : LW

Address : 100  System tag

Index register

But in the illustration below, the “Read address” becomes [LW (100 + Index 3)] when [Index register] is checked. “Index 3” represents the value at INDEX 3: LW9203 (16bit) ; in other words, if the value at the [LW9203] is 5, the “Read address” in the becomes [LW105], i.e. [LW100+5].

Read address


PLC name : Local HMI

Device type : LW

Address : 100  System tag

Index : INDEX 3 (16-bit)  Index register

By using index registers, users can change object’s reading and writing addresses in operation without changing the object’s content. For example as below, set Index 3 as 0, i.e. the value at the [LW9203] address is 0. Under this situation, the contents of [LW100 + Index 3] and [LW101 + Index 3] are the same as those of the [LW100] and [LW101].



At this time, the setting of Object A’s “Read address” is:

Read address

PLC name : Local HMI

Device type : LW

Address : 100  System tag

Index : INDEX 3 (16-bit)  Index register

The setting of Object B's "Read address" is:

Read address

PLC name : Local HMI

Device type : LW-9203 (16bit) : address index 3

Address : LW9203  System tag  Index register

The setting of Object C's "Read address" is:


Read address

PLC name : Local HMI

Device type : LW

Address : 100  System tag  Index register


Now, if the user changes Index 3 value to 20, the contents of [LW100 + Index 3] and [LW101 + Index 3] will become those of [LW120] and [LW121], i.e. the values in [LW100+20=LW120] and [LW101+20=LW121].




Similarly, the index register can also work with LB.

1 word = 16 bit, 1 value change of index register means the change of 16 bits.

See the example below. When Index 5 is set as 0, the contents of “Bit Lamp” of [LB0] and [LB6] are the same as those of “Toggle Switch” of [LB0+Index 5] and [LB6+Index 5]



Now, if users change Index 5 value to 1, and then the contents of Toggle Switch are the same as those of [LB16] and [LB22], i.e.[LB0+16=LB16] and [LB6+16=LB22].



## Chapter 12 Keypad Design and Usage

Both “Numeric Input” and “ASCII Input” objects have to use keypad as input tool. Except calling up the keyboard to the screen, users can design a fixed personalized keypad in the same window as input objects.

### 12.1 Steps to Design a Pop-up Keypad


#### Step 1

Create and open a window for a keypad to be added. For example, set WINDOW 200 as the window for a keypad.




#### Step 2

Adjust the height and width of WINDOW 200 and create a variety of kinds of objects as Function Keys. Input signals will be triggered by pressing Function Keys.




The Function Key objects on WINDOW 200 are arranged as above which must to be set as [ASCII/UNICODE mode].


Where FK\_11 is used as the “Escape (Esc)” key and its setting is:



FK\_14 is used as the “ENTER” key and its setting is:



Most of the other Function Keys are used as number or text inputs. For example, FK\_0 is used to trigger signal of input number “1” and its setting is:



At last, select a suitable Picture for each Function Key object. GP\_0 is a “picture” object where is place at the lowest layer as the background.




### Step 3


Go to [General] tab in “System Parameter Settings” and click [Add...] in [Keyboard]. [Add a keyboard] dialog appears. Select WINDOW 200 and press “OK”.



As illustration shown as below, a new item: “200.Keyboard” will be added to [Keyboard] in [General] tab in “System Parameter Settings.”



After a Keypad object is created, when open the object of “Numeric Input” or “ASCII Input”, “200.Keyboard” can be found in [Keyboard] setting tab, as shown below. [Popup Position] is used to decide the display position of the Keypad in a screen where EB8000 divides the screen into 9 areas.



Selecting “200.Keyboard,” when users press “Numeric Input” or “ASCII Input” object. WINDOW 200 will pop up on the HMI screen.



## 12.2 Steps to Use Keypad without Title Bar

### Step 1

Create a Direct window. Set a read address to activate a direct window (ex: LB0).In [General]/[Attribute], select “No title bar” and Window no.




### Step 2

Set WINDOW 200 the same size as keypad.




### Step 3


Create a Numeric Input object, select "Use an external keyboard".



#### Step 4

Add a Set Bit object, set the LB 0 as ON and overlay it on the Numeric Input object. If the user does not want to use the keypad, set LB0 as OFF to disable the feature.






## 12.3 Steps to Use Fixed Keypad

Users can also place a fixed keypad in the same window as input objects. In this way, keypad can't be moved or disabled.


### Step 1

Create a Numeric Input object, and select [Use an external keyboard].




## Step 2

Design a keyboard by function keys and place it on the screen.



## Step 3

Design the keypad by function key objects and place the keypad on the window.



## Chapter 13 Object

This chapter is to illustrate the ways of using and setting all kinds of objects. For those settings generic for all the objects, such as index register, label, shape, and so on, please refer to the chapter “Object’s General Attributes”.

### 13.1 Bit Lamp Object


#### 13.1.1 Overview


Bit Lamp object displays the ON and OFF states of a bit address. If the bit state is OFF, the State 0 shape will be displayed. If the bit state is ON, the State 1 shape will be displayed



#### 13.1.2 Configuration

Click the “bit lamp” icon on the toolbar and the “Bit Lamp Object’s Properties” dialogue box will appear, fill in the content of dialogue box and press OK button, a new bit lamp object will be created. See the pictures below.





<b>Description</b>	A reference name that assigned with the object, the system does not take use of this reference name, it is for user document only.
<b>Read address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the bit device that controls the bit lamp object.
	<b>[Invert signal]</b> Display shape with inverse states; for example, the present state is “OFF”, but it displays the shape of “ON” state.
<b>Blinking</b>	Set blinking attribute of bit lamp.
<b>Blinking time</b>	Set the frequency of blinking

<b>Blinking mode</b>	
None	No blinking.
Alternating image on state 0	Alternatively display the shape of state 0 and state 1 when the bit value is OFF (state 0)
Alternating image on state 1	Alternatively display the shape of state 0 and state 1 when the bit value is ON (state 1)
Blinking on state 0	Display the shape of state 0 in blinking when the bit value is OFF (state 0).
Blinking on state 1	Display the shape of state 1 in blinking when the bit value is ON (state 1).

## 13.2 Word Lamp Object

### 13.2.1 Overview

A Word Lamp object displays the corresponding shape according to the value in the designated word address. (up to maximum of 256 states)

*Numeric Display (LW0)    Word Lamp (LW0)*



*Numeric Display (LW0)    Word Lamp (LW0)*




*Numeric Display (LW0)    Word Lamp (LW0)*



### 13.2.2 Configuration

Click the “Word lamp” icon on the toolbar and the “Word Lamp Object’s Properties” dialogue box will appear, fill in each items and press OK button, a new word lamp object will be created. See the pictures below.






<b>Description</b>	A reference name that assigned with the object, the system does not take use of this reference name, it is for user document only.
<b>Mode and Offset</b>	
Word lamp object offers the following three modes of selection:	
<b>a.</b> “Value” display mode	Calculate result of word value to subtract [offset] and displays its corresponding shape.



	
<b>Read address</b>	Select the <b>[PLC name] [device type][address]</b> of the word device that controls the word lamp object.
<b>Attribute No. of states</b>	The number of the object's states. The state number begins from 0 to [no. of States] - 1. Supposed that the number of the states is 8, the valid states will be 0, 1, 2,..., 7. When the word value is more than [no. of states] - 1, the system will display the shape of last state.

### 13.2.3 Restrictions

In label dialog, Language 1 is able to change attribute settings, for Language 2~8 only font size can be changed and other settings follows language 1.




## 13.3 Set Bit Object


### 13.3.1 Overview

The Set Bit object provides two operation modes: the “manual operation” mode defines a touch area, users can activate the touch area to set the state of the bit device to be ON or OFF. When users select the “automatic operation” mode, the operation will be automatically activated in pre-configured conditions, the touch area is no action at any circumstance.


### 13.3.2 Configuration

Click the “Set Bit” icon in the toolbar and the “New Set Bit Object” dialogue box will appear, fill in each items and press OK button, a new Set Bit object will be created. See the pictures below.





<b>Description</b>	A reference name that assigned with the object, the system does not take use of this reference name, it is for user document only.
<b>Write address</b>	Select the [PLC name] [device type][address] of the bit device that system set value to .
<b>Write after button is released</b>	If this function is selected, the operation is activated at touch up. If the function is not selected, the operation is activated at touch down. If the “Momentary” switch is selected as the operation mode, the [Write after button is released] function will be ignored.
<b>Attribute Set Style</b>	Please refer to the following description for different type of operation mode.

	Set ON	When the operation is activated, the bit device will be set to ON.
	Set OFF	When the operation is activated, the bit device will be set to OFF.
	Toggle	When the operation is activated, the bit device will be set to opposite.
	Momentary	When touch down the area, the bit device will be set to ON, when touch up the bit device will be set to OFF.
	Periodical toggle	The state of the <b>bit device</b> will be switched between ON and OFF periodically. Operation's time interval can be selected in the combo box showed in the picture below:  
	Set ON when window open	When the window containing the Set Bit object is opened, the bit device will be automatically set to ON.
	Set OFF when window open	When the window containing the Set Bit object is opened, the bit device will be automatically set to OFF.
	Set ON when window close	When the window containing the Set Bit object is closed, the bit device will be automatically set to ON.
	Set OFF when window close	When the window containing the Set Bit object is closed, the bit device will be automatically set to OFF.
	Set ON when backlight on	When the backlight is turned on, the bit device is automatically set ON.
	Set OFF when backlight on	When the backlight is turned on, the bit device is automatically set OFF.
	Set ON when backlight off	When the backlight is turned off, the bit device is automatically set ON.
	Set OFF when backlight off	When the backlight is turned off, the bit device is automatically set OFF.
<b>Macro</b>	Users can use set bit object to activate macro commands. Macro commands have	

to be built before configure this function. Please refer to related chapter on how to edit Macros.

**Set style**

The screenshot shows a configuration interface with two main sections: 'Attribute' and 'Macro'.  
In the 'Attribute' section, there is a dropdown menu labeled 'Set style' which is currently set to 'Toggle'.  
In the 'Macro' section, there is a checked checkbox labeled 'Execute macro'. To its right is a dropdown menu labeled 'Macro' set to 't (ID : 1)'. Below that is another dropdown menu labeled 'Trigger mode' which is currently set to 'OFF->ON'. This dropdown menu is open, showing three options: 'OFF->ON' (highlighted in blue), 'ON->OFF', and 'OFF<->ON'.

When “Set style” is selected as “Toggle”, there are three different modes to trig macro command, i.e. OFF->ON, ON->OFF or ON<->OFF.

## 13.4 Set Word Object

### 13.4.1 Overview



The Set Word object provides two operation modes: the “manual operation” mode and the “automatic operation” mode. The “manual operation” mode defines a touch area, and users can activate the area to set the value of the word device. When users select the “automatic operation” mode, the operation will be automatically activated in pre-configured conditions, the touch area is no action at any circumstance.

### 13.4.2 Configuration

Click the “Set Word” icon on the toolbar and the “New Set Word Object” dialogue box will appear, fill in each items and press OK button, a new Set Word object will be created. See the pictures below.



<b>Write address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the word device that system set value to .
<b>[Write after button is released]</b>	If this function is selected, the operation is activated at touch up. If the function is not selected, the operation is activated at touch down.
<b>Notification</b>	When this function is selected, in the “manual operation” mode, the state of the designated bit device will be set to <b>[ON]</b> or <b>[OFF]</b> at the same time that the operation is completed.
<b>[Enable]</b>	Click to select notification function.

<b>[Before writing]</b>	To set the state of the designated bit device before write to word device
<b>[After writing]</b>	To set the state of the designated bit device after write to word device
<b>Attribute</b>	
<b>[Set style]</b>	<p>To set the operation mode. The available modes for selection are listed as follows:</p> 
<p><b>a. “Write constant value”</b></p> <p>Set constant function. When the operation is activated, the [Set value] will be written into the word device. The constant’s format (16-bit BCD, 32-bit BCD, ...) depends on the format of “Write address”.</p> 	
<p><b>“Increment value (JOG+)”</b></p> <p>Increase value function. When the operation is activated, the [Inc. value] will be added to the value of the word device, on the condition that the result is not larger than the value [Upper limit].</p> 	
<p><b>b. “Decrement Value (JOG-)”</b></p> <p>Decrease value function. When the operation is activated, the [Dec. value] will be subtracted from the value of the word device, on the condition that the result is not less than the value [Bottom limit].</p>	

Attribute

Set Style : Decrement value (JOG-)

Dec. value :  Bottom limit :

**c. “Press and hold increment (JOG++)”**

Press and hold increment function. When the touch down is held longer than the time set in [JOG delay], the value of the word device will be added by the value set in [Inc. value] at the speed set in [JOG speed], on the condition that the result is not larger than the value in [Upper limit].

Attribute

Set Style : Press and hold increment (JOG++)

Inc. value :  Upper limit :

JOG delay :   JOG speed :

**e. “Press and hold decrement (JOG--)”**

Press and hold decrement function. When the touch down is held longer than the time set in [JOG delay], the value of the word device will be subtracted by the value set in [Dec. value] at the speed set in [JOG speed], on the condition that the result is not smaller than the value in [Bottom limit].

Attribute

Set Style : Press and hold decrement (JOG--)

Dec. value :  Bottom limit :

JOG delay :   JOG speed :

**f. “Periodical JOG++”**

Periodically increment function. A set word object can use the interval set in [Break time] and the value set in [Inc. value] to automatically increase the value of the word device, on the condition that the result is not larger than the value in [Upper limit].

Attribute

Set Style : Periodic JOG++ (up->0->up->...)

Inc. value : 1      Upper limit : 0

Time interval : 1.0 second(s)

**g. “Automatic JOG--”**

Periodically decrement function. A set word object can use the interval set in [Break time] and the value set in [Dec. value] to automatically increase the value of the word device, on the condition that the result is not smaller than the value in [Bottom limit].

Attribute

Set Style : Automatic JOG-- (down to low limit)

Dec. value : 1      Bottom limit : 0

Time interval : 1.0 second(s)

**h. “Periodical bounce”**

Periodically bouncing function. A Set word object will add the value set in [Inc. value] to the value of the word device at the regular intervals set in [Break time] until the resulting value reaches the value in the [Upper limit], and then subtract the value set in [Inc. value] from the value of the word device at the same intervals until the result value reaches the value in the [Bottom limit]. In the example shown below, the value in the word device will change periodically in order of 0, 1, 2..., 9, 10, 9, 8, 7,..., 1, 0, 1, 2.....

Attribute

Set Style : Periodic bounce (up->down->up->...)

Bottom limit : 0      Upper limit : 1

Inc. value : 1

Time interval : 1.0 second(s)

**i. “Periodical step up”**

Stepping up function. A Set word object will add the value set in [Inc. value] to the value of the word device at the regular intervals set in [Break time] until the result value reaches the value in the [Upper limit], and the value of the word device will return to the value of the [Bottom value] and then repeat the action to keep the value

in an active state. In the example shown below, the value of the word device will change periodically in order of 0, 1, 2,..., 9, 10, 0, 1, 2, .....

The screenshot shows a dialog box titled "Attribute" with the following settings:

- Set Style: Periodic step up (low to high...)
- Low limit: 0
- High limit: 10
- Inc. value: 1
- Time interval: 0.5 second(s)

**j. “Periodical step down”**

Stepping down function. A Set word object will subtract the value set in [Dec. value] from the value of the word device at the regular intervals set in [Break time] until the result value reaches the value of the [Bottom limit], and the value of the word device will return to the value of the [Upper value] and then repeat the action to keep the value in an active state. In the example shown below, the value of the word device will change periodically in order of 10, 9, 8,..., 1, 0, 10, 9, 8, .....

The screenshot shows a dialog box titled "Attribute" with the following settings:

- Set Style: Periodic step down (high to low...)
- Low limit: 0
- High limit: 10
- Dec. value: 1
- Time interval: 0.5 second(s)

**k. “Set when window open”**

When the window containing the object is opened, the value of [Set value] will be automatically written into the word device.

The screenshot shows a dialog box titled "Attribute" with the following settings:

- Set Style: Set when window opens
- Set value: 5

**l. “Set when window close”**

When the window containing the object is closed, the value of [Set value] will be automatically written into the word device .

Attribute

Set Style : Set when window closes

Set value : 5

**m. "Set when backlight on"**

When the backlight is turned from off to on, the value of [Set value] will be automatically written into the word device.

Attribute

Set Style : Set when backlight on

Set value : 5

**n. "Set when backlight off"**

When the backlight is turned from on to off, the value of [Set value] will be automatically written into the word device.

Attribute

Set Style : Set when backlight off

Set value : 5

## 13.5 Function Key Object


### 13.5.1 Overview

Function key object is used to change base window, pop-up window and close windows. It can also be used to design the keypad buttons.

### 13.5.2 Configuration




Click the “Function Key” icon on the toolbar and the “Function Key Object’s Properties” dialogue box will appear, fill in each items and press the OK button, a new function key object will be created. See the pictures below.






Function Key object provides the following operation modes:

<b>[Active after button is released]</b>	If this function is selected, the operation is activated at touch up. If the function is not selected, the operation is activated at touch down.
<b>[Change full-screen Window]</b>	Change base window. <b>[NOTE]:</b> Do not use this function to pop up the window which has been opened by direct / indirect window object.
<b>[Change Common]</b>	Change common window; refer to the “windows” chapter for related information.

<b>[Window]</b>	
<b>[Display Popup Window]</b>	<p>Pop up window. The pop up window must be on the top of the base window. There is a [Close when change window] option with this function, see the picture below; when the function is selected, the pop up window will be closed when executing change base window. Otherwise, users have to set a “Close” button on the pop-up window to close the window.</p> 
<b>[Window no.]</b>	This is used to select the window no. when performing “change base window”, “change common window”, and “pop up the window”
<b>[Return to Previous Window]</b>	This is used to return to the previous base window. Fox example, when changing window 10 to window 20, users can use this function to return to window 10. This function is only available for base window change.
<b>[Close window]</b>	Close the pop-up windows on the top of the base window.
<b>Items in ASCII mode</b>	<p>[ASCII mode] is used as element to configure a keypad, the keypad is used where numbers or texts are needed to input to the numeric input object or ASCII input object. Refer to the “Designing and Using Keypad” chapter for detailed information.</p>  <p><b>[Enter]</b> Same as the keyboard’s “enter” function.</p> <p><b>[Backspace]</b> Same as the keyboard’s “backspace” function.</p> <p><b>[Clear]</b> To clear the temperate input alphanumeric strings stored in the buffer.</p> <p><b>[Esc]</b> Same as the [Close window] function, it is used to close the keyboard window.</p> <p><b>[ASCII]</b> To set the characters that are input in the numeric input object and the ASCII input object. Digital characters such as 0,1,2... or ASCII characters like a,b,c,... etc. are available for selection.</p>
	<p><b>[Execute Macro]</b></p> 


	<p>Macro commands are executed with this selection. Macro commands have to be built before users choose this function. Please refer to related chapter on how to edit Macros.</p> <p><b>[Screen hard copy]</b></p> <p>Hardcopy current display screen to the printer attached with MT8000. Before using this function, please choose printer model in System Parameter / Model / printer. If printer does not support color, user can select grayscale to have a better printout effect. Black and white is for improving text printing quality.</p> 
<b>Notification</b>	
<b>[Enable]</b>	When the function is selected, the MT8000 will set the state of the designated bit device to [ON] or [OFF] after the action is completed.

### 13.5.3 Non-ASCII character input

Below we illustrate the method to input non-ascii character such as Traditional Chinese, Simplified Chinese, Japanese, Greece and so on.

Step1: Setting non-ascii fonts

Go to System parameter/Font and add non-ascii fonts in the “Fonts for non-ascii strings” list. For example, use “AR MinchoL JIS” for Japanese, ” AR MingtiM GB” for simplified Chinese, ” AR MingtiM KSC” for Korean, ” Arial” for Greek, please refer illustration below.




Step2: Design non-ascii input keypad

Create “window11” for non-ascii input keypad, keypad design is shown below.




Those object on the window are function keys with input code in accord with the label . For example, to input ”简” function key, create a function key object/General/[ASCII]/[UNICODE] mode, type in ”简” in the column as below illustration.




Go to Function key/Label and then select “Use label”, type ”简” in the content and in the Attribute/Font select ” AR MingtiM GB”, it must be the same as setp1’s setting, as illustrated below.

The label of non-ascii function key must use the same Font. For example, in simplified Chinese keypad, the fonts all use ” AR MingtiM GB”.



After complete the keypad configuration, add window11 into System Parameters / General / keyboard as illustration below.



## 13.6 Toggle Switch Object


### 13.6.1 Overview

Toggle Switch object is a combination of bit lamp object and set bit object. The object can be used not only to display the state of a bit device but also to define a touch area, when activated, the state of the bit device will be set to “ON” or “OFF”.

### 13.6.2 Configuration

Click the “Toggle Switch” icon on the toolbar and the “New Toggle Switch Object” dialogue box appear, fill in each item, and press OK button, a new toggle switch object will be created. See the pictures below.





<b>Read address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the bit device that control the display of toggle switch state.
<b>Write address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the bit device that system set value to. The write address can be the same as or different from the read address
	<b>[Write when button is released]</b> Refer to the “Set Bit Object” section of this chapter for related information.
<b>Attribute</b>	This is used to select the operation mode. The available operation modes for

	selection include “Set ON”, “Set OFF”, ”Toggle”, and ”Momentary”. Refer to the illustrations in the “Set Bit Object” section of this chapter for related information.
<b>Macro Commands</b>	Users can execute macro command by triggering toggle switch. This function is the same as that of set bit object. Please refer to “the chapter of set bit object”.

## 13.7 Multi-Switch Object

### 13.7.1 Overview

Multi-State Switch object is a combination of word lamp object and set word object. The object can be used not only to display the state of a word device but also to define a touch area, when activated the value of the word device can be set.

### 13.7.2 Configuration

Click the “Multi-State Switch” icon on the toolbar and the “New Multi-State Switch Object” dialogue box will appear, fill in each item, then click OK button, a new Multi-State Switch object will be created. See the pictures below.



**New Multi-State Switch Object**

General Security Shape Label

Description :

Mode : Value  Offset : 0

**Read address**

PLC name : Local HMI

Device type : LW

Address : 0   System tag

Address format : ddddd [range : 0 ~ 10255]

Index register

16-bit Unsigned

**Write address :**

PLC name : Local HMI

Device type : LW

Address : 0   System tag

Address format : ddddd [range : 0 ~ 10255]

Index register

16-bit Unsigned

Write when button is released

**Attribute**

Switch style : JOG+  No. of states : 1

Cyclical : Disable

User-defined mapping

OK Cancel Help

<b>[Mode]</b>	There are “Value” and “LSB” display mode. Refer to the “Word Lamp Object” section of this chapter for related information.
<b>[Offset]</b>	It is used in the “Value” display mode. Refer to the “Word Lamp Object” section of this chapter for related information.
<b>Read address</b>	Select the <b>[PLC name] [device type][address]</b> of the word device that controls the display of multi-state switch..
<b>Write address</b>	Select the <b>[PLC name] [device type][address]</b> of the word device that system set value to. The write address can be the same as or different from the read address.

	<p><b>[Write when button is released]</b></p> <p>Refer to the “Set Bit Object” section of this chapter for related information.</p>
<b>Attribute</b>	Select the object’s operation mode.
<b>[Switch style]</b>	<p>There are “JOG+” and “JOG-” for selection. When the read address is the same as the write address, the minimum value of the word value is [Offset] (state 0), and the maximum value is “[no. of state] -1 + [Offset]”. See the picture below.</p> <p style="text-align: center;"><i>Numeric Display (LWO) Multi-State (LWO),offset = 1</i></p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid gray; padding: 5px; text-align: center;">2</div> <div style="background-color: #008080; color: white; padding: 5px; text-align: center; font-weight: bold;">State 1</div> </div> <p><b>a. “JOG+”</b></p> <p>When the Multi-State Switch object is activated, the value of the write address will be added by 1. In the “Value” display mode, if the resulting value is equal to or larger than the value of [No. of States] + [Offset] and “Enable” in [Cyclic] is selected, the value of the write address will return to [Offset] and show the state 0; otherwise the value of the write address will maintain as ([No. of states] – 1) + [Offset] and shows the state ([No. of states no.] – 1).</p> <p><b>NOTE:</b> Like the word lamp object, the state shown by Multi-State Switch object is the value of the word device subtracts [Offset].</p> <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> <p><b>Attribute</b></p> <p>Stwich style : JOG+      State no. : 5</p> <p>Cyclic : Enable</p> </div> <p><b>b. “JOG-”</b></p> <p>When the Multi-State Switch object is activated, the value of the write address will be subtracted by 1. In the “Value” display mode, if the resulting value is smaller than the value of [Offset] and “Enable” in [Cyclic] is selected, the value of the register will change to ([No. of states] – 1) + [Offset] and shows the state ([No. of states no.] – 1); otherwise the value of the word device will remain in [Offset] and shows the state 0.</p>

## 13.8 Slide Object


### 13.8.1 Overview

The slide object can be used to display the value of word device.

### 13.8.2 Configuration

Click the “slide object” icon on the toolbar and the dialogue box will appear, fill in each items and click OK button, a new slide object will be created. See the picture below.






<b>Write address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the word device that system set value to
<b>Notification</b>	When this function is selected, the state of the designated bit device can be set at the same time as the operation is completed. There are <b>[ON]</b> and <b>[OFF]</b> selection to set the state.
	<b>[Enable]</b> This is to select whether or not to use the function.
	<b>[Before writing]</b> To set the state of the designated register before write to the word device.

**[After writing]**


To set the state of the designated register after write to the word device.



**Attribute**

**[Direction:]**

The bar on the slide direction, i.e. left, right, up and down.



**[Resolution:]**

The slider will move in every [N] lines step, where [N] is the resolution.

For example,

if [N] = 10, every 10th line will be displayed

if [N] = 5, every 5th line will be displayed

if [N] = 1, every line will be displayed


**[Low limit & High limit: ]**

**a. Constant**

The low limit and high limit of the word device is set as constant value. i.e. [Input low] and [Input high]

**b. Address**

The low / high limit of the word device is controlled by an designated address.



Control address	Low Limit	High Limit
16-bit format	Address+0	Address+1
32-bit format	Address+0	Address+2

**[Coarse increment:]**

If this option is selected, the word value will increase/decrease one [increment] value for every touch activation. If not, the word value will be set the value in accord with the touch activated point.

<b>Moving piece</b>	There are four moving piece for selection. You also can adjust the width of moving piece.
<b>Frame/Background/Slot</b>	This is use to select slide object frame, background and slot's color.


## 13.9 Numeric Input and Numeric Display Objects

### 13.9.1 Overview

Both of the Numeric Input object and the numeric display object can be used to display the value of the word devices. The difference is the numeric input object can be used to input data from the keypad, the input value is written to the designated word devices.

### 13.9.2 Configuration

Click the “numeric input” or “numeric display” icon on the toolbar and the “New Numeric Input Object” or “New Numeric Display Object” dialogue box will appear, fill in each items, click OK button and a new “Numeric Input Object” or “Numeric Display Object” will be created. See the pictures below.



The difference between the “New Numeric Input Object” and “New Numeric Display Object” dialogue boxes is that the latter has the settings for ”Notification” and keypad input while the former doesn’t have. The picture below shows the [General] tab in “New Numeric Display Object.”

**New Numeric Input Object**

General Numeric Format Security Shape Font

Description :

**Read address**

PLC name : Local HMI

Device type : LW

Address : 0  System tag

Address format : ddddd [range : 0 ~ 10255]  Index register

**Notification**

Enable  Set ON  Set OFF

Before writing  After writing

PLC name : Local HMI

Device type : LB

Address : 0  System tag

Address format : ddddd [range : 0 ~ 11999]  Index register

**Input order**

Enable Input order : 1  Group

**Keyboard**

Use an external keyboard

Window no. : 50. Keypad 1 - Integer


Popup position :   
{relative to HMI screen}

Hint : If the keyboard is an USB keyboard, on indirect/direct window, or on the same window, please check "Use an external keyboard".

OK Cancel Help


<b>Read address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the word device that system display its value and write new data to it.
<b>Notification</b>	When this function is selected, the state of the designated bit device will be set to <b>[ON]</b> or <b>[OFF]</b> after the value of the register is changed successfully.
	<b>[Enable]</b> Click to enable notification function.
	<b>[Before writing]</b> To set the state of the designated bit device before update the word device..
	<b>[After writing]</b>

	To set the state of the designated bit device after update the word device.																				
<b>Input Order</b>	When user input value into “Numeric input” or “ASCII input” and then press ENT, the system will automatically search next active Numeric or ASCII input object.																				
<b>[Input Order]</b>																					
	<p><b>a. Check Input order</b></p> <p>[Numeric input] has a [Input order] and [Group], click “Enable” to active this function. In the [Input order], input the sequence number for each input object, and the system will follow this order to the next object.</p>																				
	<p><b>b. Check Group</b></p> <p>User can define separate input objects to different group. The system will only search the next object in the same group.</p> <div style="text-align: center; margin: 10px 0;"> <table border="0"> <tr> <td></td> <td style="color: blue; font-weight: bold;">Group 1</td> <td></td> <td style="color: red; font-weight: bold;">Group 2</td> </tr> <tr> <td style="color: blue;">Input Order 1</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="11"/></td> <td style="color: red;">Input Order 1</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="21"/></td> </tr> <tr> <td style="color: blue;">Input Order 2</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="21"/></td> <td style="color: red;">Input Order 2</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="22"/></td> </tr> <tr> <td style="color: blue;">Input Order 3</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="31"/></td> <td style="color: red;">Input Order 3</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="32"/></td> </tr> <tr> <td style="color: blue;">Input Order 4</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="41"/></td> <td style="color: red;">Input Order 4</td> <td><input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="42"/></td> </tr> </table> </div>		Group 1		Group 2	Input Order 1	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="11"/>	Input Order 1	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="21"/>	Input Order 2	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="21"/>	Input Order 2	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="22"/>	Input Order 3	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="31"/>	Input Order 3	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="32"/>	Input Order 4	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="41"/>	Input Order 4	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="42"/>
	Group 1		Group 2																		
Input Order 1	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="11"/>	Input Order 1	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="21"/>																		
Input Order 2	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="21"/>	Input Order 2	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="22"/>																		
Input Order 3	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="31"/>	Input Order 3	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="32"/>																		
Input Order 4	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="41"/>	Input Order 4	<input style="width: 50px; height: 25px; border: 1px solid blue;" type="text" value="42"/>																		
	<p><b>c.</b> In online operation, please click ES button to stop the system searching for the NI object.</p>																				

	
	<p><b>NOTE</b> :If one of input object has set “interlock” function, this object will be skip in the “next input object search”.</p> <ul style="list-style-type: none"> <li>● [Input order] range from 1 to 511</li> <li>[Group] range from 1 to 15</li> </ul>
<p><b>Keyboard</b></p>	<p>There are two ways to display keyboard, one is to use system parameter/ General/ keyboard, to include standard keyboard into the project. The another is to select “external keyboard” and use direct window to display customized keyboard. The customized keyboard is composed of function key.</p> <p>When using the Numeric Input Object, you may select the keypad style. Then select the window where the keypad displayed and set the position in the window. When the Numeric Input object is activated, the popup window of keypad will appear automatically. Refer to the “Designing and Using Keypad” chapter for further information.</p>



The picture below shows the [Numeric Format] tab, included in both of the numeric input object and the numeric display object, which is to set the data display format.



<p><b>Display</b></p>	<p><b>[Data format]</b>          To select the data format of the word device designated by the “Read address”. The selection list is shown as follows:</p>
-----------------------	---

	<div data-bbox="790 203 1018 472" style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> 16-bit BCD  32-bit BCD  16-bit Hex  32-bit Hex  16-bit Binary  32-bit Binary  16-bit Unsigned  16-bit Signed  32-bit Unsigned  32-bit Signed  32-bit Float </div> <p><b>[Mask]</b>  When the data is displayed, “*” will be used to replace all digitals and the color warning function will be cancelled.</p>
<b>Number of digits</b>	<p><b>[Left of decimal Pt]</b>  The number of digits before the decimal point.</p> <p><b>[Right of decimal Pt]</b>  The number of digits after the decimal point.</p>
<b>Scaling option</b>	<p><b>[Do conversion]</b>  The data displayed on the screen is the result of processing the raw data from the word address designated by the “Read address.” When the function is selected, it is required to set [Engineering low], [Engineering high], and [Input low] and [Input high] in the “Limitation”. Supposed that “A” represents the raw data and “B” represents the result data, the converting formula is as follows:</p> $B = [\text{Engineering low}] + (A - [\text{Input low}]) \times \text{ratio}$ <p>where, the ratio = <math>([\text{Engineering high}] - [\text{Engineering low}]) / ([\text{Input high}] - [\text{Input low}])</math></p> <p>See the example in the picture below, the raw data is 15, after being converted by the above formula as <math>10 + (15 - 0) \times (50 - 10) / (20 - 0) = 40</math>, and the result “40” will be displayed on the numeric input object.</p> <div data-bbox="483 1608 1323 1899" style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;"> <p><b>Scaling option</b></p> <p><input checked="" type="checkbox"/> Do conversion</p> <p>Engineering low : <input type="text" value="10"/>      Engineering high : <input type="text" value="50"/></p> <hr/> <p><b>Limits</b></p> <p><input checked="" type="radio"/> Direct      <input type="radio"/> Dynamic limits</p> <p>Input low : <input type="text" value="0"/>      Input high : <input type="text" value="20"/></p> </div>
<b>Limits</b>	To set the source of the range for the input data and to set the warning color effect.

### [Direct]

The low limit and high limit of the input data can be set in [Input low] and [Input high] respectively. If the input data is out of the defined range, the input value will be ignored.

### [Dynamic limits]

Limits

Direct  Dynamic limits

PLC name : Local HMI

Device type : LW Device address : 100

Index register

Low limit : [Yellow bar] [Dropdown]  Blink

High limit : [Red bar] [Dropdown]  Blink

Set the low limit and high limit of the input data to be derived from the designated register. The data length of the designated register is the same as the input object itself. In the above example, the low limit and high limit are derived from [LW100] and the following explains the usage of the low limit and high limit from designated address.

a. If the input object data format is “32-bitBCD”, then

- [LW100] low limit position (32-bit BCD)
- [LW100 + 2] high limit position (32-bit BCD)

b. If the input object data format is “16-bit unsigned”, then

- [LW100] low limit position (16-bit unsigned)
- [LW100 + 1] high limit position (16-bit unsigned)

c. If the input object data format is “32-bitfloat”, then

- [LW100] low limit position (32-bit float)
- [LW100 + 2] high limit position (32-bit float)

### [Low limit]

When the value of the PLC’s register is smaller than [Low limit], the value is displayed with pre-defined color.


### [High limit]

When the value of the PLC’s register is larger than [High limit], the value is

displayed with pre-defined color..

**[Blink]**

When the value of the PLC's register is smaller than [Low limit] or larger than [High limit], the object will display data with Blinking. The picture below shows the [Font] tab, available in both of the numeric input object and the numeric display object to set font, font size, color, and aligning mode.




**Attribute**

**[Color]**

When the data is within high and low limit, it will be displayed with this color..

**[Align]**

There are three aligning modes: "Left", "Leading zero", and "Right". The picture below shows the style of each modes.



**[Size]**

Set font size


## 13.10 ASCII Input and ASCII Display Objects

### 13.10.1 Overview


Both of the ASCII input object and the ASCII display object can display the value of the designated word devices in ASCII format. The ASCII input object can also accept the data input from the keypad and change the value of the word devices.

### 13.10.2 Configuration


Click the “ASCII Input” or “ASCII Display” icon on the toolbar and the “New ASCII Input Object” or “New ASCII Display Object” dialogue box will appear, fill in each items, press OK button, a new “ASCII Input Object” or “ASCII Display Object” will be created. See the pictures below.




The difference between the “New ASCII Input Object” and “New ASCII Display Object” dialogue boxes is that the latter has the settings for “Notification” and keypad input while the former doesn’t have. The picture below shows the [General] tab of the “New ASCII Input Object.”



<b>Use UNICODE</b>	Click “Use UNICODE” to display data in UNICODE format. Otherwise the system displays the character in ASCII format. This feature can be used with function key [UNICODE]. Not every Unicode has corresponding font stored in the system. The font of UNICODE is only available for those Unicode character that registered function key.
<b>Reverse high/low byte</b>	In normal condition, the ASCII code is displayed in “low byte”, “high byte” order. The reverse selection make the system display ASCII characters in “high byte”, “low byte” order.
<b>Read address</b>	Select the [PLC name] [device type][address] of the word device that system

	<p>display its value and write new data to it.</p> <p><b>[No. of words]</b>          To set the length of ASCII data in the unit of words. Each ASCII character take one byte, each word contains two ASCII characters.</p> <p>In the example shown below, the object will display <math>3 * 2 = 6</math> characters.</p> <div style="text-align: center;">  </div>
<b>Notification</b>	<p>When this function is selected, the state of the designated bit device will be set to [ON] or [OFF] after the value of the word devices are changed successfully.</p> <p><b>[Enable]</b>          Make notification selection enable.</p> <p><b>[Before writing]</b>          To set the state of the bit device before update the ASCII data.</p> <p><b>[After writing]</b>          To set the state of the bit device after update the ASCII data.</p>
<b>Input order</b>	<p>When user input value into “Numeric input” or “ASCII input” and then press ENT, the system will automatically search next active Numeric or ASCII input object.</p> <p><b>1. Check Input order</b>          [ASCII input] has a [Input order] and [Group], click “Enable” to active this function. In the [Input order], input the sequence number for each input object, and the system will follow this order to the next object.</p> <p><b>2. Check Group</b>          User can define separate the input objects to different group. The system will only search the next object in the same group.</p> <div style="text-align: center;">  </div> <p>To stop the system searching for the next objects, please click Esc button.</p>




If one of input object has set “interlock” function, this object will be skip in the “next input object search”.

- [Input order] range from 1 to 511
- [Group] range from 1 to 15

**Keyboard**

There are two ways to display keyboard, one is to use system parameter/ General/ keyboard, to include standard keyboard into the project. The other is to select “external keyboard” and use direct window to display customized keyboard. The customized keyboard is composed of function key.

When using the ASCII Input Object, you may select the keypad style. Then select the window where the keypad displayed and set the position in the window. When the ASCII Input object is activated, the popup window of keypad will appear automatically. Refer to the “Designing and Using Keypad” chapter for further information.



<p><b>Attribute</b></p>	<p>The picture shows the [Font] tab of the ASCII Input object and the ASCII display object. Users can set the font, font size and color, and aligning mode.</p> 
	<p><b>[Align]</b></p> <p>There are two aligning modes: “Left” and “Right”. The picture below shows</p>

how each mode performs.

*Left alignment*

ab

bde

*Right alignment*

ab

bde

**[Size]**

Set font size.

## 13.11 Indirect Window Object


### 13.11.1 Overview

“Indirect window” object is to define a popup window location (position / size) and a word device. When the content of the word device is written a valid window number, the window will be popup in the predefined location. The popup window will be closed when the value of the word device is reset (0). The system will only take action when the content of word device is changed ( 0 → valid window number, nonzero → 0, A → B valid window number ).


### 13.11.2 Configuration

Click the “indirect window” icon on the toolbar and the “New Indirect Window Object” dialogue box will appear, fill in each items, click OK button , a new “Indirect Window Object” will be created. See the pictures below.





<b>Read address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the word device that control the window popup.
<b>Attribute</b>	<b>[Style]</b> To set the display style of the popup window. There are two styles, “No title bar” and “With title bar”.
	<b>a. “No title bar”</b> The popup window does not have title bar, and its position is fix as predefined in configuration.

	
	<p><b>b. “With title bar”</b>  The Popup window contains title bar, and its position can be dragged at online operation.</p> 

### 13.11.3 Example to use indirect window

Here is a simple example to illustrate indirect window object. The pictures show how to configure an indirect window and use the word device [LW100] to change the popup window.

**WP\_0**

**SW\_0**

**SW\_1**

**SW\_2**

Read address

Device type : LW ▼

Address : 100  System tag

Index register

16-bit Unsigned ▼

*Set constant 35 to LW100*

*Set constant 36 to LW100*

*Set constant 0 to LW100*

```

34
+ *35: WINDOW_035
+ *36: WINDOW_036
37
38

```

Use the set word object SW\_0 to set the value of [LW100] as 35, and the location of indirect window will display window 35.



Use the set word object SW\_1 to set the value of [LW100] as 36, and the location of indirect window will display window 36.



No matter window 35 or 36 is displayed on the indirect window location, press SW\_2 to set the value of [LW100] to 0 will close the popup window. The other way to close the popup window from indirect window object is to configure a function key with [close window]. Once you press the function key the popup window will be closed.

**NOTE:** Do not use this function to open the window when the same window has been opened by function key or direct window.

## 13.12 Direct Window Object

### 13.12.1 Overview

“Direct window” object is to define a popup window location (position / size) , a bit device and a predefined valid window number . When the content of the bit device is set ON, the window will be popup in the predefined location. The popup window will be closed when the content of the bit device is reset (0).The system will only take action when the content of bit device is changed ( OFF → ON, ON → OFF).

The difference between the “Direct window” and the “Indirect window” is that the direct window object sets the popup window in configuration. When system is in operation, users can use the state of the designated register to control popup or close the window.

### 13.12.2 Configuration

Click the “Direct window” icon on the toolbar and the “New Direct Window Object” dialogue box will appear, fill in each items, press OK button, and a new “Direct Window Object” will be created. See the pictures below.



**New Direct Window Object**

General

Description :

Read address

PLC name : Local HMI

Device type : LB

Address : 0  System tag

Address format : ddddd [range : 0 ~ 11999]

Index register


Attribute

Style : No title bar

Window No. : 35. Window\_035

OK Cancel Help

<b>Read address</b>	Select the <b>[PLC name]</b> <b>[device type]</b> <b>[address]</b> of the bit device that control the window popup .
<b>Attribute</b>	<b>[Style]</b> Refer to the “Indirect Window Object” for related information.
	<b>[Window no.]</b> Set the popup window number.



### 13.12.3 Example

Here is an example to explain how to use the direct window object. The picture below shows the settings of the direct window object. In the example, use [LB10] to call up the window 35.


The configuration panel is divided into two sections:

- Read address:**
  - Device type : LB (dropdown menu)
  - Address : 10 (text input field)
  - System tag (checkbox)
- Attribute:**
  - Style : Not drawing frame (dropdown menu)
  - Window no. : 35. WINDOW\_035 (dropdown menu)

Below the configuration panel, the following text is displayed:

*Toggle Switch*  
*Read address : LB10, Write address : LB10*  
*Mode : "Toggle"*

When the state of LB10 is to ON, the window 35 will be popup; when the state of LB10 is OFF, the window 35 will be closed. See the picture below.



**NOTE:** Do not use this function to open the window when the same window has been opened by function key or indirect window.

## 13.13 Moving Shape Object

### 13.13.1 Overview

Moving Shape object is used to define the object's state and moving distance. The Moving shape object is used to place an object in a window at a location specified by the PLC. The state and the absolute location of the shape in the window depend on the current values of three continuous PLC registers. Typically, the first register controls the state of the object, the second register controls the horizontal position (X), and the third register controls the vertical position (Y).

### 13.13.2 Configuration

Click the "Moving Shape" icon on the toolbar and "New Moving Shape Object" dialogue box will appear, fill in each items, press OK button, and a new "Moving Shape Object" will be created. See the pictures below.



**New Moving Shape Object**

General Shape Label

Description :

PLC name : Local HMI

Read address

Device type : LW

Address : 100  System tag

Address format : ddddd [range : 0 ~ 10255]

Index register

16-bit Unsigned

Attribute

Mode : X axis only

No. of states : 1

Min. X : 0 Max. X : 400

Display ratio

State : 0 Ratio : 1

Limit address

Limit from register

OK Cancel Help


**Read address** Select the **[PLC name] [device type][address]** of the word devices that control the display of object's state and moving distance. The table below shows the address to control object's states and moving distance in each different data format.

Data format	address to control object state	Address to control Moving Distance on the X-axis	Address to control Moving distance on the Y-axis
16-bit BCD	Address	Address + 1	Address + 2
32-bit BCD	Address	Address + 2	Address + 4

16-bit Unsigned	Address	Address + 1	Address + 2
16-bit Signed	Address	Address + 1	Address + 2
32-bit Unsigned	Address	Address + 2	Address + 4
32-bit Signed	Address	Address + 2	Address + 4

For example, if the object's read address is [LW100] and the data format is "16-bit Unsigned", [LW100] is to control the object's state, [LW101] is to control the object's moving distance on the X-axis, and [LW102] is to control the object's moving distance on the Y-axis.

The picture below shows that the object's read address is [LW100] and initial position is (100, 50). Supposed you want the object moved to the position (160, 180) and be displayed in the shape of State 2, the value of [LW100] must be set to 2, [LW101] = 160-100 = 60, [LW102] = 180-50 = 130.



**Attribute**

To select the object's movement mode and range.

**a. X axis only**

The object is only allowed to move along the X-axis. The moving range is defined by [Min. X] and [Max. X].

The screenshot shows a configuration window titled "Attribute". It contains three input fields: "Mode" is a dropdown menu set to "X axis only"; "No. of states" is a dropdown menu set to "8"; "Min. X" is a text input field set to "0"; and "Max. X" is a text input field set to "600".

### b. Y axis only

The object is only allowed to move along the Y-axis. The moving range is defined by [Min. Y] and [Max. Y].

Attribute

Mode : Y axis only

No. of states : 8

Min. Y : 0                      Max. Y : 600

### c. X & Y axis

The object is allowed to move along the X-axis and Y-axis. The moving range in XY direction is defined by [Min. X], [Max. X] and [Min. Y], [Max. Y] respectively.

Attribute

Mode : X & Y axis

No. of states : 8

Min. X : 0                      Max. X : 600

Min. Y : 0                      Max. Y : 300

### d. X axis w/ scaling

The object is for X axis movement with scale. Supposed that the value of the designated register is DATA, the system use the following formula to calculate the moving distance on the X-axis.

X axis move distance =

$$(DATA - [\text{Input low}]) * ([\text{Scaling high} - \text{Scaling low}] / ([\text{Input high}] - [\text{input low}]))$$

Attribute

Mode : X axis w/ scaling

No. of states : 8

Input low : 0                      Input high : 600

Scaling low : 300                      Scaling high : 1000

For example, the object is only allowed to move within 0~600, but the range of the register's value is 300~1000, set [Input low] to 300 and [Input high] to 1000, and set [Scaling low] to 0 and [Scaling high] to 600, and the object will move within

	<p>the range.</p> <p><b>e. Y axis w/ scaling</b> The object is for Y axis movement with scale. and the formula to calculate the moving distance on the Y-axis is the same as the one in “X axis w/ scaling.”</p> <p><b>f. X axis w/ reverse scaling</b> This function is the same as “X axis w/ scaling”, but the moving direction is in reverse.</p> <p><b>g. Y axis w/ reverse scaling</b> This function is the same as “Y axis w/ scaling”, but the moving direction is in reverse.</p>																																			
<b>Display ratio</b>	<p>The size of shape in different states can be set individually as shown in the picture below.</p> <p style="text-align: center;"> <i>Ratio : 1</i>      <i>Ratio : 1.2</i>      <i>Ratio : 1.4</i>      <i>Ratio : 1.6</i>   </p>																																			
<b>Limit address</b>	<p>The object’s moving range can be set not only by [Min. X], [Max. X] and [Min. Y] [Max. Y], but also by the designated registers. Supposed that the object’s moving range is set by the value of the designated register “Address”, then the address of [Min. X], [Max. X] and [Min. Y] [Max. Y] are listed in the following table.</p> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Data format</th> <th>[Min. X] address</th> <th>[Max. X] Address</th> <th>[Min. Y] address</th> <th>[Max. Y] Address</th> </tr> </thead> <tbody> <tr> <td>16-bit BCD</td> <td>Address</td> <td>Address + 1</td> <td>Address + 2</td> <td>Address + 3</td> </tr> <tr> <td>32-bit BCD</td> <td>Address</td> <td>Address + 2</td> <td>Address + 4</td> <td>Address + 6</td> </tr> <tr> <td>16-bit Unsigned</td> <td>Address</td> <td>Address + 1</td> <td>Address + 2</td> <td>Address + 3</td> </tr> <tr> <td>16-bit Signed</td> <td>Address</td> <td>Address + 1</td> <td>Address + 2</td> <td>Address + 3</td> </tr> <tr> <td>32-bit Unsigned</td> <td>Address</td> <td>Address + 2</td> <td>Address + 4</td> <td>Address + 6</td> </tr> <tr> <td>32-bit Signed</td> <td>Address</td> <td>Address + 2</td> <td>Address + 4</td> <td>Address + 6</td> </tr> </tbody> </table>	Data format	[Min. X] address	[Max. X] Address	[Min. Y] address	[Max. Y] Address	16-bit BCD	Address	Address + 1	Address + 2	Address + 3	32-bit BCD	Address	Address + 2	Address + 4	Address + 6	16-bit Unsigned	Address	Address + 1	Address + 2	Address + 3	16-bit Signed	Address	Address + 1	Address + 2	Address + 3	32-bit Unsigned	Address	Address + 2	Address + 4	Address + 6	32-bit Signed	Address	Address + 2	Address + 4	Address + 6
Data format	[Min. X] address	[Max. X] Address	[Min. Y] address	[Max. Y] Address																																
16-bit BCD	Address	Address + 1	Address + 2	Address + 3																																
32-bit BCD	Address	Address + 2	Address + 4	Address + 6																																
16-bit Unsigned	Address	Address + 1	Address + 2	Address + 3																																
16-bit Signed	Address	Address + 1	Address + 2	Address + 3																																
32-bit Unsigned	Address	Address + 2	Address + 4	Address + 6																																
32-bit Signed	Address	Address + 2	Address + 4	Address + 6																																


## 13.14 Animation Object

### 13.14.1 Overview


The Animation object is used to place an object on the screen at a specified location determined by a predefined path and data in the PLC. The state and the absolute location of the shape on the screen depend on current reading value of two continuous PLC registers. Typically, the first register controls the state of the object and the second register controls the position along the predefined path. As the PLC position register changes value. The shape or picture jumps to the next position along the path.

### 13.14.2 Configuration

Click the “Animation” icon on the toolbar, move the mouse to each moving position and click the left button to define all moving positions one by one. When settings of all moving positions are completed, click the right button of the mouse, a new animation object will be created. See the picture below.




To change the object’s attributes, you can double click the left button of the mouse on the object, and the “Animation Object’s Properties” dialogue box, as shown in the picture below, will appear.



<b>Attribute</b>	
<b>[Total no. of State no.]</b>	To set the number of the states for this number.
<b>[Position]</b>	<b>a. Controlled by register</b> When select “Controlled by register”, the designated register controls the object’s state and position.
<b>Read address</b>	If select “Controlled by register” option, it is necessary to set the read address. In the table below, it describes the address that control shape’s state and position in different data format.

Data Format	Address to control object's state	Address to control object's position
16-bit BCD	Address	Address + 1
32-bit BCD	Address	Address + 2
16-bit Unsigned	Address	Address + 1
16-bit Signed	Address	Address + 1
32-bit Unsigned	Address	Address + 2
32-bit Signed	Address	Address + 2

For example, if the designated register is [LW100] and the data format is "16-bit Unsigned", then [LW100] represents object's state, [LW101] represents position. In the picture below, [LW100] = 2, [LW101] = 3, so the object's state is 2 and position is 3.



**[Position]**

**b. Time interval attributes**

If "Based upon time interval" is chosen, the object automatically changes status and display location. "Time interval attributes" is to set the time interval for states and position.

**Time interval attributes**

Position speed :  \* 0.1 second(s)

Image state change :   Backward cycle

Image update time :  \* 0.1 second(s)

**[Speed]**

Position changes speed, the unit is 0.1 second. Supposed that [Speed] is set to 10, the object will change its position every 1 second.

**[Backward]**

If the object has four positions: position 0, position 1, position 2, and position 3, and [Backward] is not selected. In this case when the object moves to the last position (position 3), next position will be back to the initial position 0, and repeat the action over again. The moving path is shown as follows:


position 0 → position 1 → position 2 → position 3 → position 0 → position 1 → position 2...

If [Backward] is selected, when the object moves to the last position (position 3), it will move backwards to the initial position 0, and repeat the moving mode over again. The moving path is shown as follows.


position 0 → position 1 → position 2 → position 3 → position 2 → position 1 → position 0...

**[Image state change]**

State change mode. There are “Position dependant” and “Time-based” options. When “Position dependant” is selected, it means that following the change of position, the state will change too. When “Time-based” is selected, it means that the position will change based on “Position speed” and shape state will change based on “Image update time”



The following dialog shows size setup of animation object. Call up the animation object dialogue box by double clicking.



<b>Shape rectangle size</b>	To set the size of the shape.
<b>Trajectory</b>	To set the position of each point on the moving path.

## 13.15 Bar Graph Object

### 13.15.1 Overview


Bar graph object displays PLC register data as a bar graph in proportion to its value.

### 13.15.2 Configuration

Click the “Bar Graph” icon on the toolbar, the “Bar Graph” dialogue box will be shown up, fill in each items of settings, click OK button, a new “Bar Graph Object” will be created. See the picture below.




The following picture shows the “General” tab of the bar graph object.






Read address


Select the **[PLC name]** **[device type]****[address]** of the word devices that control the bar graph display.

The following picture shows the “Outline” tab of the bar graph object.




<b>Attribute</b>	
<b>[Type]</b>	<p>There are “Normal” and “Offset” for selection. When select “Offset”, there must be a original value for reference. Please refer the illustration below.</p> 
<b>[Direction]</b>	<p>To select the bar graph direction, and there are ”Up”, “Down”, “Right”, and “Left” for selection.</p>

<p><b>[Zero]</b> 、 <b>[Span]</b></p>	<p>The filled bar percentage can be calculated with the following formula:</p> <p>The filled bar percentage = (Register value – Zero) / [Span] – [Zero] * 100%</p> <p>When select “Offset”, if (Register value – Zero) &gt; 0, the bar will fill up from origin setting; if (Register value – Zero) &lt; 0, the bar will fill up but down side from origin setting.</p> <p>For example, Origin =5, Span=10, Zero=0 and use different value in read address, it will display as illustration below.</p> <p>When read address value is 4,</p>  <p>When read address value is 8,</p> 
<p><b>[Bar width ratio(%)]</b></p>	<p>To display the ratio between bar and object width. Below illustration displays two ratio, 50% and 100%.</p>




**Bar color/style** To set the bar's Frame, Background color, Bar style, and Bar color. See the picture below.



**Target Indicator** When the register value meets the following condition, the color of filled area will change to the "Destination color"

$$[\text{Desti. Value}] - [\text{Tolerance}] \leq \text{Register value} \leq [\text{Desti. Value}] + [\text{Tolerance}]$$

See the picture below, in here [Desti. Value] = 5, [Tolerance] = 1, if the register value is equal to or larger than 5-1=4 and equal to or less than 5+1=6, the filled area's color of the bar will change to the "Destination color"



<b>Alarm Indicator</b>	When register's value is larger than [High limit], the color of filled area will change to [High color], when register's value is smaller than [Low limit], the color of filled area will change to [Low color].
<b>Target/Alarm Dynamic Address</b>	<p>When select [Enable], the [Low limit] and [High limit] of “Limitation alarm” and the [Desti. Value] of “Destination” all come from designated register. See the picture below.</p> <div data-bbox="438 533 1385 1765" data-label="Image"> </div> <p>The following table shows the read address of low limit, high limit, and destination. The “Address” means the device address, for example, if the device address is [LW20] and data format is 16-bit,          The Alarm Low limit is LW 20. / The Alarm High limit is LW21</p>

The Target indicator is LW22. / The Zero is LW23 / The Span is LW24.

Data Format	Alarm Low limit	Alarm High limit	Target indicator	Zero	Span
16-bit BCD	Address	Address + 1	Address + 2	Address + 3	Address + 4
32-bit BCD	Address	Address + 2	Address + 4	Address + 6	Address + 8
16-bit Unsigned	Address	Address + 1	Address + 2	Address + 3	Address + 4
16-bit Signed	Address	Address + 1	Address + 2	Address + 3	Address + 4
32-bit Unsigned	Address	Address + 2	Address + 4	Address + 6	Address + 8
32-bit Signed	Address	Address + 2	Address + 4	Address + 6	Address + 8

## 13.16 Meter Display Object

### 13.16.1 Overview


The meter display object can displays the value of word device with meter.

### 13.16.2 Configuration

Click the “Meter Display” icon on the toolbar and the “Meter Display Object’s Properties” dialogue box will appear, fill in each items, press OK button, and a new “Meter Display Object” will be created. See the picture below.




The picture below shows the “General” tab in the “Meter Display Object’s Properties” dialogue box.







### Read address


Select the **[PLC name]** **[device type]****[address]** of the word devices that control the display of meter.





In the above dialogue box, users can set the meter display object's outline. Refer to the picture below for the names of each part of the meter.




<p><b>Degree</b></p>	<p>Set the object's "start degree" and "end degree", the angle range is 0-360 degrees. The following pictures show several results of different settings.</p> <div style="text-align: center;">  <p>[Start degree] = 290, [End degree] = 70</p>  <p>[Start degree] = 45, [End degree] = 240</p>  <p>[Start degree] = 120, [End degree] = 135</p> </div>
----------------------	--

	 <p data-bbox="676 533 1203 568">[Start degree] = 225, [End degree] = 315</p>
--	---


<b>Background</b>	Set the object's background color and profile color.
-------------------	--

<b>[Full circle]</b>	<p data-bbox="402 636 1433 761">When the "Full circle" is selected, the object will display the whole circle, otherwise the object will display the defined degree range. See the picture below.</p> <div data-bbox="715 788 1117 1187">  <p data-bbox="833 1200 992 1236"><i>Full circle</i></p> </div> <div data-bbox="721 1281 1110 1496">  <p data-bbox="804 1509 1024 1545"><i>non-full circle</i></p> </div>
----------------------	---


<b>[Transparent]</b>	<p data-bbox="402 1639 1433 1720">When the "Transparent" is selected, the object will not display the background and profile color. See the picture below.</p> <div data-bbox="730 1747 1098 1953">  <p data-bbox="833 1962 1018 1998"><i>Transparent</i></p> </div>
----------------------	--

<b>Tick marks</b>	To set the tick mark's number and color.
<b>Pointer</b>	To set Pointer's style, length, width, and color.
<b>Pin point</b>	To set pin point's style, radius, and color

The following pictures show the “Limit” tab and the sign of low and high limit set in the “Limit” tab.




<b>Value</b>	<p>To set object's display range. Meter display object will use the value of [Zero] and [Span] and the value of register to calculate the pointer's indication position. For example, supposed that [Zero] = 0, [Span] = 100, when the value of register is 30 and [Start degree] = 0, [End degree] = 360, then the degree indicated by pointer is:</p> $\{(30 - [Zero]) / ([Span] - [Zero])\} * ([End degree] - [Start degree]) =$ $\{(30 - 0) / (100 - 0)\} * (360 - 0) = 108$ <p>Pointer will indicate the position of 108 degrees. See the picture below.</p>
--------------	---



**Range limit**

To set the value of low and high limit, the display color, width of the sign of low, high limit.  
 Below illustration use above setting to display the range mark.




**[Dynamic Limits] / uncheck**

When “Dynamic Limits” is not selected, the low limit and high limit are fixed value, which directly comes from the settings. See the example below, the low limit is 30 and high limit is 60.



**[Dynamic Limits] / check**

When Dynamic Limits is selected, the low limit and high limit are decided by the register. Please refer to the following dialog.




There following table shows the read address of low limit and high limit. The “Address” means the register’s address. If the register is [LW100], the “Address” is 100.

Data format	High limit's read address	Low limit's read address
16-bit BCD	Address	Address + 1
32-bit BCD	Address	Address + 2
16-bit Unsigned	Address	Address + 1
16-bit Signed	Address	Address + 1
32-bit Unsigned	Address	Address + 2
32-bit Signed	Address	Address + 2

## 13.17 Trend Display Object

### 13.17.1 Overview

Trend display object can use the curve to represent the data recorded by data sampling object. The sampling operation is conducted by data sampling objects. The trend display object display the result of sampling. The following picture shows an example of trend display object.



### 13.17.2 Configuration


Click the “Trend Display” icon on the toolbar and the “Trend Display Object’s Properties” dialogue box will appear, fill in each items, press the OK button and a new “Trend Display Object” will be created. See the picture below.



The following picture shows the “General” tab in the “Trend Display Object’s Properties” dialogue box.

<b>[Data Sampling Object index]</b>	To select data sampling object as the source of data. Refer to the “data sampling” section for related information.
<b>[Trend mode]</b>	<p>To select the mode of data source. There are “Real-time” and “History” for selection.</p> <p><b>a. Real-time</b></p> <p>In this mode, it can display the sampling data from the beginning of the MT8000 operation to the present time. If previous data are required, you must select the “History” mode to read the data from historical record.</p>

you can use the “Hold control” object to pause the update of trend display, but it is only pause the update of the trend display, and it will not stop the operation of data sampling object. The picture below shows the “Hold control” setting page. Set the state of the designated register to ON, it will pause the updating of the trend display.



Hold control

Enable

Device type : LB


Address : 0

System tag

Index register

### b. History

In this mode, the data come from the historical record of the designated data sampling object in [Data sampling index]. Data sampling object will use the sampling data which was sorted in according to dates. The system use “History control” to select the historical records that are created by the same data sampling object. The picture below shows the “History control” setting page.



History control

Device type : LW

Address : 200


System tag


Index register

The system sorts the historical records of sampling data by date; the latest file is record 0 (In normal condition it is sampling data today), the second latest file is record 1, and so on.

If the value of designated register in “History control” is n, the trend display object will display data record n.

Here is an example to explain usage of “History control.” In the above picture, the designated register is [LW200], if the sampling data available in the files are pressure\_20061120.dtl, pressure\_20061123.dtl, pressure\_20061127.dtl, and pressure\_20061203.dtl and it is 2006/12/3 today. Based on the value of [LW200], the sampling data files selected by the trend display object is shown as follows:

	<table border="1" data-bbox="504 241 1302 533"> <tr> <td>Value of [LW200]</td> <td>The files of the sampling data from the historical record</td> </tr> <tr> <td>0</td> <td>pressure_20061203.dtl</td> </tr> <tr> <td>1</td> <td>pressure_20061127.dtl</td> </tr> <tr> <td>2</td> <td>pressure_20061123.dtl</td> </tr> <tr> <td>3</td> <td>pressure_20061120.dtl</td> </tr> </table>	Value of [LW200]	The files of the sampling data from the historical record	0	pressure_20061203.dtl	1	pressure_20061127.dtl	2	pressure_20061123.dtl	3	pressure_20061120.dtl
Value of [LW200]	The files of the sampling data from the historical record										
0	pressure_20061203.dtl										
1	pressure_20061127.dtl										
2	pressure_20061123.dtl										
3	pressure_20061120.dtl										
<b>[No.of channels]</b>	<p>This is the number of channel displayed on the trend display. Each channel represents the sampling data from one word device.</p> <p>The max. channel is up to 20 channels.</p>										
<b>[Distance between data samples:] / Pixel</b>	<p><b>[Pixel]</b></p> <div data-bbox="523 788 1347 913" style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;">       Distance between data samples : <input checked="" type="radio"/> Pixel <input type="radio"/> Time        Distance : <input type="text" value="20"/> pixel(s)     </div> <p>Select [Pixel], the [Distance] can be used to set the distance between two sampling points. See the picture below.</p> <div data-bbox="434 1075 1442 1576" style="border: 1px solid #ccc; padding: 5px;">  </div>										
<b>[X axis time range] / Time</b>	<p><b>[Time]</b></p> <div data-bbox="513 1693 1359 1818" style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;">       X axis time range : <input type="radio"/> Pixel <input checked="" type="radio"/> Time        Distance : <input type="text" value="20"/> second(s)     </div> <p>Select [Time], the [Distance] is used to set the X-axis in unit of time elapsed. See the picture below.</p>										



Otherwise, select Time for X axis time range and go to Trend/Grid for enable “Time scale” function. Please refer “Time scale” on the following.

**Watch line**

Watch line


Enable

Device type : LW

Address : 300  System tag

Index register


Using the “Watch line” function, when user touches the trend display object, it will display a “watch line”, and export the sampling data at the position of watch line to the designated word device. You may register a numeric display object to display the result. Please refer to the following pictures




“Watch line” function also can export sampling data of multiple channels, The address registered in “watch line” is the start address and those sampling data will be exported to the word devices starting from “start address” The data format of each channel may be different, the corresponding address of each channel is arranged from the first to the last in sequence Please refer to the following pictures.


[LW300]	Ch. 0 : 16-bit Unsigned	( 1 words)
[LW301]	Ch. 1 : 32-bit Unsigned	( 2 words)
[LW303]	Ch. 2 : 32-bit Unsigned	( 2 words)
[LW305]	Ch. 3 : 16-bit Signed	( 1 words)

The picture below shows the attribute of “trend display”.



<b>Frame</b>	The color of frame.
<b>Background</b>	The color of background.
<b>Show scroll controls</b>	To enable / disable scroll control on the trend display. 
<b>Grid</b>	Set the distance and the color of grid.
<b>Grid/</b>	Enable / disable grid.

<b>[Enable]</b>	<b>[Horiz.]</b> Set the number of horizontal line.
	<p><b>[Verti. interval]</b></p> <p><b>a. Pixel</b></p> <p>Point distances : <input checked="" type="radio"/> Pixel <input type="radio"/> Time</p> <p>When select [pixel] to set the display interval (see note on the above graph and “General” tab), the [Verti. interval] is used to select how many sampling point will be included between two vertical grid line. See the picture below.</p> <p>Verti. interval : <input type="text" value="4"/> point(s)</p> <p><b>b. Time</b></p> <p>When select [Time] to set the time range of display data, the [Verti. interval] is used to select the time range between two vertical grid lines. See the picture below.</p> <p>Verti. interval : <input type="text" value="4"/> second(s)</p> <p>According to these settings, the system will calculate the number of vertical grid line automatically.</p>
	<p><b>[Time Scale]</b> To enable the time scale on the bottom of trend display</p> <p><b>[Format]</b> To select time scale as HH:MM or HH:MM:SS</p> <p><b>[Font]</b> To select font style</p> <p><b>[Size]</b> To select font size. Recommend use font size: 8.</p>



**Channel** Set each sampling line's format and color, and the display data's low limit and high limit.


**Limit / uncheck "Dynamic limits"**

[Zero] · [Span]

[Zero] and [Span] are used to set the low limit and high limit of sampling data, So if the low limit is 50 and high limit is 100 for one sampling line, then [Zero] and [Span] must be set as [50] and [100], so all the sampling data can be displayed in the trend display object.

The data length of the word device for limits is related to the data format of object. In the example below, the low limit and high limit are sourced from [LW0] and the following explains the addresses of the low limit and high limit.

- a. If the format of data displayed is "32-bitBCD", then
  - [LW0] low limit position (32-bit BCD)
  - [LW0 + 2] high limit position (32-bit BCD)
- b. If the format of data displayed is "16-bit unsigned", then
  - [LW0] low limit position (16-bit unsigned)
  - [LW0 + 1] high limit position (16-bit unsigned)
- c. If the format of data displayed is "32-bitfloat", then
  - [LW0] low limit position (32-bit float)
  - [LW0 + 2] high limit position (32-bit float)

	
<p><b>Limit / check</b> <b>“Dynamic limits”</b></p>	<p>When Dynamic Limits is selected, the low limit and high limit are derived from the designated word device. An extended function is zoom in and zoom out function. Please refer 17.3 Example.</p> 
<p><b>Time / Data</b></p>	<p>The time of latest sampling data will be marked on the top left corner of the object. It is used to set the time display format and color.</p>


### 13.17.3 Example

For zoom in / out the trend graph, user has to check the Limit/Dynamic limits as picture below.




For example, the LW0 and LW1 are to control low limit and high limit, you may change the value of LW1 to zoom in / out.


This following picture is in original size. The range of trend is between 0~30. The arrow on the right side are set word (LW1, increment (JOG+) and LW1, decrement (JOG-)) for control the zoom in and zoom out function.



Decrease LW1's value to exhibit zoom in function as shown below:  
The value of LW1 decreased to 11.



Increase LW1's value to exhibit zoom out function as shown below:  
The value of LW1 increased to 41.



## 13.18 History Data Display

### 13.18.1 Overview


“History Data Display” object display data stored by data sampling object. It displays history data in numeric format. Please note that the history data display will not refresh automatically, it only retrieve the data from the designated record and display at the time window popup. If the content of the designated record is updated, the history data display will not change accordingly.

No.	Time	Date	Ch.0	Ch.1	Ch.2
3577	21:52	16/09/07	0	0	0
3576	21:52	16/09/07	0	0	0
3575	21:52	16/09/07	0	0	0
3574	21:52	16/09/07	0	0	0
3573	21:52	16/09/07	0	0	0
3572	21:52	16/09/07	0	0	0
3571	21:52	16/09/07	0	0	0
3570	21:52	16/09/07	0	0	0
3569	21:52	16/09/07	0	0	0
3568	21:52	16/09/07	0	0	0

### 13.18.2 Configuration

Click the “History Data Display” icon on the toolbar, the “History Data Display” dialogue box show up on the screen. Fill in each items and click OK button, a new object will be created. See the pictures below.





<b>[Data Sampling object index]</b>	Select the corresponding “Data sampling object” where the history data comes from. .
<b>Grid</b>	Set grid enable or disable.

No.	Time	Date	Ch.0	Ch.1	Ch.2
3582	21:52	16/09/07	2	2	0
3581	21:52	16/09/07	2	2	0
3580	21:52	16/09/07	2	2	0
3579	21:52	16/09/07	2	2	0
3578	21:52	16/09/07	2	2	0
3577	21:52	16/09/07	0	0	0
3576	21:52	16/09/07	0	0	0
3575	21:52	16/09/07	0	0	0
3574	21:52	16/09/07	0	0	0
3573	21:52	16/09/07	0	0	0

**Grid**

**[Color]**  
Set color of grid.

**[Column interval]**  
Set space of column.

No.	Time	Date	Ch.0	Ch.1	Ch.2
3667	21:57	16/09/07	1	0	0
3666	21:57	16/09/07	1	0	0
3665	21:57	16/09/07	1	0	0
3664	21:57	16/09/07	1	0	0
3663	21:57	16/09/07	1	0	0
3662	21:57	16/09/07	1	0	0
3661	21:57	16/09/07	1	0	0
3660	21:56	16/09/07	0	0	0
3659	21:56	16/09/07	0	0	0
3658	21:56	16/09/07	0	0	0

No.	Time	Date
3667	21:57	16/09/07
3666	21:57	16/09/07
3665	21:57	16/09/07
3664	21:57	16/09/07
3663	21:57	16/09/07
3662	21:57	16/09/07
3661	21:57	16/09/07
3660	21:56	16/09/07
3659	21:56	16/09/07
3658	21:56	16/09/07

**Profile color**

Set color of frame and background. If it is set as transparent, the frame and background will be ignored.

No.	Time	Date	Ch.0	Ch.1	Ch.2
3982	22:02	16/09/07	0	0	0
3981	22:02	16/09/07	0	0	0
3980	22:02	16/09/07	0	0	0
3979	22:02	16/09/07	0	0	0
3978	22:02	16/09/07	0	0	0
3977	22:02	16/09/07	0	0	0
3976	22:02	16/09/07	0	0	0
3975	22:02	16/09/07	0	0	0
3974	22:02	16/09/07	0	0	0
3973	22:02	16/09/07	0	0	0

**Time and Date**

Enable or disable the time and date of data sampling and format.

**[Time ascending]**  
“Time ascending” means to put the earlier data in the top and the latest data in the bottom.

No.	Time	Date	Ch.0	Ch.1	C ▲
1	00:24:27	16/09/07	2	2	
2	00:24:28	16/09/07	4	4	
3	00:24:29	16/09/07	7	6	
4	00:24:30	16/09/07	9	8	
5	00:24:31	16/09/07	6	4	
6	00:24:32	16/09/07	4	2	
7	00:24:33	16/09/07	1	4	
8	00:24:34	16/09/07	3	6	
9	00:24:35	16/09/07	6	6	
10	00:24:36	16/09/07	8	4	


**[Time descending]**

“Time descending” means to put the latest data in the top and the earlier data in the bottom.

No.	Time	Date	Ch.0	Ch.1	C ▲
4787	22:24:15	16/09/07	2	2	
4786	22:24:00	16/09/07	3	2	
4785	22:23:59	16/09/07	3	2	
4784	22:23:58	16/09/07	3	2	
4783	22:23:57	16/09/07	3	2	
4782	22:23:56	16/09/07	3	2	
4781	22:23:55	16/09/07	3	2	
4780	22:23:54	16/09/07	3	2	
4779	22:23:53	16/09/07	3	2	
4778	22:23:52	16/09/07	3	2	

**History Control**

The history files are named with date code. The history control is used to select the designated history data files for display. In case the value of history control is 0, the latest file is selected. If it is 1, the second latest file is selected, and so on.



Each history data display object can display up to 20 channels. You can select the channels which you want to watch on the screen.

In the example below, there are four channels in the data sampling object, ch 0 and ch. 3 are selected for display only. The data format of each channel is decided by the related data sampling objects.

No.	Time	Date	Ch.0	Ch.3
5272	22:43:09	16/09/07	4	1
5271	22:43:08	16/09/07	2	0
5270	22:33:42	16/09/07	0	0
5269	22:33:41	16/09/07	0	0
5268	22:33:40	16/09/07	0	0
5267	22:33:39	16/09/07	0	0
5266	22:33:38	16/09/07	0	0
5265	22:33:37	16/09/07	0	0
5264	22:33:36	16/09/07	0	0
5263	22:33:35	16/09/07	0	0

**New History Data Display Object**

General | Data Format | **Title** | Shape

Use title


Title background

Transparent

Title name	Title	Label library	Label tag
Sequence no.	No.	None	
Time	Time	None	
Date	Date	None	
Channel 0	ch.0	None	
Channel 1	ch.1	None	
Channel 2	ch.2	None	
Channel 3	ch.3	None	
Channel 4	ch.4	None	
Channel 5	ch.5	None	
Channel 6	ch.6	None	
Channel 7	ch.7	None	
Channel 8	ch.8	None	
Channel 9	ch.9	None	
Channel 10	ch.10	None	
Channel 11	ch.11	None	
Channel 12	ch.12	None	
Channel 13	ch.13	None	
Channel 14	ch.14	None	

Setting ...

OK Cancel Help

Title	<p><b>[Use title]</b> To enable or disable title.</p> 												
Title background	<p><b>[Transparent]</b> To enable or disable transparent.</p>												
	<p><b>[Background color]</b> Set the background color of title.</p>												
Setting	<p>This dialogue window defines the title.</p> <table border="1" data-bbox="655 925 1171 1048"> <thead> <tr> <th>No.</th> <th>Time</th> <th>Date</th> <th>Ch.0</th> </tr> </thead> <tbody> <tr> <td>5272</td> <td>22:43:09</td> <td>16/09/07</td> <td>4</td> </tr> <tr> <td>5271</td> <td>22:43:08</td> <td>16/09/07</td> <td>2</td> </tr> </tbody> </table> <p>You can use label tag library for title with multi-language. Go to [setting] and select one from label library.</p> 	No.	Time	Date	Ch.0	5272	22:43:09	16/09/07	4	5271	22:43:08	16/09/07	2
No.	Time	Date	Ch.0										
5272	22:43:09	16/09/07	4										
5271	22:43:08	16/09/07	2										



### 13.18.3 Note

If you have run the off-line simulation and the sampling data is saved in the record, then you want to change the format of sampling data, be sure to delete previous data record in C:\EB8000\datalog to avoid the system misinterpret the old data record.

## 13.19 Data Block Display

### 13.19.1 Overview

Data Block is a combination of several word devices with continuous address, for example LW12, LW13, LW14, LW15 and so on. Use Data Block Display object to display multiple data blocks in trend curve, for example, it can display two data blocks LW12~LW15 and RW12~RW15 in trend curve simultaneously. It is very useful to observe and compare the difference of trend curves.




Snapshot of Data Block Display

### 13.19.2 Configuration

**[New object]**


Click the “Data Block Display” icon  , “Data Block Display’s properties” dialogue box appears as follows:



<b>[General]</b>	<p><b>No. of channel</b> Set the no of channel for this object. Each channel represents one data block. The max. no. of channel is 12.</p>
------------------	--

	No. of channel : <input type="text" value="2"/> 
<b>Cursor Line</b>	<p>Using the “Cursor line” function, when user touches the Data Block display object, it will display a cursor line on the data block display object, and transfer the position of cursor and the data at the cursor position to the designated registers.</p> <p>Please refer 19.3 On line operation for further information.</p>
<b>Channel</b>	Select each channel and set the attributes.
<b>Control address</b>	<p><b>[PLC name]</b> Select the PLC where the target data block located.</p> <p><b>[Device type]</b> Select the device type where the target data block located</p> <p><b>[Control word address]</b> “Control word” is used to control and clear trend curve display.  0=No action (default)  1= Plot trend curve  2=Clear trend curve  3=Redraw trend curve</p> <p>After executing the operation above, the system will reset the control word to zero.</p> <p><b>[No. of data address]</b> “No. of data address” is default as “Control word address +1”.  “No. of data” is to store the number of word device in each data block, i.e. the number of data to plot in trend curve. The maximum value is 1024.</p> <p><b>[Data storage start address]</b> If “offset to start address” is disabled, the “Data storage start address” is default as “Control word address + 2”.</p> <p><b>[Offset value storage address]</b> If “offset to start address” is enabled, the “Data storage start address” is “[Offset value storage] + Control word address”, the “Offset value storage address” is default as “Control word address” + 2.</p> <p><b>[Format]</b> If you select 16-bit data format, the address of each data will be start address,</p>

	<p>start address + 1, start address + 2 and so on.</p> <p>If you select 32-bit data format, the address of each data will be start address, start address + 2, start address + 4 and so on.</p>
<b>Limit</b>	Set the minimum and maximum limit of trend curve, the trend curve is limited by the minimum and maximum limit.



<b>Data Sample</b>	Set the data samples, samples to scroll, frame and color of background.
--------------------	---

Data samples : 50  Samples to scroll : 10 


Enable scroll swieth

Profile color


Transperent



Frame :  Background : 

Enable background



Disable background




<p><b>Grid</b></p>	<p>Enable Grid</p>  <p>Disable Grid</p> 
<p><b>Channel</b></p>	<p>Set the color and width of each trend curve.</p> 

### 13.19.3 On line operation

#### 13.19.3.1 How to shows a trend curve

- Write the number of data to [No. of data address], i.e. “word control address+1”
- Have the content of data block ready for display.  
**NOTE:** data block start from “word control address + 2”.
- Write “1” to [Control word address], the previous trend curve remains and the new content in data block will be plot on the screen.
- The system will write “0” to [Control word address] after the trend curve displayed.





---

**NOTE:** During the period between c and d, do not change the content of [Control], [No. of Data] and [Data], it might cause error for trend curve plot.

---

#### 13.19.3.2 How to clear a trend curve

- Write “2” to [Control word address], all the trend curves will be cleared.
- The system will write “0” to [Control word address] after the trend curve is cleared.




### 13.19.3.3 How to clear the previous trend curve and display new one

- Write the number of data to [No. of data address], i.e. “word control address+1”
- Have the content of data block ready for display.

Note: data block start from “word control address + 2”.


- Write “3” to [Control word address], the previous trend curves will be cleared and the new content in data block will be plot on the screen.
- The system will write “0” to [Control word address] after the trend curve displayed.



### 13.19.3.4 How to use offset mode

If “offset to start address” is selected, the “Data storage start address” will be calculated from “control word address + [Offset value storage address]”. “Offset value storage address” is “control word address + 2”.

In the following example, the content of “Offset value storage address” is “m”, therefore the data block is started from the address “control word address + m”.



**NOTE** If the control register is 32 bits device, only bit 0-15 will be used as control purpose, bit 16-31 will be ignored. (as illustration below)


**32 bit device**

	31	16	15	0
+0	0	Control		
+1	0	No. of Data		
+2	0	Offset		


If you do not use “offset to start address”, the system will continuously read [Control] and [No. of Data]. At the time [Control] is changed to non-zero, the system will then read the data block. If you use “offset to start address”, the system will continuously read [Control], [No. of Data] and [Offset].

It is recommended to use “offset to start address” for data block display with multiple channels and the same device type. You can register [Control], [No. of Data] and [Offset] in continuous address for each channel. The system will read the control words of all the channels in one read command and it shall speed up the response time.

Please refer to the following picture. The control words of channel 1 is located from address 0, the control words of channel 2 is located from address 3, there are continuous address and the system will read all the control words in one read command.




### 13.19.3.5 How to use watch (Cursor Line) feature



You may use the “Watch” function to check the value of any point in trend curve. When operator touches the data block object, it will display a “Cursor line”, the system will write the index and value of that data in cursor line to the designated address. The user shall register NI objects with the designated address. The operator shall be able to observe the numeric value in across with the cursor line.


In the following example, the data block display contains two data blocks. The data format of channel 1 is 16 bit BCD and that of channel 2 is 32 bit unsigned. The cursor is positioned in data index 3 which is corresponding to the fourth data in data block. The system writes “data index” and the content of watched data to the watch address as shown in the following picture.




**NOTE** 1. [Data Index] is a 16 bit unsigned integer; when the designated register of cursor line is 32 bit device, it will be stored in the bit 0-15.

2. The watch function can only inspect current value in the data block. If there are multiple trend curves of the same channel on the screen, the data of previous trend curves is not exist, only the latest value is available for watch.

3. If the trend curve is cleared, when position the cursor line, the “0” will be displayed as shown below.



4. If there are only three data in Channel 1, when position the cursor in Data 4, the “0” will be displayed as shown below.



### 13.19.3.6 Limitation

The maximum number of channels is 12.

1. The system can draw up to 32 trend curves.
2. The system can draw up to 1024 points for each channel.

## 13.20 XY Plot

### 13.20.1 Overview

XY Plot object displays two dimension data. Each data contains X and Y values and each curve is composed of a stream of XY data. The maximum number of trend curves in a XY plot is 16 channels.

### 13.20.2 Configuration

#### [New object]

Click the “XY plot” icon , and “XY Plot Object” dialog box appears.

**New XY Plot Object**

General | Display Area | Shape

Description :

Direction :  No. of channels :

**Control Address**

PLC name :

Device type :

Control address :

Address format : ddddd [range : 0 ~ 10255]

No. of data address :

Index register

Channel :

**Read address**

PLC name :

Separated address for X and Y data

X axis data :

Y axis data :

**Limits**

Dynamic limits


**X axis**

Low :  High :

**Y axis**

Low :  High :

<b>General</b>	<p>a. Direction: There are four selections, right, left, up or down.</p> <p style="text-align: center;">Right: <span style="margin-left: 200px;">Left:</span></p>
----------------	---



b. No. of channel.  
 Set the no. of channels of the XY plot. Each channel may conduct the draw operation alone.

**Control address**

**[PLC name]**  
 Select the PLC where the control address coming from

**[Device type]**  
 Select the device type where the control address coming from.

**[Control address]**  
 “Control address” is used to control the display of XY curve for each channel.

1= Plot XY curve  
 Write ”1” to control address, the system will plot the XY curve, the previous XY curve if exists would not be clear. The system will reset the control address after operation complete.

2= Clear XY trend curve  
 Write ”2” to control address, the system will clear all the previous XY curves and reset the control address after operation complete.


3= Refresh XY trend curve  
 Write ”3” to control address, the system will clear the previous XY curve and plot the new XY curve and reset the control address after operation complete.

**[No. of data address]**  
 This address store the number of XY data. Each channel can have up to 1023 XY data.

**Channel** Setting the channels detail for graph display.

**Read Address** **[PLC name]**  
 Select the PLC where the control address coming from.

**[PLC address]**



Click settings button, a pop-up window appears as above, you can set the device type, data format and address, the usage of each address is listed on the right side.

Address :	100	X low limit	] Setting X low limit and X high limit
	100 + 1	X high limit	
	100 + 2	Y low limit	] Setting Y low limit and Y high limit
	100 + 3	Y high limit	
	100 + 4	X data 0	] XY plot point data
	100 + 5	Y data 1	

If you check “Separated address for X and Y data”, the pop-up window

appears as below. It allows you to set different address for X and Y axis respectively.

Read address

PLC name : Local HMI

Separated address for X and Y data

X axis data : LW-100      Settings ...

Y axis data : LW-200      Settings ...

Channel 0

PLC name : Local HMI

Read address

Device type : LW

Index register

X low and high limit      16-bit Signed

Address : 100	X low limit
100 + 1	X high limit
100 + 2	X data 0
100 + 3	X data 1
100 + 4	X data 2
100 + 5	X data 3

OK      Cancel

Channel 0

PLC name : Local HMI

Read address

Device type : LW

Index register


Y low and high limit      16-bit Signed

Address : 200	Y low limit
200 + 1	Y high limit
200 + 2	Y data 0
200 + 3	Y data 1
200 + 4	Y data 2
200 + 5	Y data 3

OK      Cancel

## Limits

The above settings are based on dynamic limits, you can also have dynamic limits disable and set the fix high and low limits.



Limits

Dynamic limits

X axis

Low : 0 High : 32767


Y axis

Low : 0 High : 32767

The high and low limits is used as scale to calculate the percentage of X and Y axis. i.e. X or Y % = ( X or Y reading value – low limit ) / ( high limit – low limit )


Based on your settings, the memory allocation for limit and XY data will be listed on the pop-up window.

The following setting is for 16-bit signed data format and dynamic limits.



Address	Label	Offset
100	X low limit	n+0
100 + 1	X high limit	n+1
100 + 2	Y low limit	n+2
100 + 3	Y high limit	n+3
100 + 4	X data 0	n+4
100 + 5	Y data 1	n+5

The following setting is for 32-bit float data format and dynamic limits.



Address	Label	Offset
100	X low limit	n+0,n+1
100 + 2	X high limit	n+2,n+3
100 + 4	Y low limit	n+4,n+5
100 + 6	Y high limit	n+6,n+7
100 + 8	X data 0	n+8,n+9
100 + 10	Y data 1	n+10,n+11

**NOTE**

There are four different type of selection to designate memory location for high/low limits and XY data. Please refer to the following settings.


<input checked="" type="checkbox"/> Separated address for X and Y data			
<input type="checkbox"/> Dynamic limits		<input checked="" type="checkbox"/> Dynamic limits	
X	Y	X	Y
Data 0	Data 0	Min	Min
Data 1	Data 1	Max	Max
Data 2	Data 2	Data 0	Data 0
Data 3	Data 3	Data 1	Data 1
⋮	⋮	Data 2	Data 2
⋮	⋮	⋮	⋮


<input type="checkbox"/> Separated address for X and Y data					
<input type="checkbox"/> Dynamic limits		<input checked="" type="checkbox"/> Dynamic limits			
X	+	Y	X	+	Y
X Data 0		Y Data 0	X Min		Y Min
X Data 1		Y Data 1	X Max		Y Max
X Data 2		Y Data 2	XData 0		YData 0
X Data 3		Y Data 3	XData 1		YData 1
⋮		⋮	XData 2		YData 2
⋮		⋮	⋮		⋮

If dynamic limit is checked, you may change the high and low limits to realize zoom in and zoom out function. (Please refer trend display object's dynamic limit.)


In the following example, the dynamic limit is selected, where XL=X low limit, XH=X high limit, YL=Y low limit, YH=Y high limit, and XY, XY1, XY2 are three XY data. Now we change the high limit of X and Y respectively and you may observe the effect of zoom in and zoom out.




1. Change Y high limit to 25 for zoom in effect.




2. Change Y high limit to 100 for zoom out effect.



[Display Area]



<p><b>Profile color</b></p>	<p><b>Enable Transparent:</b> It will not display the background color.  <b>Disable Transparent:</b> It will display the background color</p>
<p><b>Curve</b></p>	<p>Set the attribute of XY curve (color and width) for each channel.</p> 


**Maker**

There are four different type of XY plot, i.e. Line, Point, X-axis projection and Y-axis projection, check one of them.


For Line and Point selection, set appropriate point width (unit in pixels).



Line & Point:




X-axis projection is shown as the following:

**Remarks:**


Please refer to the figure below, there is a curve containing 7 points from P0 to P6. The system carries out X-axis projection with following steps:

- Automatically calculate two projected points in X-axis –  $(X_0, 0)$  and  $(X_6, 0)$ .
- Link all these points in the order of  $(X_0, 0)$ , P0, P1... P6,  $(X_6, 0)$  and returns to  $(X_0, 0)$  at last.
- Fill out all enclosed areas formed.

X-axis projection :



Similarly for Y-axis projection:



Reference line

In order to make the XY plot more readable, you can configure up to 4 horizontal reference lines on the graph. Fill in high, low limit and Y axis coordinate for each reference line.

The screenshot shows the 'Reference line' configuration window. At the top, there is a checkbox labeled 'Limit from PLC' which is unchecked. Below this is a 'Limit' section containing two input fields: 'Low limit' with the value '0' and 'High limit' with the value '100'. At the bottom, there are four rows, each representing a reference line. Each row has a checked checkbox, a label (e.g., 'Reference line 1'), a numerical input field (e.g., '20'), a color selection bar (e.g., green), and a dropdown arrow.

Reference line	Y-axis coordinate	Color
Reference line 1	20	Green
Reference line 2	40	Blue
Reference line 3	60	Orange
Reference line 4	80	Red

You may also use PLC address to define high and low limit.

The screenshot shows the 'Reference line' configuration window. At the top, there is a checked checkbox labeled 'Limit from PLC'. Below this is a 'Limit' section containing several fields: 'PLC name' with the value 'Local HMI', 'Device type' with the value 'LW', and 'Address' with the value '20'. There is also an unchecked checkbox labeled 'Index register' and a dropdown menu set to '16-bit Signed'. At the bottom, there are four rows, each representing a reference line. Each row has a checked checkbox, a label (e.g., 'Reference line 1'), a numerical input field (e.g., '20'), a color selection bar (e.g., green), and a dropdown arrow.

Reference line	Y-axis coordinate	Color
Reference line 1	20	Green
Reference line 2	40	Blue
Reference line 3	60	Orange
Reference line 4	80	Red

## 13.21 Alarm Bar and Alarm Display Objects

### 13.21.1 Overview


Alarm bar and alarm display object are used to display alarm messages. Alarm messages are those events registered in the “event log” and meet trigger conditions. Alarm bar and alarm display objects display these alarms in order of priority and triggering time.

Alarm bar object scroll all alarm messages in one line, alarm display object displays alarm messages in multi-line and each line represents one alarm message. The following pictures show that the alarm message are displayed in alarm display and alarm bar objects. Refer to the “Event Log” chapter for related information.



**! (When LW 1 >= 10) 13:21:06 Event 0 (when LW0**

**Alarm bar object**




<b>13/12/06</b>	<b>13:21:38</b>	<b>Event 2 (when LB10 = ON)</b>
<b>13/12/06</b>	<b>13:21:38</b>	<b>Event 3 (when LB11 = ON)</b>
<b>13/12/06</b>	<b>13:21:38</b>	<b>Event 0 (when LW0 == 100)</b>
<b>13/12/06</b>	<b>13:21:38</b>	<b>Event 1 (When LW 1 &gt;= 10)</b>

**Alarm display object**

### 13.21.2 Configuration

Click the “Alarm bar” icon on the toolbar, the “Alarm bar” dialogue box appear; similiarly, click the “Alarm display” icon on the toolbar, the “Alarm display” dialogue box appear, fill in the setting in the “General tab” and press the OK button, a new object will be created. See the pictures below.



**New Alarm Bar Object** [Close]

Alarm | Shape | Font

Include categories : 0 thru 0 {see Alarm (Event) Log object}

Scroll speed : Speed 6 [v]

Color \_\_\_\_\_

Transparent

Frame : [Color Picker] Background : [Color Picker]

Format \_\_\_\_\_

Sort

Time ascending  Time descending

Time


Event trigger time

Date


Event trigger date

[OK] [Cancel] [Help]

<b>Include categories</b>	<p>Select category of events that belongs to the alarm display or alarm bar object. ( category of an event is set in event log)</p> <p>For example, if the category of an alarm bar is set to 2~4, it will display all the alarm messages with “category” equal to 2, 3, or 4.</p>
---------------------------	--

	Please refer to “Category” statement in “Event Log” chapter.
<b>Scroll Speed</b>	Set the scroll speed of alarm bar.
<b>Color</b>	Set frame and background color of alarm bar.
<b>Format</b>	<p><b>a. Sort</b></p> <p>Set the order to display alarm message.</p> <p><b>Time ascending</b></p> <p>Put Latest trigger alarm message in the bottom.</p> <p><b>Time descending</b></p> <p>Put Latest trigger alarm message in the top.</p>
	<p><b>b. Time</b></p> <p><b>Event trigger time</b></p> <p>Display the time tag with alarm message. There are three formats of time tag.</p> <p>1. HH:MM:SS / 2. HH:MM / 3. DD:HH:MM</p> 
	<p><b>c. Date</b></p> <p><b>Event trigger date</b></p> <p>Display the date tag with alarm message. There are four formats of date tag.</p> <p>1. MM/DD/YY / 2. DD/MM/YY / 3. DD.MM.YY / 4. YY/MM/DD</p> 

Set font and color of alarm message in the “Font” tab. See the picture below.



## 13.22 Event Display Object

### 13.22.1 Overview

Event display object displays active and finished events. The events are registered in “event log” object. The active events are the events which are in trigger condition, or have been triggered and unacknowledged.


The event display object displays those active events in the order of trigger time. See the picture below. Event display object can also display the time of the events been triggered, acknowledged and recovered.




18	01/20/09	15:35:22		Event 1 (LB10 = ON)
17	01/20/09	15:35:22		Event 0 (LB0=ON)
16	01/20/09	15:35:20	15:35:23	Event 3 (LW20 <= 5)
15	01/20/09	15:35:19		Event 0 (LB0=ON)
14	01/20/09	15:35:18		Event 1 (LB10 = ON)
13	01/20/09	15:35:15	15:35:16	Event 2

### 13.22.2 Configuration

Click the “Event Display” icon on the toolbar, the “Event Display” dialogue box appear, set each items in the “General” tab, press OK button and a new “Event Display Object” will be created. See the picture below.



<b>Mode</b>	Select the event source format, there are “Real-time” and “History” for selection.
	<p><b>a. Real-time</b></p> <p>Mode : </p> <p><b>Write address</b></p> <p>When an event is acknowledged (refer to the following illustrations for detail</p>


information), the data in “write value” will be exported to the designated register. The “write value” is set in “event log” object, as shown in the picture below. Refer to the “Event Log” chapter for related information.



Write value for event display

Write value : 200

## b. History




Mode : History

- Real-time
- History

In this mode, it can display event log from history record. The system save the event history in daily basis, the event history of each date is saved in a separate file with date tag. The “History control” is used to select one history record file.

The picture below shows the “History control” setting, which designates a word device for “History control”.



History control

Device type : LW

Address : 100

System tag

Index register

16-bit Unsigned

The system selects history record by an index. The index 0 refer to the latest history record (normally it is history record today), the index 1 refer to the second latest history record, and so on.


The current value in “History control” register is used as the index to select corresponding history record.

Here is an example to explain how to use the “History control”. The “history control” register is [LW100], supposed that the history records saved in system are


EL\_20061120.evt,  
EL\_20061123.evt,  
EL\_20061127.evt  
EL\_20061203.evt,

Where the 2006xxxx is the date that system saved history record. The following table shows the event display object displays the corresponding historical record in according to the value of [LW100].

Value of [LW100]	Corresponding Historical Record
0	EL_20061203.evt
1	EL_20061127. evt
2	EL_20061123. evt
3	EL_20061120. evt



<p><b>Include categories</b></p>	<p>Select category of events that belongs to the event display object. ( category of an event is set in event log)</p> <p>For example, if the category of an event log display is set to 2~4, it will display all the active event messages with “category” equal to 2, 3, or 4.</p> <p>Please refer to “Category” statement in “Event Log” chapter.</p>
----------------------------------	--



**Acknowledge style**

Sequence no.	Time	Event Description
6	13:12:19	Event 1 (When LW 1 >= 10)
5	13:12:18	Event 2 (when LB10 = ON)
4	13:12:18	Event 3 (when LB11 = ON)
3	13:12:15	Event 2 (when LB10 = ON)
2	13:12:14	Event 1 (When LW 1 >= 10)
1	13:12:14	Event 0 (when LWO == 100)

You may select “Click” or “Double click” to acknowledge a new event. When a new event comes up, the operator can “Click” or “Double click” to acknowledge the new event, the system will change the text color of that event and export the “write value” registered with the event to the designated register.

Take use of this feature, the user can register a popup window and put the warning message in the window, then configure an indirect window object, when the event is acknowledged, the “write value” is written into the read address of the indirect window and call up the popup window.

**Max. event no.** The maximum number of events to be displayed in the event display object. When the number of events is larger than the maximum, the oldest event will be removed from the event display object.

**Color** To set the color of events in different states

- a. Acknowledge
- b. Return to normal
- c. Select box – The system draw a highlight box around the latest acknowledged event.

**Format** **Sequence no.**  
Check to add sequence no with event message.


<b>Sort</b>	<p>Set the order to display alarm message.</p> <p><b>Time ascending</b> Put Latest trigger alarm message in the bottom.</p> <p><b>Time descending</b> Put Latest trigger alarm message in the top..</p>																							
<b>Time</b>	<p><b>Event trigger time</b> Display the trigger time with event message.</p> <p><b>Acknowledge time</b> Display the “acknowledge” time with event message.</p> <p><b>Return to normal time</b> Display the “return to normal” time with event message.</p>																							
<b>Date</b>	<p><b>Event trigger date</b> Display the event trigger date with event message..</p> <div style="border: 2px solid purple; padding: 5px; margin-top: 10px;"> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><i>trigger date</i></th> <th style="text-align: left;"><i>trigger time</i></th> <th style="text-align: left;"><i>notification time</i></th> <th style="text-align: left;"><i>return to normal time</i></th> <th style="text-align: left;"></th> </tr> </thead> <tbody> <tr> <td><b>0</b></td> <td><b>12/14/06</b></td> <td><b>15:26:21</b></td> <td><b>15:26:31</b></td> <td><b>15:26:36</b></td> <td><b>Event 0 (when LV</b></td> </tr> <tr> <td><b>1</b></td> <td><b>12/14/06</b></td> <td><b>15:26:47</b></td> <td><b>15:26:50</b></td> <td></td> <td><b>Event 1 (When LI</b></td> </tr> <tr> <td><b>2</b></td> <td><b>12/14/06</b></td> <td><b>15:26:48</b></td> <td></td> <td></td> <td><b>Event 2 (when LE</b></td> </tr> </tbody> </table> </div>	<i>trigger date</i>	<i>trigger time</i>	<i>notification time</i>	<i>return to normal time</i>		<b>0</b>	<b>12/14/06</b>	<b>15:26:21</b>	<b>15:26:31</b>	<b>15:26:36</b>	<b>Event 0 (when LV</b>	<b>1</b>	<b>12/14/06</b>	<b>15:26:47</b>	<b>15:26:50</b>		<b>Event 1 (When LI</b>	<b>2</b>	<b>12/14/06</b>	<b>15:26:48</b>			<b>Event 2 (when LE</b>
<i>trigger date</i>	<i>trigger time</i>	<i>notification time</i>	<i>return to normal time</i>																					
<b>0</b>	<b>12/14/06</b>	<b>15:26:21</b>	<b>15:26:31</b>	<b>15:26:36</b>	<b>Event 0 (when LV</b>																			
<b>1</b>	<b>12/14/06</b>	<b>15:26:47</b>	<b>15:26:50</b>		<b>Event 1 (When LI</b>																			
<b>2</b>	<b>12/14/06</b>	<b>15:26:48</b>			<b>Event 2 (when LE</b>																			

The font tab sets the font size and italic attribute. The font of event message is set with the event log object.

## 13.23 Data Transfer (Trigger-based) Object

### 13.23.1 Overview

Data Transfer (Trigger-based) object can transfer the value from the source register to the destination register. The data transfer operation can be activated by pressing the object or setting a trigger bit.



### 13.23.2 Configuration

Click “Data Transfer (Trigger-based) object” icon on the toolbar, “Data Transfer (Trigger-based) object” dialogue box show up, set each item in the “General” tab, press OK button, a new Trigger Data Transfer object will be created. See the picture below.

**New Data Transfer (Trigger-based) Object**

General Security Shape Label

Description :

**Source address**

PLC name : Local HMI

Device type : LW

Address : 0  System tag

Address format : ddddd [range : 0 ~ 10255]

Index register

No. of words : 1

**Destination address**

PLC name : Local HMI

Device type : LW

Address : 100  System tag

Address format : ddddd [range : 0 ~ 10255]

Index register

**Attribute**

Mode : External trigger  Touch trigger  External trigger  Trigger mode : ON->OFF

**Trigger address**

PLC name : Local HMI

Device type : LB

Address : 0  System tag

Address format : ddddd [range : 0 ~ 11999]

Index register

OK Cancel Help

<b>Source address</b>	Set source address of data transfer.
	<b>No. of words</b> The number of words to be transferred from source to destination.
<b>Destination address</b>	Destination address for data transfer.
<b>Attribute</b>	Set the trig mode of data transfer.

**[Mode]**

**a. Touch trigger mode**

Press the object to activate data transfer operation.

**b. External trigger**

Register a bit device to trigger the data transfer operation.

**[ON → OFF]**

Bit device change from ON to OFF to activate data transfer operation.

**[OFF → ON]**

Bit device change from OFF to ON to activate data transfer operation.

**[ON ↔ OFF]**

Bit device change states to activate data transfer operation.

Trigger address

PLC name :	Local HMI	▼
Device type :	LB	▼
Address :	0	<input type="checkbox"/> System tag
		<input type="checkbox"/> Index register

## 13.24 Backup


### 13.24.1 Overview

The backup function can store the recipe data (RW, RW\_A), event log and sampling data to USB device. The [LB-9039] represents the backup status, when backup operation is in progress, the status of [LB-9039] is ON.




### 13.24.2 Configuration

Click “Backup Object” icon on the toolbar, the “Backup Object” dialogue box show up. See the pictures below.





<p><b>Source</b></p>	<p>[RW] [RW_A] [Event log] [Data log]</p> <p>Select one from the above for the source. There may be several data sampling objects registered in the project. If you select [Data log], use “Data Sampling object index:” to select the right one as shown below.</p>
----------------------	--

	
<p><b>Backup Position</b></p>	<p>Select the destination where the source files will be copied to.</p> <p>a. USB1 or USB2 The USB disk connected to MT8000.</p> <p>b. MT remote printer server To select this, users have to enable <i>MT remote printer server</i> from: Menu ⇒ Edit ⇒ System Parameters ⇒ Printer Server</p>
<p><b>Range</b></p>	<p><b>[Start] from [Today] or [Yesterday]</b></p> <p><b>Within</b></p> <p>Select the range of time period, for example, Select [Yesterday] in [Start], and select “2 day(s)”. It means to save the files yesterday and the day before yesterday. Select “All” to save all the files available in the system.</p> 
<p><b>Attribute</b></p>	<p>There are two ways to activate Backup function.</p> 
	<p><b>Touch trigger</b></p> <p>Touch the object to activate backup operation.</p>

### External trigger

Use a bit device to activate backup operation.


[ON → OFF] when bit device change from ON to OFF

[OFF → ON] when bit device change from OFF to ON

[ON ↔ OFF] when bit device change state.

### Trigger address

When use “external trigger”, assign an appropriate bit device as shown below.



The screenshot shows a configuration window titled "Trigger address". It contains the following fields and options:

- PLC name : Local HMI (dropdown menu)
- Device type : LB (dropdown menu)
- Address : 0 (text input field)
- System tag
- Index register

## 13.25 Media Player Object


For the first timers using Media Player objects, it's necessary to download the project to the HMI *via Ethernet*. EasyBuilder8000 will install Media Player drivers during the download.


### 13.25.1 Overview

The Media Player function is not only used to play video files but also to provide uses of additional controls such as seeking, zooming, volume adjusting and so on. With the Media Player, users can provide operation and maintenance instructions or standard procedures on video, which can help to create an environment that enables any on-site operators to perform tasks efficiently from clear, comprehensible instructions. (Note: The Media Player function is only available on the MT8000X Series models.)

### 13.25.2 Configuration

Click “Media Player object” icon on the toolbar, “Media Player object” dialogue box show up, set each item in the “General” tab, press OK button, a new Media Player object will be created. See the picture below. (Note: The instruction of this section is an example to play a video file located in the “/example” directory.)





General :

- a. In [Control address], select [Enable] and register a word device to control the operation of media player object (example : LW0)

Control address

Enable

PLC name : Local HMI

Device type : LW

Address : 0  System tag

Index register

Command : 0 Status : 0 + 3

Parameter 1 : 0 + 1 File index : 0 + 4

Parameter 2 : 0 + 2 Start time : 0 + 5

End time : 0 + 6

b. In [Control address], unselect the [Update video playing time]

Update video playing time

c. In [Ext. device], select [USB1] and input “*example*” as [Folder name].

Ext. device

USB1  USB2

Folder name : example

d. In [Attribute], unselect [Auto. repeat] and choose black as the background color.

Attribute

Auto. repeat

Background :           

Preview :

Users can examine whether the MT8000 supports the video format via preview function.



- a. Click [Load...] and select the file to be examined. (Users should put the file in the */example* directory of an USB disk)

If the media player starts playing the video, it means the MT8000 supports this video format.

Use [<<] and [>>] to navigate video by 1 minute each time.

To play another video, click [Stop] to close the video file and repeat from step a.

Prepare the video file:

Remove all external devices (SD/USB disk) connected to the MT8000.

Plug the USB disk, which has the video file in it, into the MT8000.

---

**Note**

The first step is there for ensuring the USB disk (in step b) will be recognized as USB1.

---

### 13.25.3 Start / Stop playing video

#### 1. Start playing video

- a. Set [Parameter 1] to 0.
- b. Set [Command] to 1, the system will open the video file and start playing.
- c. After the system start operation, it will reset the [Command] to "0".

---

**Note**

During the period between step b and c, don't change the content of [Command], [Parameter 1], and [Parameter 2], it may cause unpredictable result.

---

## **2. Stop playing video**

- a. Set [Command] to 5, the system will stop playing and close the video file.
- b. After the system complete a, it will reset the [Command] to "0".

---


### **Note**

During the period between step a and b, don't change the content of [Command], [Parameter 1], and [Parameter 2], it may cause unpredictable result.

---

### 13.25.4 Media player setting guide

General :



Setting		Description
Control address	Enable control address	<ul style="list-style-type: none"> <li>● Enable                             <ol style="list-style-type: none"> <li>a. You can use “Control address” to control the operation of media player</li> <li>b. Register a device address for “Control address”.</li> </ol> </li> <li>● Disable                             <p>There is no manual control of video play operation. The system will start to play the first video at designated folder</p> </li> </ul>

		when the window is popup.
	Command	Users set this address to control the operation of media player. ➤ Command (control address + 0)
	Parameter 1	Parameter 1 for control operation. ➤ Parameter 1 (control address + 1)
	Parameter 2	Parameter 2 for control operation ➤ Parameter 2 (control address + 2)
	Status	The system will turn bits ON when state changes or malfunctions. ➤ Status (control address + 3)
	File index	The system will write file index when starting to play a video. ➤ File index (control address + 4)
	Start time	The system will write video start time when starting to play a video. (unit = sec) (Always 0) ➤ Start time (control address + 5)
	End time	The system will write video end time when starting to play a video. (unit = sec) ➤ End time (control address + 6)
	Video playing time	Update video playing time ● Enable The system will write video elapsed time into [playing time] register in every [update period] seconds.
		Update period Update period of [playing time], range between 1 to 60 sec.
		Playing time Update the video elapsed time periodically. (unit = sec) ➤ Playing time (control address + 7)
Video file store location	USB1	Play video files in USB1.
	USB2	Play video files in USB2.
	Folder name	The name of the folder storing video files. Users must put video files in a folder (e.g. “/example”) instead of root directory.  <b>Note</b> 1. [Folder name] couldn't be empty. 2. [Folder name] couldn't include \/:*?"<> .
Attribute	Auto. repeat	When finish playing a video file, the system will

		automatically play next video. e.g. [video 1] ⇒ [video 2] ⇒ ... ⇒ [video n] ⇒ [video 1]
	Background	Select the background color of the object.

★ Normally the format of the above registers is 16-unsigned integer. If a 32-bit word device is chosen as the control address, only 0-15 bits are effective. Users should zero the 16-31 bits.

## 1. Control command :

### a. Play index file

[Command] = 1

[Parameter1] = file index

[Parameter2] = ignore (set 0)

- 
- Note**
1. The files are sorted with file name in ascending order, the “file index=0” is for to the first file, and son on.
  2. If it is unable to scan file, it will set [status] bit 8 to ON.
  3. If check [Auto. repeat], it will automatically play the next file after finish.
- 

### b. Play previous file

[Command] = 2

[Parameter1] = ignore (set 0)

[Parameter2] = ignore (set 0)

- 
- Note**
1. If the [file index] is previously 0, it will re-play the same video from the start.
  2. If it is unable to search the right file, it will set [status] bit 8 to ON.
  3. If check [Auto. repeat], it will automatically play the next file after finish.
- 

### c. Play next file

[Command] = 3

[Parameter1] = ignore (set 0)

[parameter2] = ignore (set 0)

- 
- Note**
1. If there is no next video file, it will play the first (index 0) file.
  2. If it is unable to search the right file, it will set [status] bit 8 to ON.
  3. If check [Auto. repeat], it will automatically play the next file after finish.
-

**d. Pause / Play Switch**

[Command] = 4

[Parameter 1] = ignore (set 0)

[Parameter 2] = ignore (set 0)

**e. Stop playing and close file**

[Command] = 5

[Parameter 1] = ignore (set 0)

[Parameter 2] = ignore (set 0)

**f. Start playing at designated target location**

[Command] = 6

[Parameter 1] = target location (sec)

[Parameter 2] = ignore (set 0)

---

**Note** Parameter 1 (target location) should less than end time. If it is over end time, the system play video from last second.

---

**g. Forward**

[Command] = 7

[Parameter 1] = target location (sec)

[Parameter 2] = ignore (set 0)

---

**Note**

1. Increase playing time by [Parameter 1] seconds. If the system is previously playing video, it continues to play after the operation. If previously paused, it keeps paused.
2. If the playing time is over end time, the system play video from last second.

---

**h. Backward**

[Command] = 8

[Parameter 1] = target location (The unit is sec)

[Parameter 2] = ignore (set 0)

---

**Note**

1. Decrease playing time by [Parameter 1] seconds. If the system is previously playing video, it continues to play after the operation. If previously paused, it keeps paused.
2. If the playing time is less than start time, the system play video from the beginning.

---

**i. Adjust volume**

[Command] = 9

[Parameter 1] = volume (0 ~ 128)

[Parameter 2] = ignore (set 0)

---

**Note** Default volume is 128.

---

**j. Set video display size**

[Command] = 10

[Parameter 1] = display size (0 ~ 16)

[Parameter 2] = ignore (set 0)


---

**Note**

- [0] : Fit video image to object size.
- [1 ~ 16] : Magnification from 25% ~ 400%. Set 1 for 25%, 2 for 50%, 3 for 75% and so on.

---

**k. Status (control address + 3)**



When playing a video, the system will turn ON [open file bit] and [play file bit]. If the file is unable to be scanned or the command is incorrect, the [command error bit] will be set ON (0→1).

---

**Note**


1. If file format is unsupported or disk I/O error happens during playing (e.g. user unplugs the USB disk), the [file error bit] will be set ON (0→1).

2. Refer to the following figure, the value of [status] at each state would be:

“Stop” [status] = 0

“Pause” [status] = 1 ([open file bit])

“Playing” [status] = 3 ([open file bit] + [play file bit])



---

★ Users should only set values to [Command], [Parameter 1] and [Parameter 2], and regard the other registers as read-only.

### 13.25.5 Restrictions

- The system can only play one video file each time.
- If [Auto. repeat] is unselected, the system will stop playing video and close the file after complete a video play operation.
- If [control address] is unselected, the system will find the first file in the designated directory and start playing it.


## 13.26 Data Transfer (Time-based) Object

### 13.26.1 Overview

Data transfer (time-based) object is the same as data transfer (trigger-based) object, it also transfers the data from source to destination register. The difference is the way to activate data transfer operation. The Data transfer (time-based) object conducts data transfer operation based on time schedule, it can also transfer data in the unit of bits.

### 13.26.2 Configuration

Click “Data Transfer (Time-based) Object” icon on the toolbar, the summary of data transfer objects is shown as follows:.



Press the “New...” button in the above dialogue box, the Data Transfer (Time-based) Object dialogue box appear as shown in the picture below, set item and press OK button, the object will be created.

**Data Transfer (Time-based) Object**

Description :

**Attribute**

Address type : Bit  Interval : 3.0 second(s)

No. of bits :

**Source address**

PLC name : Local HMI

Device type : LB


Address :   System tag  
 Index register

**Destination address**

PLC name : Local HMI


Device type : LB

Address :   System tag  
 Index register

<b>Attribute</b>	<b>Address type</b> Select the bit or word device.
	<p><b>[No. of words] or [No. of bits]</b> When select “Word type”, the unit of data transfer is word, set the number of data to transfer. See the picture below.</p>  <p>When select “Bit type”, the unit of data transfer is bit, set the number of bits to transfer.</p>

	<div data-bbox="432 203 1369 369" style="border: 1px solid black; padding: 5px;"> <p>Attribute</p> <p>Address type : <input type="text" value="Bit"/>      Interval : <input type="text" value="3.0 second(s)"/></p> <p>No. of bits : <input type="text" value="15"/></p> </div> <p><b>Interval</b></p> <p>Select the wait interval for each data transfer, for example, select 3 seconds, the system will conduct data transfer operation every 3 seconds.</p> <p><b>Note</b></p> <ol style="list-style-type: none"> <li>1. Specifying a small interval or a big number of data to transfer may cause an overall performance decrease due to the time consuming in transferring data. Therefore, users should always try to choose a longer interval and a smaller amount of data to transfer.</li> <li>2. When a short interval is inevitable, be aware of the interval must be longer than the data transfer operation. For example, if the data transfer operation take 2 seconds, you must set the interval longer than 2 seconds.</li> </ol>
<b>Source address</b>	Set source address.
<b>Destination address</b>	Set destination address

After completing all settings and pressing the “OK” button, a new Data Transfer (Time-based) Object is created. The summary displays all the registered data transfer objects with brief information as shown below.





## 13.27 PLC Control Object

### 13.27.1 Overview

The PLC control object activates a specific operation when the corresponding control device is triggered.

### 13.27.2 Configuration

Click the “PLC Control” icon and the “PLC Control Object” summary appear as shown below.



Press the “New...” button and the “PLC Control” dialogue box appear. Set all the attributes of PLC control and press OK button, a new PLC control object will be created.

**PLC Control**

Description :

PLC name :

**Attribute**

Type of control :

Clear data after window changed       Turn on back light


**Trigger address**

Device type :

Address :        System tag


Index register

OK      Cancel

<p><b>Attribute &amp; Trigger address</b></p>	<p><b>[Type of control]</b></p> <p>To set the type of control. Click the select button and you can drag down a list of all available PLC control functions</p> 
---	---

**a. “Change window”**

This is used to change base window. When the value of [trigger address] is written in a valid window number, the system will close the current window and open the window designated by the [trigger address]. The new window number will be written to the [trigger address + 1].



As an example of the above configuration. When writing a valid window number – 11 into LW0, the system will close the current window and open window 11, then write 11 into LW1 (LW0+1)

If you use 32 bit device as trigger address, and the device type of the trigger address is in word basis, then the system will write the window number into [trigger address +2]

Below is the list of write address for each different type of data format.

Data Format	Trigger address	Write address
16-bit BCD	Address	Address + 1
32-bit BCD	Address	Address + 2
16-bit Unsigned	Address	Address + 1
16-bit Signed	Address	Address + 1
32-bit Unsigned	Address	Address + 2
32-bit Signed	Address	Address + 2

**Note:** If [LB9017] = ON, the write back operation will not be executed.

If “clear data after window change” is selected, the [trigger address] will be reset to 0 after new window is open.

**b. “Write data to PLC (current base window)”**

When the system change the base window, the new window number will be written into the [Trigger address]

**c. “General PLC Control”**

This function performs data transfer between PLC and MT8000 when users set appropriate value in [trigger address].

Control code [trigger address]	Operation for data transfer
1	PLC register → MT8000 RW
2	PLC register → MT8000 LW
3	MT8000 RW → PLC register
4	MT8000 LW → PLC register

With this function the system uses four continuous word devices, please refer to the following explanation.

Address	Purpose	Description
[Trigger address]	Control code	The valid control code is listed in the above table. When a new control code is written into the register, the system will conduct the data transfer function.
[Trigger address+1]	Number of words to transfer	
[Trigger address+2]	Offset to the start address of PLC register	If the value is “n”, the start address of PLC register is “Trigger address + 4 + n”.
[Trigger address+3]	The start address of LW or RW	

As an example, to transfer PLC registers [DM100, 101 ... 105] to MT8000 [RW10, 11 ... 15], follow the steps below:

1. Set Trigger address to DM10..
2. Set [DM11] = 6 ( no. of words to transfer )

3. Set [DM12] = 86 ( DM10+4+86= DM100 )
4. Set [DM13] = 10 ( RW10)
5. Set [DM10] = 1, The system will execute the data transfer operation.

**d. “Back light control (write back)”**

Set [Trigger address] to “1”, the system will turn off the backlight and reset the [Trigger address]. Any touch on the screen will turn the backlight on.

**e. “Back light control”**

This operation is the same as “Back light control (write back)” except the system would not reset the [Trigger address].

**e. “Sound control”**




Activate the [Trigger address], the system will play the sound.

You may configure three different way to activate the [Trigger address ]:

- (1) OFF to ON (OFF→ON)
- (2) ON to OFF (ON→OFF)
- (3) State change (either from ON→OFF or OFF→ON)

**f. “Execute macro program”**



Activate the [Trigger address], the system will execute the Macro.

You may configure three different way to activate the [Trigger address ]:


- (1) OFF to ON (OFF→ON)
- (2) ON to OFF (ON→OFF)
- (3) State change (either from ON→OFF or OFF→ON)

**h. “Screen hardcopy”**

Activate the [Trigger address], the system will have designated window printed out. You may configure three different way to activate the [Trigger address ]:

- (1) OFF to ON (OFF→ON)
- (2) ON to OFF (ON→OFF)
- (3) State change (either from ON→OFF or OFF→ON)

The designated window can be one of following three different types:




**[Current base window]**

Print the base window at the time the operation is activated.


**[Window no. from register]**

Print the window designated by a PLC device. In the following example, if [LW0] = 14, the window 14 will be printed out.



**[Designate window no.]**

Select a base window to be printed out.



**Note**

1. The system performs a *background printing process* when the printed

	<p>window is not the current base window.</p> <p>2. For a window designed to be printed at background, users should put neither direct window nor indirect window in it.</p>
--	--


## 13.28 Schedule Object


### 13.28.1 Overview

Schedule object is used to turn on/off a bit or write a value to a word device at designated time. The time schedule setting is very flexible, it can be on daily basis or weekly basis. For more advance application you can use a table (a block of word devices) to set start and terminate time, then update the table at any scheduled time.

### 13.28.2 Configuration

Click the “Schedule” icon on the toolbar and the “Scheduler list” dialogue box will appear, press the “New” , the schedule object dialogue box shall appear as shown below:





Example 1:

The motor is scheduled to be power ON at 8:00 and power off at 17:00, Monday to Friday. Here we use LB100 to control the motor. Follow the steps to set up the schedule object.




[Time Set tab]

3. Select [Time Set] tab, check [Constant]




4. Unselect [Setting on individual day]. In [Start], adjust time as 8:00:00 and select Monday to Friday.



5. In [End], select [Enable termination action] and adjust time as 17:00:00.



6. Click [OK], a new schedule object is created and display on the schedule list.





Example 2:

Set temperature at 90F at 8:00 and set it back to 30F (standby mode) at 17:00, Monday to Friday.





When the designated start time is reached



The running mode temperature setting is written




When the designated stop time is reached



The standby mode temperature setting is written

Click [New...], to add a new schedule object. Follow the steps to set up the schedule object. The [LW100] is used to store set value of temperature.



[General]

1. [Power-ON start/end action]

Power-ON start/end action

2. Check [Word write] in [Action mode],



3. Set LW100 in [Action address]

**Action address**

PLC name : Local HMI

Device type : LW

Address : 100  System tag

Index register

16-bit Unsigned

4. Check [Constant] and set [Write start value] to 90 in [Word write value settings],

**Word write value settings**

Constant  Address

Write start value : 90

[Time Set tab]

5. Select [Time Set] tab, check [Constant]

General **Time Set** Prohibit

Constant  Address

6. Unselect [Setting on individual day]. In [Start], adjust time as 8:00:00 and select Monday to Friday.

Setting on individual day

**Start**

8 0 0

Sun  Mon  Tue  Wen  Thu  Fri  Sat

7. In [End], select [Enable termination action] and adjust time as 17:00:00.

**End**

Enable termination action

17 0 0

- Select [General] tab, set [Write start value] to 90 and [Write end value] to 30.


Write start value :

Write end value :




- Click [OK], the settings appear in the Scheduler list.



Schedule settings guide:

**Action**



Settings	Description
Action Mode	Select the type of operation performed at designated time.


<p>Bit ON</p>	<p>At start time, turn ON the specific bit. At end time, turn OFF the bit.  Example: Start time = 09:00:00  End time = 17:00:00</p> 
<p>Bit OFF</p>	<p>At start time, turn OFF the specific bit. At end time, turn ON the bit.  Example: Start time = 09:00:00  End time = 17:00:00</p> 
<p>Word write</p>	<p>At start time, the specific [Write start value] is written to the action address.  At end time, [Write end value] is written to the action address.  Example: Device address = LW100  Start time = 09:00:00  End time = 12:00:00  Write start value = 10  Write end value = 0</p> 
<p>Action address</p>	<p>Specify the address where the scheduler performs actions on.</p>


Settings	Description
Power-ON start/end action	<p>Select the action to perform when power is turned on.</p> <p>Enable</p> <p>If the MT8000 power is turned ON within the scheduler range, the start action is performed. If the MT8000 power is turned ON outside of the scheduled range, the termination action is performed.</p> <p>Inside the scheduled range:</p>  <p>Outside the scheduled range:</p>  <p>Disable</p> <p>If power is turned ON but the time is later than the Start Time, the action is not automatically performed. However, the termination action is automatically performed.</p> <p>Also, if the termination action is not set, the schedule range is unable to recognize and the action is not performed.</p>
Word write value Settings	<p>These settings are active only when Action Mode is set to [Word Write].</p>
Write start value	<p>When performing start action, the system will write this value into action address.</p> <p>For [Constant] Designates the value to be written at start time.</p> <p>For [Address] Designates the address used to store the start time value.</p>



Write end value	<p>When performing end action, the system will write this value into action address.</p> <p>For [Constant] Designates the value to be written at end time.</p> <p>For [Address] Designates the address used to store the end time value.</p> <p><b>Note</b> You can use this option if the [Enable termination action] in [Time Set] tab is selected.</p>
-----------------	---

**[Time Set]**

**Time Set (when [Constant] is selected)**




Settings	Description
Constant/Address	<p>Select the method to set the start time and end time.</p> <p>Constant Specifies a fixed time and day.</p> <p>Address The start/end time is retrieved from the device address at on line operation.</p>
Setting on individual day	<p>Enable</p> <p>Start time and end time can be set in different day of week. There is only one start time and one end time during the week. You have to set both start time and end time with this mode.</p> <div style="text-align: center;"> <p>Start action                      Termination action</p> <p>09:00                                      17:00</p>  </div> <p><b>NOTE</b></p> <ol style="list-style-type: none"> <li>1. You must enter settings for the Start Time and End Time.</li> <li>2. You cannot set the Start Time and End Time to the exact same day and time.</li> </ol> <p>Disable</p> <p>A schedule that is 1 day (Start and End times are within 24 hours) can be entered. Multiple Start and End days can be selected. You can perform actions at the same time on multiple days..</p> <p>To specify an End Time, you must select [Enable termination action]</p>

	<div style="text-align: center;"> <p>Start action 09:00                      Termination action 17:00</p>  </div> <p>You cannot set the Start Time and End Time to the exact same day and time.</p> <p>The time scheduler is for one day only, so if the End Time is earlier than the Start Time, the operation of End Time will be performed on the next day.</p> <p>(For example)</p> <p>Start day: Monday  Start: 22:00:00  End: 01:00:00</p> <div style="text-align: center;">  </div>
Start	Set the start time and day. When [Setting on individual day] is disabled, user can designate more than one day.
End	Set the end time and day.  When [Enable termination action] is selected, the end time can be specified.  The day settings can only be set when [Setting on individual day] is enabled.

### Time Set (when [Address] is selected)

If “address” mode is selected, the system retrieves the start/end time and day from word devices. Therefore, users can set and change scheduled time in operation.



The image shows a software dialog box titled "Scheduler" with a blue title bar and a close button (X) in the top right corner. The dialog has three tabs: "General", "Time Set", and "Prohibit". The "Time Set" tab is active. At the top, there are two radio buttons: "Constant" (unselected) and "Address" (selected). Below this, there is a section titled "Time setting address" enclosed in a rounded rectangle. It contains a dropdown menu for "PLC name" set to "Local HMI", another dropdown for "Device type" set to "LW", and a text input field for "Address" containing "0". To the right of the "Address" field are two checkboxes: "System tag" and "Index register", both of which are unchecked. Below the "Time setting address" section, there are eleven text input fields, each with a label and a value: "Control : 0 + 0", "Status : 0 + 1", "Action mode : 0 + 2", "Start time (day) : 0 + 3", "Start time (hour) : 0 + 4", "Start time (minute) : 0 + 5", "Start time (second) : 0 + 6", "End time (day) : 0 + 7", "End time (hour) : 0 + 8", "End time (minute) : 0 + 9", and "End time (second) : 0 + 10". At the bottom of the dialog, there are three buttons: "OK", "Cancel", and "Help".

User designates the [Time setting address] as the top address used to store time settings data. The 11 word devices are automatically allotted.

Normally the format of the above word devices is 16-unsigned integer. If a 32-bit word device is chosen, only 0-15 bits are effective and users should zero the 16-31 bits.

a. **Control** (Time setting address +0)

The layout of the Control word is shown below. Users set the [time acquisition request bit] ON (0→1) to make the system reads the [Action mode], [Start time], and [End time] and uses them as the new scheduled time.



Bit 00: time acquisition request bit (0: no action, 1: perform time read)

---

**NOTE** The system would not read start and end time data unless the [time acquisition request bit] is set ON.

---

b. **Status** (Time setting address +1)

The layout of the Status word is shown below.

When the system completes the read operation, it will turn the [time acquisition complete bit] ON (0→1). Also, if the read time data is incorrect, the [error notification bit] will be turned ON (0→1).




Bit 00: time acquisition complete bit (0: null, 1: read operation complete)

Bit 01: error notification bit (0: no error, 1: start or end time format is incorrect)

---

**NOTE** After system reads the time data and turns the [time acquisition complete bit] ON, be sure to turn [Control] [time acquisition request bit] OFF. Once this bit is turned OFF, the system will set both the [Status] [time acquisition complete bit] and [error notification bit] to OFF.

---



c. **Mode** (Time setting address +2)

Enable and disable the [Termination time action] and [Setting on individual day].

15	02 01 00	Bit
Reserved (0 fixed)	0	0

Bit 00: Termination time setting (0: disable, 1: enable)

Bit 01: Setting on individual day (0: disable, 1: enable)


**NOTE**

1. If [setting on individual day] is OFF, the system still reads all 11 word devices but ignores the end time data.

2. If [setting on individual day] is ON, be sure to enter all start and end time information. If 2 or more of the start/end day bits are turned ON simultaneously, an



## Prohibit




Settings	Description
Prohibit	Enable MT8000 reads the bit status before performing start action. If the bit is ON, the schedule action is not performed.
Sound	Enable When performing start and termination action, the system will simultaneously play the specified sound.

### 13.28.3 Restrictions

User can register the maximum of 32 entries in Scheduler list.

The time scheduler features are one time actions. When the start time or end time is reached, the system writes the value to device just one time. (not repeated)



- Once the system execute start action, it will read [Write start address] and [Write end address] altogether, after then, even you change the value of [Write end address], the system would not use the new value.
- When the operator changes RTC data, for those schedule object with both start time and end time setting, the system will check if the time update changes the status from out of schedule range to within schedule range, if it is, the start action will be performed.
- If there are several schedule objects registered the same start time or end time, when time up the system will perform the operation from the first to the last in ascending order.
- When [Time Set] are specified as [Address] mode, the system will read [control] word periodically.
- When [Time Set] are specified as [Address] and start time and end time is over valid range, the system may not execute operation properly.
- When [Time Set] are specified as [Address], the action will not start up until time data update is success.

## 13.29 Option List


### 13.29.1 Overview

An Option List displays a list of items that the user can view and select. Once the user selects an item, the value corresponding to the item will be written to a word register. There are two forms for this object – Listbox and Drop-down list. The listbox lists all items and highlights the selected one. However, the drop-down list normally displays only the selected item. Once the user touches it, the system will display a listbox (which is similar to the one with Listbox style) beneath the object.



### 13.29.2 Configuration

Click the “Option List” icon , “Option List object properties” dialogue box appears as follows:




### Option list tab

Settings	Description
Attributes	<ul style="list-style-type: none"> <li>• Mode Select the object style; one of Listbox and Drop-down list.</li> <li>• No. of state Set the number of states for the object. Each state represents an item displayed in the list and a value to be written to the [Control address].</li> <li>• Background Select background color for the object.</li> <li>• Selection Select background color for the selected/highlighted item.</li> </ul>
Control address	Select the [PLC name], [Device type], [Address] of the word register device that controls the display of the object and the system writes the value of the state to the word register.
Write when button is released	<ul style="list-style-type: none"> <li>• Unselected The system will write value to the [Control address] when the user touches an item.</li> <li>• Selected The system will write value to the [Control address] when the touch action is released.</li> </ul>

**NOTE**

- This option is only available in listbox style.

Mapping tab



Settings	Description
Mapping table	This table displays all available states/items and their labels and values.. To change the number of available states, please refer to [Option list tab] → [Attributes] → [No. of state].

	<ul style="list-style-type: none"> <li>● State The system lists all available states. Each state represents an item that will be displayed in the list. This field is read-only.</li> <li>● Value Here user can assign value for each item, basing on the following two criteria: <ul style="list-style-type: none"> <li>a. [For reading] If any change of the content from [Control address] is detected, the object compares the content with these values and selects the first matched item. If no item is matched, the status goes to error state and signals the notification bit register (if requested).</li> <li>b. [For writing] The system writes this value to [Control address] when user selects an item.</li> </ul> </li> <li>● Label Users can assign label for each item. The option list object displays the labels of all items in the list for users to review and select.</li> <li>● Error state <ul style="list-style-type: none"> <li>a. As the illustration shown above, state 10 is the error state when specifying 10 in [No. of state]. Similarly, if you set [No. of state] to 11 then state 11 would be the error state, and so on.</li> <li>b. On error state, the listbox-style option list removes the highlight to represent no item is selected and the drop-down list displays the label of error state.</li> <li>c. The label of error state is only applied to the option list objects with drop-down list style. The listbox-style list has nothing to do with this label.</li> </ul> </li> </ul>
Set default	Set default values for all states, i.e. set 0 for state 0, 1 for state 1 and so on.
Notification	<ul style="list-style-type: none"> <li>● Enable The system will set ON/OFF to the specified bit register when error is detected. The signal of the bit register could be used to trigger a procedure for correcting the error.</li> </ul>


## Chapter 14 Shape Library and Picture Library

The EB8000 provides Shape Library and Picture Library features to add the visual effects of objects. Each Shape and Picture includes up to 256 states. This chapter expatiates how to create Shape Library and Picture Library.



Refer to Chapter 9 - “Object’s General Attribute” for information about how to use Shape Library and Picture Library.

### 14.1 Creating Shape Library

A shape is a graph composed of lines, rectangles, circles and other drawing objects. A complete Shape can possess more than one state, and each state can include two parts: frame and inner. See the illustration as below:



An object can be set to use the Shape’s frame, inner or both. Click [Shape Library] button on the toolbar, and the [Shape Library] dialogue box appears as below:



### [Library]

Selecting the source of a Shape from the Shape Library which has been added into the current project.


### [State]

Selecting the state the current Shape wants to display. If the selected Shape isn't displayed, it means that the Shape does not exist or the state of the Shape isn't defined.

### [Select Lib. ...]

Click the [Select Lib. ...] button, and the following dialog appears for users to select the file path of the Shape Library to be added.

By previewing the content of the library on the right hand side of the window, users can select suitable library.



**[New Lib. ...]**

Click the button to add a new Shape Library.



**[Unattach Lib.]**

Click the button to delete the Shape Library in [Library] from the current project.



**[Delete all States]**


Delete all states of the selected Shape.

**[Delete Cur. State]**

Delete current state of the selected Shape.


**[Rename ...]**

Rename the selected Shape.



**[Place ...]**


Export the Shape to be placed in the current window.




Below is an example of how to create a new Shape Library and add a Shape with two states to it.

Step 1

Click [New Lib. ...] and input the name of the new Shape Library.




A new Shape Library “TEST” will be added to the Shape Library Manager dialogue box. At this moment, there is no Shape in the library.




### Step 2

Add a state to the selected Shape. First, using the drawing tools to draw a graph in the window and select the graph to be added to the Shape Library.



Click the “Save Objects to Shape Library” button on the toolbar and the following dialogue appears:



[Shape library]

Select the Shape Library for the graph to be added to. In this example, we select “TEST” library.

[Description]

The name of the Shape.

[Shape no.]

The number of the Shape Library the shape would like to be added in.

[State]

Select the state of the Shape which the graph wants to be. Here the state is set for 0. The EB8000 provides 256 states for each Shape.

[Frame]


If [Frame] is selected, the graph will become a frame for the Shape.

[Inner]

If [Inner] being selected, the graph will become an inner for the Shape.




The picture above shows information of the Shape. Neither frame nor inner is defined in the current state (state 0) of the Shape. After clicking the OK button, the graph will be added to the Shape Library; In addition, it also shows that the Shape No.0 has only one state and the frame has also been defined.




### Step 3

Likewise, create another state by the same process as in the Step 2, but the new graph has to be defined as state 1:




Click OK and a complete Shape with two states is created. See the following picture.



## 14.2 Creating Picture Library

Click the “Picture Library” button on the toolbar, and the “Picture Library” dialogue appears.





[Library]

Picture Libraries which have been added into the current project. Select the library source of a picture from the list.


[State]

Select the state that the current graph wants to display. If the selected Picture isn't displayed, it means that the Picture does not exist or the state of the Picture isn't defined.

[Select Lib. ...]


Click the [Select Lib. ...] button, and the following dialog appears for users to select the file path of the Picture Library to be added.

By previewing the content of the library on the right hand side of the window, users can select suitable library.




[New Lib. ...]

Click the button to add a new Picture Library.



[Unattach Lib.]

Click the button to delete the Picture Library in [Library] from the current project.



[Delete all States]


Delete all states of the selected Picture.

[Delete Cur. State]

Delete current state of the selected Picture.

[Rename ...]

Rename the selected Picture.



[Insert Before...]


Add a new state before the current state.

[Insert After...]

Add a new state after the current state.

[Export ...]


Export the selected picture to the appointed place. As shown below, users can get the original picture.



Below is an example of how to create a new Picture Library and add a Picture with two states to it.

Step 1

Click [New Lib. ...] and input the name of the new Picture Library.




A new Picture Library “TEST” will be added to the Picture Library Manager dialogue box. At this moment, there is no Picture in the library.




### Step 2

Prepare the pictures to be added; suppose the two graphs in the following picture are used to represent the state 0 and the state 1 respectively.




Click the [Import Picture...] button and a dialogue appears as below. Set [Total states] to 2, meaning the picture includes 2 states, and then click [Next].



### Step 3

When the dialogue shown in the following picture appears, select the source of a picture, state 0, and select the correct transparent color. In the example below, the blue color RGB (0, 0, 255) is a transparent color. After the setting of the state 0 is completed, click the [next] button to continue the setting of the other state.




Before choosing transparent color, check [Transparent] box first and then left click on location-to-be of the graph. At this time, EB8000 will automatically display RGB value of the transparent color. Take above as an example, the actual shape shows as below:




#### Step 4

Likewise, select the source of a picture, state 1 and select the correct transparent color for it. After the completion of the settings, click the [Finished] button.



Below shows the complete picture is created. A new picture “F Yellow” can be found in the Picture Library Manager dialogue box. From the information we know the picture is in the format of bitmap and with two states.





## Chapter 15 Label Library and Using Multi-Language

Label Library is used in the Multi-Language environment. Users can design the content of Label Library according to the real demands. Select the suitable label from Label Library when text is needed.

### 15.1 Introduction

The system in operation will display the corresponding text to the language in use according to the settings. The EB8000 supports 8 different languages simultaneously. Click the “Label Library Manager” button on the toolbar and the dialogue appears as below:



#### [State no.]

Indicate the current state; each Label has a maximum of 256 states.

**[New ...]**

Create a new Label.

**[Settings ...]**

Modify the content of Label.

**[Delete]**

Delete the selected Label.

**[Copy]**

Copy the content of the label.

**[Paste]**

Paste the content of the label.

**[Save Label File]**

Save the label file.

**[Load Label File]**

Download the label file.

**[Export CSV]**

Export the whole content of the specified Label Library with CSV format to the appointed storage space.

This function doesn't support Unicode.

**[Import CSV]**


Import the existing Label Library with CSV format to the current project (MTP).

This function doesn't support Unicode.

The two Labels “Demo” and “Test” can be seen in the “Label Library” dialogue where “Demo” includes 8 languages: English, traditional Chinese, simplified Chinese, Japanese, Korean, French, Thai, and Russian.

## 15.2 Settings of Label Library's Font

Different fonts can be selected for different languages.




### [Font]

Under the Multi-Language configuration, users select fonts for different languages.

### [Comment]


The comment for each font.



## 15.3 How to Create a Label Library

The following illustrations show how to create a Label Library.

First of all, open the “Label Library” dialogue and click [NEW...]. Correctly set the dialogue as shown below and then click OK.




### [Label name]

The name of the label. Here it's named as “Pump Alarm”.


### [No. of states]

The number of states possessed by the Label.

When the process is complete, a new Label “Pump Alarm” with 2 states will be added to the Label Library. See the picture below.




Last, select “Pump Alarm”, click [Settings ...] and the Label Tag Content dialog appears for users to set up the corresponding language content.




## 15.4 Using Label Library

When there are already some defined labels in Label Library, users can find out those Labels in [Label tag] by selecting [Use label library] in the object's [Label] tab.




When the Label is selected, [Content] dialog shows the content of selected label, and the settings of the font are also included in the Label Library.




## 15.5 Use of Multi-Language

When users would like to have the object's text with the multi-language support, except for using the Label Library, it needs to use with the system reserved register [LW9134]. The value range of the [LW9134] can be set from 0 to 7. Different value of [LW9134] corresponds to different Languages. The example below demonstrates how to use the multi-language feature.

First of all, create a Text Object and set the content of it as below:



Next, create a Numeric Input Object. Set its Read address as below: you will see the Read address in use is the system reserved register [LW9134].



The following illustrations are the results of simulation.


When the value of [LW9134] is changed, the content of the Text Object will also be changed automatically.



## Chapter 16 Address Tag Library

### 16.1 Creating Address Tag Library

At the beginning of designing a project, generally speaking, users are recommended to define commonly-used addresses in the Address Tag Library. It is not only to avoid repeating the address input for an address but also to more clearly convey the function of an address. Click the “Tag” button on the toolbar to call up the “Address Tag Library” dialogue box. See the pictures below.



#### [Customized]

Display the Address Tags defined by users.

#### [System]

Display the Address Tags reserved by the system.

#### [New ...]

Add a new Address Tag.

### [Delete]

Delete a selected Address Tag.

### [Settings ...]

Modify the selected Tag.

### [Export CSV...]

Export the current Address Tag Library to the appointed space in the form of CSV.


### [Import CSV...]

Import the Address Tag Library to the current project in the form of CSV.

The picture above shows the contents of two existing customized Address Tags in the library. And the following explains the meanings of terms.

No.	Tag name	PLC Name	Device Mode	Device Type	Address	Read/Write
1	Temperature	mitsubishi fx0n	WORD	TV	100	Read/Write

The picture below indicates another kind of Address Tag which is the system reserved register.



Before using the Address Tag Library, users need to add the content of the library at first. Click the [New...] button, and the “Address Tag” dialogue appears as below:

**[Tag name]**

The name of the Address Tag.

**[PLC name]**

The name of the PLC which is selected from the device list.

**[Address type]**

The type of the Address; there are “bit type” and “word type” available.

**[Device type]**

The type of the device t; the types available are related to [PLC name] and [Address type].

**[Address]**


The content of the address.

Click the OK when the settings are done, and a new tag will be found in the customized library. See the picture below.

No.	Tag Name	PLC Name	Device Mode	Device Type	Address	Read/Write
0	Alarm	MITSUBISHI FX0n	BIT	X	0	Read/Write
1	Temperature	MITSUBISHI FX0n	WORD	TV	100	Read/Write
2	Test Tag	MITSUBISHI FX0n	WORD	TV	200	Read/Write

## 16.2 Using Address Tag Library

After creating the Address Tag Library and setting up the connection PLC devices which are related to the customized Tag in the [General] tab of the “Object Attributes,” the [User-defined tag] check box can be found as below.



The screenshot shows the 'General' tab of the 'Object Attributes' dialog. The 'PLC name' dropdown is highlighted with a red box and contains 'MITSUBISHI FX0n'. The 'Mode' is set to 'Value' and 'Offset' is '0'. The 'Device type' dropdown is set to 'Temperature' and the 'Address' is 'TV100'. The 'User-defined tag' checkbox is checked and highlighted with a red box.

There are some items in the [Device type] tab for selecting.



The screenshot shows the 'Device type' dropdown menu. The 'Temperature' option is selected and highlighted in blue. The 'Test Tag' option is also visible.

When the settings are completed, the object information window will show the name of the Address Tag used for the object. See the picture below.

```
-----  
TX_2  
TX_3  
FK_0  
TX_4  
NE_0 (LW-9134 (16bit) : language mode : -LW9134)  
WL_0 (Temperature : MITSUBISHI FX0n-TV100)  
11  
12: WINDOW_012  
13
```

## **Chapter 17 Transferring Recipe Data**


Recipe Data are stored in flash memory. When system startup up, both the RW and RW\_A memory will be restored from the recipe data in flash memory, the way of reading and writing Recipe Data is the same as operating the normal Word Register.

The size of Recipe Data in both RW and RW1 are 64k words. User can update Recipe Data by using CF Card, USB cable or Ethernet. It is possible to upload Recipe Data to the designated address of PC; furthermore, it can save the PLC's data in recipe memory. The following explain all of the ways of operating recipe data.

### **17.1 Updating Recipe Data by Using Ethernet or USB cable**

Click [Download] on Project Manager. Select [RW] and [RW\_A] and designate the directory of the source files. After the download operation complete, start up the HMI again, and the contents of RW and RW\_A will be updated.


When [Reset recipe] is selected, before start download processing, the EB8000 will set all the data of [RW] and [RW\_A] to 0 first.



## 17.2 Updating Recipe Data by Using CF Card or USB Stick

Click [Building Download Data for CF/USB Disk] on Project Manager.

The function is for building the download data and the settings shows as below.



### [Select the folder to save download data]

Insert CF card or USB stick to PC and click **[Browse...]** to assign the file path (or directory name) and then click **[Build]** to set all contexts of the downloaded data.

**Note:** Save location should be the name of directory and avoid designating only root directory. For example, both “c:\” and “f:\” are illegal names.

## 17.3 Transferring Recipe Data

Using the [Data Transfer (Trigger-based) object] to transfer Recipe Data to the appointed address, or saving the data of the designated address in [RW] and [RW\_A] as well. Please refer to the [Data Transfer (Trigger-based) object] section for related information.

## 17.4 Saving Recipe Data Automatically

In order to prolong the life of HMI’s flash memory, the EB8000 will save Recipe Data automatically **every minute** to avoid losing the data when the HMI shuts down. The EB8000 provides user with [LB9029: save all recipe data to machine (set ON)] system register bit function

to save Recipe Data manually. The EB8000 will save Recipe Data when user set ON to [LB9029]. But when user set ON to [LB9028: reset all recipe data (set ON)], the EB8000 will clear all Recipe Date as 0.

## Chapter 18 Macro Reference

Macros provide the additional functionality your application may need. Macros are automated sequences of commands that are executed at run-time. Macros allow you to perform tasks such as complex scaling operations, string handling, and user interactions with your projects. This chapter describes syntax, usage, and programming methods of macro commands.

### 18.1 Macro Construction

A Macro is made up of statements. The statements contain constants, variables and operations. The statements are put in a specific order to create the desired output.

A Macro is constructed in the following fashion:

Global Variable Declaration	-----Optional
Sub Function Block Declarations	-----Optional
Local Variable Declarations	
End Sub	
macro_command main()	-----Required
Local Variable Declarations	
[Statements]	
end macro_command	-----Required

Macro must have one and only one main function which is the execution start point of macro. The format is:

```
macro_command Function_Name()
```

```
end macro_command
```

Variable declarations must at the beginning of a statement within a function. Other statements before variable declarations will cause compiler error.

Local variables are used within the main macro function or in a defined function block. Its value remains valid only within the specific block.

Global variables are declared before any function blocks and is valid for all functions in the macro. When local variables and global variables have the same name declaration name, only the local variables are valid.

Below is a simple Macro which includes a variable declaration and a function call.

```
macro_command main()
  short pressure = 10           // local variable declaration
  SetData(pressure, "Allen-Bradley DF1", N7, 0, 1) // function calling
end macro_command
```

## 18.2 Syntax

### 18.2.1 Constants and Variables

#### 18.2.1.1 Constants

Constants are fixed values and can be entered directly into statements as:

Constant Type	Note	Example
Decimal integer		345, -234, 0, 23456
Hexadecimal	Must begin with 0x	0x3b, 0xffff, 0x237
ASCII	String must be enclosed in single quotes	'a', 'data', 'name'
Boolean		true, false

Example statement using a constant:

```
macro_command main()
short A, B // A and B are variables
A = 1234
B = 0x12 // 1234 and 0x12 are constants
end macro_command
```

### 18.2.1.2 Variables

Variables are names that represent information. The information can change as the variable is modified by statements.

#### Naming Rules for Variables

1. A variable must start with an alphabet.
2. Variable names longer than 32 characters are not allowed.
3. Reserved words cannot be used as Variable names.

There are 5 different Variable types:

Variable Type	Description	Range
bool	1 bit (discrete)	0, 1
Char	8 bits (byte)	±127
short	16 bits (word)	±32767
Int	32 bits (double word)	±2147418112
float	32 bits (double word)	

#### Declaring Variables

Variables must be declared before being used. All variable declarations must be made before any other statements in the macro. To declare a variable, specify the type then the variable name.

Example:

```
int    a
short  b, switch
float  pressure
```

#### Declaring Arrays

Macros support one-dimensional arrays (zero-based index). To declare an array of variables, specify the type, the variable name then the number variables in the array enclosed in brackets “[ ]”. Arrays are 1 to 4096 variables in length. (Macros only support up to 4096 variables per macro).

Example:

```
int    a[10]
short  b[20], switch[30]
float  pressure[15]
```

Minimum of array index is 0 and maximum of array index is (array size – 1).

Example:

```
char data 100] // array size is 100
```

where: minimum of array index is 0 and maximum of array index is 99 ( 100 – 1)

## Variable and Array Initialization

There are two ways variables can be initialized:

1. By statement using the assignment operator (=)

Example:

```
int a
```

```
float b[3]
```

```
a = 10
```

```
b[0] = 1
```

2. During declaration

```
char a = '5', b = 9
```

The declaration of arrays is a special case. An entire array can be initialized during declaration by enclosing comma separated values inside curly brackets “{}”.

Example:

```
float data[4] = {11, 22, 33, 44} //now data[0] is 11, data[1] is 22....
```

## 18.2.2 Operators

Operations are used to designate how data is to be manipulated. In each statement, the operator on the left is set to the conditions on the right.

Operator	Description	Example
=	Assignment operator	pressure = 10

Arithmetic Operators	Description	Example
----------------------	-------------	---------

+	Addition	$A = B + C$
-	Subtraction	$A = B - C$
*	Multiplication	$A = B * C$
/	Division	$A = B / C$
%	Modulo division (return remainder)	$A = B \% 5$

Comparison Operators	Description	Example
<	Less than	if $A < 10$ then $B = 5$
>=	Less than or equal	if $A >= 10$ then $B = 5$
>	Greater than	if $A < 10$ then $B = 5$
<=	Greater than or equal	if $A <= 10$ then $B = 5$
==	Equal	if $A == 10$ then $B = 5$
<>	Not equal	if $A <> 10$ then $B = 5$

Logic Operators	Description	Example
<b>And</b>	Condition AND	if $A < 10$ and $B > 5$ then $C = 10$
<b>Or</b>	Condition OR	if $A >= 10$ or $B > 5$ then $C = 10$
<b>Xor</b>	Condition Exclusive OR	if $A \text{ xor } 256$ then $B = 5$
<b>Not</b>	Condition NOT	if not $A$ then $B = 5$

Shift and bitwise operators are used to manipulate bits within char, short, and int variable types. The priority of these operators is from left to right within the statement.

Shift Operators	Description	Example
<<	Shift left specified number of bits	$A = B << 8$
>>	Shift right specified number of bits	$A = B >> 8$

Bitwise Operators	Description	Example
&	ANDs two values together	$A = B \& 0xf$
	ORs two values together	$A = B   C$
^	XORs two values together	$A = B \wedge C$
~	Compliments a value	$A = \sim B$

## Priority of All Operators

The overall priority of all operations from highest to lowest is as follows:

Operations within parenthesis are carried out first

Arithmetic operations

Shift and Bitwise operations

Comparison operations

Logic operations

Assignment

## Reserved Keywords

The following keywords are reserved for Macro use. They cannot be used for variable, array, or function names.

`+`, `-`, `*`, `/`, `%`, `>=`, `>`, `<=`, `<`, `<>`, `==`, `and`, `or`, `xor`, `not`, `<<`, `>>`, `=`, `&`, `|`, `^`, `~`  
`exit`, `macro_command`, `for`, `to`, `down`, `step`, `next`, `return`, `bool`, `short`, `int`, `char`, `float`, `void`, `if`, `then`,  
`else`, `break`, `continue`, `set`, `sub`, `end`, `while`, `wend`, `true`, `false`  
`SQRT`, `CUBERT`, `LOG`, `LOG10`, `SIN`, `COS`, `TAN`, `COT`, `SEC`, `CSC`, `ASIN`, `ACOS`, `ATAN`,  
`BIN2BCD`, `BCD2BIN`, `DEC2ASCII`, `FLOAT2ASCII`, `HEX2ASCII`, `ASCII2DEC`, `ASCII2FLOAT`,  
`ASCII2HEX`, `FILL`, `RAND`, `DELAY`, `SWAPB`, `SWAPW`, `LOBYTE`, `HIBYTE`, `LOWORD`,  
`HIWORD`, `GETBIT`, `SETBITON`, `SETBITOFF`, `INVBIT`, `ADDSUM`, `XORSUM`, `CRC`, `INPORT`,  
`OUTPORT`, `POW`, `GetError`, `GetData`, `GetDataEx`, `SetData`, `SetDataEx`

## 18.3 Statement

### 18.3.1 Definition Statement

This covers the declaration of variables and arrays. The formal construction is as follows:

`type`      `name`              where define the type of name

Example:

```
int A              //define a variable A as an integer
```

`type name[constant]`      where define the type of array name

Example:

```
int B[10]
```

where define a variable B as a one-dimensional array of size 10

### 18.3.2 Assignment Statement

Assignment statements use the assignment operator to move data from the expression on the right side of the operator to the variable on the left side. An expression is the combination of variables, constants and operators to yield a value.

Variable = Expression

Example

```
A = 2
```

where a variable A is assigned to 2

### 18.3.3 Logical Statements

Logical statements perform actions depending on the condition of a Boolean expression. The syntax is as follows:

#### Single-Line Format

```
if <Condition> then
    [Statements]
else
    [Statements]
end if
```

Example:

```
if a == 2 then
    b = 1
else
    b = 2
end if
```

## Block Format

```
If <Condition> then  
    [Statements]  
else if <Condition – n> then  
    [Statements]  
else  
    [Statements]  
end if
```

Example:

```
if a == 2 then  
    b = 1  
else if a == 3  
    b = 2  
else  
    b = 3  
end if
```

Syntax description:

<b>if</b>	Must be used to begin the statement
<b>&lt;Condition&gt;</b>	Required. This is the controlling statement. It is FALSE when the <Condition> evaluates to 0 and TRUE when it evaluates to non- zero.
<b>then</b>	Must precede the statements to execute if the <Condition> evaluates to TRUE.
<b>[Statements]</b>	It is optional in block format but necessary in single-line format without else. The statement will be executed when the <Condition> is TRUE.
<b>else if</b>	Optional. The else if statement will be executed when the relative <Condition-n> is TRUE.
<b>&lt;Condition-n&gt;</b>	Optional. see <Condition>
<b>else</b>	Optional. The else statement will be executed when <Condition> and <Condition-n> are both FALSE.
<b>end if</b>	Must be used to end an if-then statement.

## 18.3.4 Reiterative Statements

Reiterative statements control loops and repetitive tasks depending on conditions. There are two types of reiterative statements.

### 18.3.4.1 for-next Statements

The for-next construction is for stepping through a fixed number of iterations. A variable is used as a counter to track progress and test for ending conditions. Use this for fixed execution counts. The syntax is as follows:

```
for [Counter] = <StartValue> to <EndValue> [step <StepValue>]  
    [Statements]  
next [Counter]
```

or

```
for [Counter] = <StartValue> down <EndValue> [step <StepValue>]  
    [Statements]  
next [Counter]
```

Example:

```
for a = 0 to 10 step 2  
    b = a  
next a
```

Syntax description:

<b>for</b>	Must be used to begin the statement
<b>[Counter]</b>	Required. This is the controlling statement. The result of evaluating the variable is used as a test of comparison.
<b>&lt;StartValue&gt;</b>	Required. The initial value of [Counter]
<b>to/down</b>	Required. This determines if the <step> increments or decrements the <Counter>. “to” increments <Counter> by <StepValue>. “down” decrements <Counter> by <StepValue>.
<b>&lt;EndValue&gt;</b>	Required. The test point. If the <Counter> is greater than this value, the macro

	exists the loop.
<b>step</b>	Optional. Specifies that a <StepValue> other than one is to be used.
<b>[StepValue]</b>	Optional. The increment/decrement step of <Counter>. It can be omitted when the value is 1. If [step <StepValue>] are omitted the step value defaults to 1.
<b>[Statements]</b>	Statements to execute when the evaluation is TRUE. “for-next” loops may be nested.
<b>next</b>	Required.
<b>[Counter]</b>	Optional. This is used when nesting for-next loops.

### 18.3.4.2 while-wend Statements

The while-wend construction is for stepping through an unknown number of iterations. A variable is used to test for ending conditions. When the condition is TRUE, the statements are executed repetitively until the condition becomes FALSE. The syntax is as follows.

```

while <Condition>
    [Statements]
wend

```

Example:

```

while a < 10
    a = a + 10
wend

```

Syntax description:

<b>while</b>	Must be used to begin the statement
<b>continue</b>	Required. This is the controlling statement. When it is TRUE, the loop begins execution. When it is FALSE, the loop terminates.
<b>return [value]</b>	Statements to execute when the evaluation is TRUE.
<b>wend</b>	Indicates the end of the while-end statements

### 18.3.4.3 Other Control Commands

<b>break</b>	Used in for-next and while-wend. It skips immediately to the end of the
--------------	---

	statement.
<b>continue</b>	Used in for-next and while-wend. It ends the current iteration of a loop and starts the next one.

## 18.4 Function Blocks

Function blocks are useful for reducing repetitive codes, must be defined before use and can use any variable and statement type. A function block is called by putting its name followed by parameters, in parenthesis, in the Main Macro Function. After the function block is executed, it returns the value to the Main Function where it is used as an assignment or condition. The syntax is as follows:

```

sub type <name> [(parameters)]
    Local variable declarations
    [Statements]
    [return [value]]
end sub

```

Example:

```

sub int Add(int x, int y)
    int result
    result = x +y
    return result
end sub

macro_command main()
    int  a = 10, b = 20, sum
    sum = Add(a, b)
end macro_command

```

Syntax description:

<b>sub</b>	Must be used to begin the function block
<b>type</b>	Required. This is the data type of value that the function returns.
<b>(parameters)</b>	Optional. The parameters hold values that are passed to the function by the Main Macro. The passed parameters must have their type declared in the parameter field and assigned a variable name. For example: sub int MyFunction(int x, int y). x and y would be integers

	<p>passed to the function by the Main Macro. This function is called by a statement that looks similar to this: <code>ret = MyFunction(456, pressure)</code></p> <p>Notice that the calling statement can pass hard coded values or variables to the function. After this function is executed, an integer values is return to 'ret'.</p>
<b>Local variable declaration</b>	<p>Variables that are used in the function block must be declared first. This is in addition to passed parameters. In the above example x and y are variables that the function can used. Global variables are also available for use in function block.</p>
<b>[Statements]</b>	<p>Statements to execute</p>
<b>[return [value]]</b>	<p>Used to return a value to the calling statement. The value can be a constant or a variable. Return also ends function block execution.</p>
<b>end sub</b>	<p>Must be used to end a function block.</p>

## 18.5 Build-In Function Block

EasyBuilder8000 has some build-in functions for retrieving and transferring data to the PLC, data management and mathematical functions.

### 18.5.1 Mathematical Functions

<b>Name</b>	SQRT
<b>Syntax</b>	SQRT(source, result)
<b>Description</b>	<p>Calculate the square root of source into result.</p> <p>source can be a constant or a variable, but result must be a variable.</p> <p>source must be a nonnegative value.</p>
<b>Example</b>	<pre>macro_command main() float source, result  SQRT(15, result)  source = 9.0 SQRT(source, result)// result is 3.0</pre>

	end macro_command
--	-------------------

<b>Name</b>	SIN
<b>Syntax</b>	SIN(source, result)
<b>Description</b>	Calculate the sine of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	macro_command main() float source, result  SIN(90, result)// result is 1  source = 30 SIN(source, result)// result is 0.5  end macro_command

<b>Name</b>	COS
<b>Syntax</b>	COS(source, result)
<b>Description</b>	Calculate the cosine of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	macro_command main() float source, result  COS(90, result)// result is 0  source = 60 GetData(source, "Local HMI", LW, 0, 1) COS(source, result)// result is 0.5  end macro_command

<b>Name</b>	TAN
<b>Syntax</b>	TAN(source, result)
<b>Description</b>	Calculate the tangent of source into result. source can be a constant or a variable, but result must be a variable.

<b>Example</b>	<pre>macro_command main() float source, result  TAN(45, result)// result is 1  source = 60 TAN(source, result)// result is 1.732  end macro_command</pre>
----------------	---

<b>Name</b>	COT
<b>Syntax</b>	COT(source, result)
<b>Description</b>	Calculate the cotangent of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() float source, result  COT(45, result)// result is 1  source = 60 COT(source, result)// result is 0.5774  end macro_command</pre>

<b>Name</b>	SEC
<b>Syntax</b>	SEC(source, result)
<b>Description</b>	Calculate the secant of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() float source, result  SEC(45, result)// result is 1.414  source = 60 SEC(source, result)// if source is 60, result is 2</pre>

	end macro_command
--	-------------------

<b>Name</b>	CSC
<b>Syntax</b>	CSC(source, result)
<b>Description</b>	Calculate the cosecant of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	macro_command main() float source, result  CSC(45, result)// result is 1.414  source = 30 CSC(source, result)// result is 2  end macro_command

<b>Name</b>	ASIN
<b>Syntax</b>	ASIN(source, result)
<b>Description</b>	Calculate the hyperbolic sine of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	macro_command main() float source, result  ASIN(0.8660, result)// result is 60  source = 0.5 ASIN(source, result)// result is 30  end macro_command

<b>Name</b>	ACOS
<b>Syntax</b>	ACOS(source, result)
<b>Description</b>	Calculate the hyperbolic cosine of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	macro_command main()

	<pre>float source, result  ACOS(0.8660, result)//  result is 30  source = 0.5 ACOS(source, result)//  result is 60  end macro_command</pre>
--	---

<b>Name</b>	ATAN
<b>Syntax</b>	ATAN(source, result)
<b>Description</b>	Calculate the hyperbolic tangent of source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() float source, result  ATAN(1, result)//  result is 45  source = 1.732 ATAN(source, result)//  result is 60  end macro_command</pre>

<b>Name</b>	RAND
<b>Syntax</b>	RAND(result)
<b>Description</b>	Calculates a random integer saved into result. result must be a variable.
<b>Example</b>	<pre>macro_command main() short result  RAND (result)//  result is not a fixed value when executes macro every time  end macro_command</pre>

## 18.5.2 Data Transformation

<b>Name</b>	BIN2BCD
<b>Syntax</b>	BIN2BCD(source, result)
<b>Description</b>	Transforms a binary-type value (source) into a BCD-type value (result). source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main()  short source, result  BIN2BCD(1234, result)//  result is 0x1234  source = 5678 BIN2BCD(source, result)//  result is 0x5678  end macro_command</pre>

<b>Name</b>	BCD2BIN
<b>Syntax</b>	BIN2BCD(source, result)
<b>Description</b>	Transforms a BCD-type value (source) into a binary-type value (result). source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main()  short source, result  BCD2BIN(0x1234, result)//  result is 1234  source = 0x5678 BCD2BIN(source, result)//  result is 5678  end macro_command</pre>

<b>Name</b>	DEC2ASCII
<b>Syntax</b>	DEC2ASCII(source, result[start], len)
<b>Description</b>	Transforms a decimal value (source) into ASCII string saved to an array (result). len represents the length of the string and the unit of length depends on result's

	<p>type., i.e. if result's type is "char" (the size is byte), the length of the string is (byte * len). If result's type is "short" (the size is word), the length of the string is (word * len), and so on.</p> <p>The first character is put into result[start], the second character is put into result[start + 1], and the last character is put into result[start + (len - 1)].</p> <p>source and len can be a constant or a variable, but result must be a variable. start must be a constant.</p>
<b>Example</b>	<pre>macro_command main() short source char result1[4] short result2[4]  source = 5678 DEC2ASCII(source, result1[0], 4) // result1[0] is '5', result1[1] is '6', result1[2] is '7', result1[3] is '8' // the length of the string (result1) is 4 bytes( = 1 * 4)  DEC2ASCII(source, result2[0], 4) // result2[0] is '5', result2[1] is '6', result2[2] is '7', result2[3] is '8' // the length of the string (result2) is 8 bytes( = 2 * 4)  end macro_command</pre>

<b>Name</b>	HEX2ASCII
<b>Syntax</b>	HEX2ASCII(source, result[start], len)
<b>Description</b>	<p>Transforms a hexadecimal value (source) into ASCII string saved to an array (result).</p> <p>len represents the length of the string and the unit of length depends on result's type., i.e. if result's type is "char" (the size is byte), the length of the string is (byte * len). If result's type is "short" (the size is word), the length of the string is (word * len), and so on.</p> <p>source and len can be a constant or a variable, but result must be a variable. start must be a constant.</p>
<b>Example</b>	<pre>macro_command main() short source char result[4]</pre>

	<pre> source = 0x5678 DEC2ASCII(source, result[0], 4) //  result[0] is '5', result[1] is '6', result[2] is '7', result[3] is '8'  end macro_command </pre>
--	--

<b>Name</b>	ASCII2DEC
<b>Syntax</b>	ASCII2DEC(source[start], result, len)
<b>Description</b>	<p>Transforms a string (source) into a decimal value saved to a variable (result). The length of the string is len. The first character of the string is source[start]. source and len can be a constant or a variable, but result must be a variable. start must be a constant.</p>
<b>Example</b>	<pre> macro_command main() char source[4] short result  source[0] = '5' source[1] = '6' source[2] = '7' source[3] = '8'  ASCII2DEC(source[0], result, 4) //  result is 5678  end macro_command </pre>

<b>Name</b>	ASCII2HEX
<b>Syntax</b>	ASCII2HEX (source[start], result, len)
<b>Description</b>	<p>Transforms a string (source) into a hexadecimal value saved to a variable (result). The length of the string is len. The first character of the string is source[start]. source and len can be a constant or a variable, but result must be a variable. start must be a constant.</p>
<b>Example</b>	<pre> macro_command main() char source[4] short result </pre>

	<pre> source[0] = '5' source[1] = '6' source[2] = '7' source[3] = '8'  ASCII2DEC(source[0], result, 4) // result is 0x5678  end macro_command </pre>
--	--

### 18.5.3 Data Manipulation

<b>Name</b>	FILL
<b>Syntax</b>	FILL(source[start], preset, count)
<b>Description</b>	Sets the first count elements of an array (source) to a specified value (preset). source and start must be a variable, and preset can be a constant or variable.
<b>Example</b>	<pre> macro_command main() char result[4] char preset  FILL(result[0], 0x30, 4) // result[0] is 0x30, result[1] is 0x30, , result[2] is 0x30, , result[3] is 0x30  preset = 0x31 FILL(result[0], preset, 2) // result[0] is 0x31, result[1] is 0x31  end macro_command </pre>

<b>Name</b>	SWAPB
<b>Syntax</b>	SWAPB(source, result)
<b>Description</b>	Exchanges the high-byte and low-byte data of a 16-bit source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre> macro_command main() short source, result  SWAPB(0x5678, result)// result is 0x7856 </pre>

	<pre> source = 0x123 SWAPB(source, result)//  result is 0x2301  end macro_command </pre>
--	--

<b>Name</b>	SWAPW
<b>Syntax</b>	SWAPW(source, result)
<b>Description</b>	Exchanges the high-word and low-word data of a 32-bit source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre> macro_command main() int source, result  SWAPB(0x12345678, result)//  result is 0x78561234  source = 0x12345 SWAPB(source, result)//  result is 0x23450001  end macro_command </pre>

<b>Name</b>	LOBYTE
<b>Syntax</b>	LOBYTE(source, result)
<b>Description</b>	Retrieves the low byte of a 16-bit source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre> macro_command main() short source, result  LOBYTE(0x1234, result)//  result is 0x34  source = 0x123 LOBYTE(source, result)//  result is 0x23  end macro_command </pre>

<b>Name</b>	HIBYTE
<b>Syntax</b>	HIBYTE(source, result)
<b>Description</b>	Retrieves the high byte of a 16-bit source into result.

	source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() short source, result  HIBYTE(0x1234, result)//  result is 0x12  source = 0x123 HIBYTE(source, result)//  result is 0x01  end macro_command</pre>

<b>Name</b>	LOWORD
<b>Syntax</b>	LOWORD(source, result)
<b>Description</b>	Retrieves the low word of a 32-bit source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() int source, result  LOWORD(0x12345678, result)//  result is 0x5678  source = 0x12345 LOWORD(source, result)//  result is 0x2345  end macro_command</pre>

<b>Name</b>	HIWORD
<b>Syntax</b>	HIWORD(source, result)
<b>Description</b>	Retrieves the high word of a 32-bit source into result. source can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() int source, result  HIWORD(0x12345678, result)//  result is 0x1234  source = 0x12345 HIWORD(source, result)//  result is 0x0001</pre>

	end macro_command
--	-------------------

### 18.5.4 Bit Transformation

<b>Name</b>	GETBIT
<b>Syntax</b>	GETBIT(source, result, bit_pos)
<b>Description</b>	Gets the state of designated bit position of a data (source) into result. result's value will be 0 or 1. source and bit_pos can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() int source, result short bit_pos  GETBIT(9, result, 3)// result is 1  source = 4 bit_pos = 2 GETBIT(source, result, bit_pos)// result is 1  end macro_command</pre>

<b>Name</b>	SETBITON
<b>Syntax</b>	SETBITON(source, result, bit_pos)
<b>Description</b>	Changes the state of designated bit position of a data (source) to 1, and pus in changed data into result. source and bit_pos can be a constant or a variable, but result must be a variable.
<b>Example</b>	<pre>macro_command main() int source, result short bit_pos  SETBITON(1, result, 3)// result is 9  source = 0 bit_pos = 2</pre>

	<pre>SETBITON (source, result, bit_pos)//  result is 4  end macro_command</pre>
--	---

<b>Name</b>	SETBITOFF
<b>Syntax</b>	SETBITOFF(source, result, bit_pos)
<b>Description</b>	<p>Changes the state of designated bit position of a data (source) to 0, and put in changed data into result.</p> <p>source and bit_pos can be a constant or a variable, but result must be a variable.</p>
<b>Example</b>	<pre>macro_command main() int source, result short bit_pos  SETBITOFF(9, result, 3)//  result is 1  source = 4 bit_pos = 2 SETBITFF(source, result, bit_pos)//  result is 0  end macro_command</pre>

<b>Name</b>	INVBIT
<b>Syntax</b>	INVBIT(source, result, bit_pos)
<b>Description</b>	<p>Inverts the state of designated bit position of a data (source), and put in changed data into result.</p> <p>source and bit_pos can be a constant or a variable, but result must be a variable.</p>
<b>Example</b>	<pre>macro_command main() int source, result short bit_pos  INVBIT(4, result, 1)//  result = 6  source = 6 bit_pos = 1 INVBIT(source, result, bit_pos)//  result = 4</pre>

	end macro_command
--	-------------------

### 18.5.5 Communication

<b>Name</b>	DELAY
<b>Syntax</b>	DELAY(time)
<b>Description</b>	Suspends the execution of the current macro for at least the specified interval (time). The unit of time is millisecond). time can be a constant or a variable.
<b>Example</b>	macro_command main() int time == 500  DELAY(100)// delay 100 ms DELAY(time)// delay 500 ms  end macro_command

<b>Name</b>	DELAY
<b>Syntax</b>	DELAY(time)
<b>Description</b>	Suspends the execution of the current macro for at least the specified interval (time). The unit of time is millisecond). time can be a constant or a variable.
<b>Example</b>	macro_command main() int time == 500  DELAY(100)// delay 100 ms DELAY(time)// delay 500 ms  end macro_command


<b>Name</b>	ADDSUM
<b>Syntax</b>	ADDSUM(source[start], result, data_count)
<b>Description</b>	Adds up the elements of an array (source) from source[start] to source[start + data_count - 1] to generate a checksum.

	<p>Puts in the checksum into result. result must be a variable.</p> <p>data_count is the amount of the accumulated elements and can be a constant or a variable.</p>
<b>Example</b>	<pre>macro_command main() char data[5] short checksum  data[0] = 0x1 data[1] = 0x2 data[2] = 0x3 data[3] = 0x4 data[4] = 0x5  ADDSUM(data[0], checksum, 5)// checksum is 0xf  end macro_command</pre>

<b>Name</b>	XORSUM
<b>Syntax</b>	XORSUM(source[start], result, data_count)
<b>Description</b>	<p>Uses an exclusion method to calculate the checksum from source[start] to source[start + data_count - 1].</p> <p>Puts in the checksum into result. result must be a variable.</p> <p>data_count is the amount of the calculated elements of the array and can be a constant or a variable.</p>
<b>Example</b>	<pre>macro_command main() char data[5] = {0x1, 0x2, 0x3, 0x4, 0x5} short checksum  XORSUM(data[0], checksum, 5)// checksum is 0x1  end macro_command</pre>

<b>Name</b>	CRC
<b>Syntax</b>	CRC(source[start], result, data_count)
<b>Description</b>	<p>Calculates 16-bit CRC of the variables from source[start] to source[start + count - 1].</p>

	<p>Puts in the 16-bit CRC into result. result must be a variable.  data_count is the amount of the calculated elements of the array and can be a constant or a variable.</p>
<b>Example</b>	<pre>macro_command main() char data[5] = {0x1, 0x2, 0x3, 0x4, 0x5} short 16bit_CRC  CRC(data[0], 16bit_CRC, 5)// 16bit_CRC is 0xbb2a  end macro_command</pre>

<b>Name</b>	OUTPORT															
<b>Syntax</b>	OUTPORT(source[start], device_name, data_count)															
<b>Description</b>	<p>Sends out the specified data from source[start] to source[start + count -1] to PLC via a COM port or the ethernet.  device_name is the name of a device defined in the device table and the device must be a “Free Protocol”-type device.  data_count is the amount of sent data and can be a constant or a variable.</p>															
<b>Example</b>	<p>To use an OUTPORT function, a “Free Protocol” device must be created first as follows:</p>  <p>The screenshot shows two dialog boxes. The top one is 'System Parameter Settings' with a 'Device list' table:</p> <table border="1"> <thead> <tr> <th>No.</th> <th>Name</th> <th>Location</th> <th>Device type</th> <th>Interface</th> </tr> </thead> <tbody> <tr> <td>Local HMI</td> <td>Local HMI</td> <td>Local</td> <td>MT8121T (800 x 600)</td> <td>Disable</td> </tr> <tr> <td>Local PLC 1</td> <td>MODBUS RTU Device</td> <td>Local</td> <td>Free Protocol</td> <td>COM1(19200,E,8,1)</td> </tr> </tbody> </table> <p>The bottom dialog is 'Device Properties' for 'MODBUS RTU Device'. It shows:</p> <ul style="list-style-type: none"> <li>Name: MODBUS RTU Device</li> <li>Radio buttons: HMI (unselected), PLC (selected)</li> <li>Location: Local</li> <li>PLC type: Free Protocol (circled in red)</li> <li>Version: V.1.00, FREE_PROTOCOL.so</li> <li>PLC I/F: RS-232</li> <li>COM: COM1 (19200,E,8,1)</li> </ul>	No.	Name	Location	Device type	Interface	Local HMI	Local HMI	Local	MT8121T (800 x 600)	Disable	Local PLC 1	MODBUS RTU Device	Local	Free Protocol	COM1(19200,E,8,1)
No.	Name	Location	Device type	Interface												
Local HMI	Local HMI	Local	MT8121T (800 x 600)	Disable												
Local PLC 1	MODBUS RTU Device	Local	Free Protocol	COM1(19200,E,8,1)												

	<p>The device is named "MODBUS RTU Device". The port attribute depends on the setting of this device. (the current setting is "19200,E, 8, 1")</p> <p>Below is an example of executing an action of writing single coil (SET ON) to a MODBUS device.</p> <pre> macro_command main()  char command[32] short address, checksum  FILL(command[0], 0, 32)//  command initialization  command[0] = 0x1//  station no command[1] = 0x5//  function code : Write Single Coil  address = 0 HIBYTE(address, command[2]) LOBYTE(address, command[3])  command[4] = 0xff//  force bit on command[5] = 0  CRC(command[0], checksum, 6)  LOBYTE(checksum, command[6]) HIBYTE(checksum, command[7])  //  send out a "Write Single Coil" command OUTPORT(command[0], "MODBUS RTU Device", 8)  end macro_command </pre>
--	--

<b>Name</b>	INTPORT
<b>Syntax</b>	INPORT(read_data[start], device_name, read_count, return_value)
<b>Description</b>	Reads data from a COM port or the ethernet. These data is stored to read_data[start]~ read_data[start + read_count - 1].

	<p>device_name is the name of a device defined in the device table and the device must be a “Free Protocol”-type device.</p> <p>read_count is the required amount of reading and can be a constant or a variable.</p> <p>If the function is used successfully to get sufficient data, return_value is 1, otherwise is 0.</p>
<b>Example</b>	<p>Below is an example of executing an action of reading holding registers of a MODBUS device.</p> <pre> // Read Holding Registers macro_command main() char command[32], response[32] short address, checksum short read_no, return_value, read_data[2]  FILL(command[0], 0, 32)// command initialization FILL(response[0], 0, 32)  command[0] = 0x1// station no command[1] = 0x3// function code : Read Holding Registers  address = 0 HIBYTE(address, command[2]) LOBYTE(address, command[3])  read_no = 2// read 2 words (4x_1 and 4x_2) HIBYTE(read_no, command[4]) LOBYTE(read_no, command[5])  CRC(command[0], checksum, 6)  LOBYTE(checksum, command[6]) HIBYTE(checksum, command[7])  // send out a ‘Read Holding Registers’ command OUTPORT(command[0], "MODBUS RTU Device", 8)  // read responses for a ‘Read Holding Registers’ command INPORT(response[0], "MODBUS RTU Device", 9, return_value) </pre>

	<pre> if return_value &gt; 0 then   read_data[0] = response[4] + (response[3] &lt;&lt; 8)//  data in 4x_1   read_data[1] = response[6] + (response[5] &lt;&lt; 8)//  data in 4x_2    SetData(read_data[0], "Local HMI", LW, 100, 2) end if  end macro_command </pre>
--	--

<b>Name</b>	GetData
<b>Syntax</b>	<pre> GetData(read_data[start], device_name, device_type, address_offset, data_count) or GetData(read_data, device_name, device_type, address_offset, 1) </pre>
<b>Description</b>	<p>Receives data from the PLC. Data is stored into read_data[start]~ read_data[start + data_count - 1].</p> <p>data_count is the amount of received data. In general, read_data is an array, but if data_count is 1, read_data can be an array or an ordinary variable. Below are two methods to read one word data.</p> <pre> macro_command main() short read_data_1[2], read_data_2 GetData(read_data_1[0], "FATEK KB Series", RT, 5, 1) GetData(read_data_2, "FATEK KB Series", RT, 5, 1) end macro_command </pre> <p>device_name is the PLC name enclosed in the double quotation marks (“”) and this name has been defined in the device list of system parameters as follows (see FATEK KB Series):</p>

Name	Location	Device Type	Stat...	I/F	Port
Local HMI	Local	MT8xxx	N/A	N/A	N/A
Remote HMI A	Remote(IP:192.168.0.205, Port...	MT8xxx	N/A	N/A	N/A
Remote HMI B	Remote(IP:210.68.117.224, Po...	MT8xxx	N/A	N/A	N/A
Remote HMI C	Remote(IP:210.68.117.224, Po...	MT8xxx	N/A	N/A	N/A
MITSUBISHI FX0n (Local)	Local	MITSUBISHI FX...	0	RS...	COM
FATEK (Local)	Local	FATEK FB Series	1	RS...	COM
MITSUBISHI FX3u	Remote(IP:210.68.117.224, Po...	MITSUBISHI FX...	0	RS...	COM
FATEK FB Series	Remote(IP:210.68.117.224, Po...	FATEK FB Series	1	RS...	COM

device\_type is the device type and encoding method (binary or BCD) of the PLC data. For example, if device\_type is LW\_BIN, it means the register is LW and the encoding method is binary. If use BIN encoding method, “\_BIN” can be ignored.

If device\_type is LW\_BCD, it means the register is LW and the encoding method is BCD.

address\_offset is the address offset in the PLC.

For example, GetData(read\_data\_1[0], “FATEK KB Series”, RT, 5, 1) represents that the address is 5.

If address\_offset uses the format – “N#AAAAA”, N indicates that PLC’s station number is N. For example, GetData(read\_data\_1[0], “FATEK KB Series”, RT, 2#5, 1) represents that the PLC’s station number is 2. If GetData() uses the default station number defined in the device list as follows, it is not necessary to define station number in address\_offset.

The number of registers actually read from depends on both the type of the read\_data variable and the value of the number of data\_count.

type of read_data	data_count	actual number of 16-bit register read
char (8-bit)	1	1
char (8-bit)	2	1
bool (8-bit)	1	1
bool (8-bit)	2	1
short (16-bit)	1	1
short (16-bit)	2	2
int (32-bit)	1	2
int (32-bit)	2	4
float (32-bit)	1	2
float (32-bit)	2	4

When a GetData() is executed using a 32-bit data type (int or float), the function will automatically convert the data. For example,

```
macro_command main()
float f
GetData(f, "MODBUS", 6x, 2, 1) // f will contain a floating point value
end macro_command
```

**Example**

```
macro_command main()
bool a
bool b[30]
short c
short d[50]
int e
int f[10]
double g[10]

// get the state of LB2 to the variable
GetData(a, "Local HMI", LB, 2, 1)

// get 30 states of LB0 ~ LB29 to the variables b[0] ~ b[29]
GetData(b[0], "Local HMI", LB, 0, 30)
```

```

// get one word from LW2 to the variable c
GetData(c, "Local HMI", LW, 2, 1)

// get 50 words from LW0 ~ LW49 to the variables d[0] ~ d[49]
GetData(d[0], "Local HMI", LW, 0, 50)

// get 2 words from LW6 ~ LW7 to the variable e
// note that the type of e is int
GetData(e, "Local HMI", LW, 6, 1)

// get 20 words (10 integer values) from LW0 ~ LW19 to f[0] ~ f[9]
// since each integer value occupies 2 words
GetData(f[0], "Local HMI", LW, 0, 10)

// get 2 words from LW2 ~ LW3 to the variable f
GetData(f, "Local HMI", LW, 2, 1)

end macro_command

```

<b>Name</b>	SetData
<b>Syntax</b>	SetData(send_data[start], device_name, device_type, address_offset, data_count) or SetData(send_data, device_name, device_type, address_offset, 1)
<b>Description</b>	<p>Send data to the PLC. Data is defined in send_data[start]~ send_data[start + data_count - 1].</p> <p>data_count is the amount of sent data. In general, send_data is an array, but if data_count is 1, send_data can be an array or an ordinary variable. Below are two methods to send one word data.</p> <pre> macro_command main() short send_data_1[2] = { 5, 6}, send_data_2 = 5 SetData(send_data_1[0], "FATEK KB Series", RT, 5, 1) SetData(send_data_2, "FATEK KB Series", RT, 5, 1) end macro_command </pre> <p>device_name is the PLC name enclosed in the double quotation marks ("") and this</p>

name has been defined in the device list of system parameters.

device\_type is the device type and encoding method (binary or BCD) of the PLC data. For example, if device\_type is LW\_BIN, it means the register is LW and the encoding method is binary. If use BIN encoding method, “\_BIN” can be ignored.

If device\_type is LW\_BCD, it means the register is LW and the encoding method is BCD.

address\_offset is the address offset in the PLC.

For example, SetData(read\_data\_1[0], “FATEK KB Series”, RT, 5, 1) represents that the address is 5.

If address\_offset uses the format – “N#AAAAA”, N indicates that PLC’s station number is N. For example, SetData(read\_data\_1[0], “FATEK KB Series”, RT, 2#5, 1) represents that the PLC’s station number is 2. If GetData() uses the default station number defined in the device list, it is not necessary to define station number in address\_offset.

The number of registers actually sends to depends on both the type of the send\_data variable and the value of the number of data\_count.

<b>type of read_data</b>	<b>data_count</b>	<b>actual number of 16-bit register send</b>
char (8-bit)	1	1
char (8-bit)	2	1
bool (8-bit)	1	1
bool (8-bit)	2	1
short (16-bit)	1	1
short (16-bit)	2	2
int (32-bit)	1	2
int (32-bit)	2	4
float (32-bit)	1	2
float (32-bit)	2	4

When a SetData() is executed using a 32-bit data type (int or float), the function will automatically send int-format or float-format data to the device. For example,

	<pre>macro_command main() float f = 2.6 SetData(f, "MODBUS", 6x, 2, 1) // will send a floating point value to the device end macro_command</pre>
<b>Example</b>	<pre>macro_command main() int i bool a = true bool b[30] short c = false short d[50] int e = 5 int f[10]  for i = 0 to 29   b[i] = true next i  for i = 0 to 49   d[i] = i * 2 next i  for i = 0 to 9   f[i] = i * 3 next i  // set the state of LB2 SetData(a, "Local HMI", LB, 2, 1)  // set the states of LB0 ~ LB29 SetData(b[0], "Local HMI", LB, 0, 30)  // set the value of LW2 SetData(c, "Local HMI", LW, 2, 1)  // set the values of LW0 ~ LW49 SetData(d[0], "Local HMI", LW, 0, 50)</pre>

```
// set the values of LW6 ~ LW7, note that the type of e is int
SetData(e, "Local HMI", LW, 6, 1)

// set the values of LW0 ~ LW19
// 10 integers are equal to 20 words, since each integer value occupies 2 words.
SetData(f[0], "Local HMI", LW, 0, 10)

end macro_command
```

## 18.6 How to Create and Execute a Macro


### 18.6.1 How to Create a Macro

Macro programming can be divided into some steps as follows,

#### Step 1:

Click the "Macro Manager" icon on the tool bar of EasyBuilder 8000 to open Macro Manager as follows.





On Macro Manager, all macros compiled successfully are displayed in “Macro list”, and all macros in developing are display in ‘Macro under development’. The following is a description of the various buttons.

**[New]**

Opens a blank “WorkSpace” editor for creating a new macro.

**[Delete]**

Deletes the selected macro.

**[Edit]**

Opens the “WorkSpace” editor, and loads the selected macro.

**[Copy]**


Copies the selected macro into the clipboard.

**[Paste]**

Pastes the macro in the clipboard into the list, and creates a new name for the macro.

**Step 2:**

Press the “New” button to open a blank “WorkSpace” editor. Every macro has a unique number defined in “Macro ID” edit box, and macro name must exist, otherwise an error will appear while compiling.



**Step 3:**

Design your macro. If it is necessary to use build-in functions (like SetData() or Getdata()), press ‘Get/Set FN...’ button to open API dialog and select the function and set essential parameters.

API

Function name :

Variable 1

Variable type :

Variable :       Array index :

Read address

PLC name :

Device type :

Address :

Address format : ddddd [range : 0 ~ 10255]

     Data count :

[Description]  
Read data from a device.


[Usage]  
GetData(desti, PLC name, device type, address, data count)

[Example]  
char byData[10]


    

**Step 4:**

After the completion of a new macro, press ‘Compile’ button to compile the macro.



If there is no error, press “Exit” button and find that a new macro “macro\_test” exists in “Macro list”.



## 18.6.2 Execute a Macro

There are several ways to execute a macro.

- a. With a PLC Control object
  1. Open the PLC Control object and set the attribute to “Execute macro program”.
  2. Select the macro by name. Choose a bit and select a trigger condition to trigger the macro. The macro will continue to be re-triggered as long as the condition is met. In order to guarantee that the macro will run only once, consider latching the trigger bit, and then resetting the trigger condition within the macro.
  3. Use a [Set Bit](#) or [Toggle Switch](#) object to activate the bit.
  
- b. With a Set Bit or Toggle Switch object
  1. On the General tab of the Set Bit or Toggle Switch dialog, select the Execute Macro option.
  2. Select the macro to execute. The macro will execute one time when the button is activated.
  
- c. With a Function Key object
  1. On the General tab of the Set Bit or Toggle Switch dialog, select the Execute Macro option.
  2. Select the macro to execute. The macro will execute one time when the button is activated.

## 18.7 Some Notes about Using the Macro

1. The maximum storage space of local variables in a macro is 4K bytes. So the maximum array size of different variable types are as follows:

```
char a[4096]
bool b[4096]
short c[2048]
int d[1024]
float e[1024]
```


2. A maximum of 256 macros are allowed in an EasyBuilder 8000 project.

3. A macro may cause the HMI to lock up. Possible causes are:
  - A macro contains an infinite loop with no PLC communication.
  - The size of an array exceeds the storage space in a macro.
4. PLC communication time may cause the macro to execute slower than expected.


## 18.8 Use the Free Protocol to Control a Device

When EasyBuilder 8000 does not provide an essential driver to communication with a device, Users also can make use of OUTPORT and INPORT to control the device. The data sent with OUTPORT and INPORT must follow the device’s communication protocol. The following example explains how to use these two functions to control a MODBUS RTU device.

First, create a new device in the device table. The device type of the new device is set to “Free Protocol” and named with “MODBUS RTU device” as follows:



The interface of the device (PLC I/F) uses “RS-232” now. If connecting a MODBUS TCP/IP device, the interface must select ‘Ethernet’. In addition, it is necessary to set correct IP and port number as follows:



Suppose that HMI will read the data of 4x\_1 and 4x\_2 on the device. First, utilize OUTPORT to send out a read request to the device. The prototype of OUTPORT is:

OUTPORT(command[start], device\_name, cmd\_count)

Because “MODBUS RTU device” is a MODBUS RTU device, the read request must follow MODBUS RTU protocol. The request uses ”Reading Holding Registers (0x03)” command to read data. The following picture displays the content of the command. (The items of the station number (byte 0) and the last two bytes (CRC) are ignored).

**Request**

Function code	1 Byte	0x03
Starting Address	2 Bytes	0x0000 to 0xFFFF
Quantity of Registers	2 Bytes	1 to 125 (0x7D)

**Response**

Function code	1 Byte	0x03
Byte count	1 Byte	2 x N*
Register value	N* x 2 Bytes	

\*N = Quantity of Registers

**Error**

Error code	1 Byte	0x83
Exception code	1 Byte	01 or 02 or 03 or 04

Depending on the protocol, the content of a read command as follows (The total bytes are 8):

- command[0] : station number (BYTE 0)
- command[1] : function code (BYTE 1)
- command[2] : high byte of starting address (BYTE 2)
- command[3] : low byte of starting address (BYTE 3)
- command[4] : high byte of quantity of registers (BYTE 4)
- command[5] : low byte of quantity of registers (BYTE 5)
- command[6] : low byte of 16-bit CRC (BYTE 6)

command[7] : high byte of 16-bit CRC (BYTE 7)

So a read request is designed as follows :

```
char command[32]
```

```
short address, checksum
```

```
FILL(command[0], 0, 32) // initialize command[0]~command[31] to 0
```

```
command[0] = 0x1 // station number
```

```
command[1] = 0x3 // read holding registers (function code is 0x3)
```

```
address = 0// starting address (4x_1) is 0
```

```
HIBYTE(address, command[2])
```

```
LOBYTE(address, command[3])
```

```
read_no = 2// the total words of reading is 2 words
```

```
HIBYTE(read_no, command[4])
```

```
LOBYTE(read_no, command[5])
```

```
CRC(command[0], checksum, 6)// calculate 16-bit CRC
```

```
LOBYTE(checksum, command[6])
```

```
HIBYTE(checksum, command[7])
```

Finally, use OUPORT to send out this read request to PLC

```
OUTPORT(command[0], "MODBUS RTU Device", 8)// send request
```

After sending out the request, use INPORT to get the response from PLC. Depending on the protocol, the content of the response is as follows (the total byte is 9):

command[0] : station number (BYTE 0)

command[1] : function code (BYTE 1)

command[2] : byte count (BYTE 2)

command[3] : high byte of 4x\_1 (BYTE 3)

command[4] : low byte of 4x\_1 (BYTE 4)

command[5] : high byte of 4x\_2 (BYTE 5)

command[6] : high byte of 4x_2	(BYTE 6)
command[7] : low byte of 16-bit CRC	(BYTE 7)
command[8] : high byte of 16-bit CRC	(BYTE 8)

The usage of INPORT is described below:

```
INPORT(response[0], "MODBUS RTU Device", 9, return_value)// read response
```

Where the real read count is restored to the variable return\_value (unit is byte). If return\_value is 0, it means reading fails in executing INPORT.

Depending on the protocol, response[1] must be equal to 0x3, if the response is correct. After getting correct response, calculate the data of 4x\_1 and 4x\_2 and put in the data into LW100 and LW101.

```
if (return_value >0 and response[1] == 0x3) then
  read_data[0] = response[4] + (response[3] << 8)// 4x_1
  read_data[1] = response[6] + (response[5] << 8)// 4x_2
```

```
  SetData(read_data[0], "Local HMI", LW, 100, 2)
end if
```

**The complete macro is as follows:**

```
// Read Holding Registers
macro_command main()

char command[32], response[32]
short address, checksum
short read_no, return_value, read_data[2], i

FILL(command[0], 0, 32)// initialize command[0]~command[31] to 0
FILL(response[0], 0, 32)

command[0] = 0x1// station number
command[1] = 0x3// read holding registers (function code is 0x3)

address = 0
address = 0// starting address (4x_1) is 0
```

```

HIBYTE(address, command[2])
LOBYTE(address, command[3])

read_no = 2/  the total words of reading is 2 words
HIBYTE(read_no, command[4])
LOBYTE(read_no, command[5])

CRC(command[0], checksum, 6)//  calculate 16-bit CRC

LOBYTE(checksum, command[6])
HIBYTE(checksum, command[7])

OUTPORT(command[0], "MODBUS RTU Device", 8 )//  send request
INPORT(response[0], "MODBUS RTU Device", 9, return_value)//  read response

if (return_value > 0 and response[1] == 0x3) then
  read_data[0] = response[4] + (response[3] << 8)//  4x_1
  read_data[1] = response[6] + (response[5] << 8)//  4x_2

  SetData(read_data[0], "Local HMI", LW, 100, 2)
end if

end macro_command

```

The following example explains how to design a request to set the status of 0x\_1. The request uses "Write Single Coil(0x5)" command.

### Request

Function code	1 Byte	<b>0x05</b>
Output Address	2 Bytes	0x0000 to 0xFFFF
Output Value	2 Bytes	0x0000 or 0xFF00

### Response

Function code	1 Byte	<b>0x05</b>
Output Address	2 Bytes	0x0000 to 0xFFFF
Output Value	2 Bytes	0x0000 or 0xFF00

### Error

Error code	1 Byte	<b>0x85</b>
Exception code	1 Byte	01 or 02 or 03 or 04

**The complete macro is as follows:**

```
// Write Single Coil (ON)
macro_command main()

char command[32], response[32]
short address, checksum
short i, return_value

FILL(command[0], 0, 32)// initialize command[0]~ command[31] to 0
FILL(response[0], 0, 32)

command[0] = 0x1// station number
command[1] = 0x5// function code : write single coil

address = 0
HIBYTE(address, command[2])
LOBYTE(address, command[3])

command[4] = 0xff// force 0x_1 on
command[5] = 0

CRC(command[0], checksum, 6)

LOBYTE(checksum, command[6])
HIBYTE(checksum, command[7])

OUTPORT(command[0], "MODBUS RTU Device", 8)// send request
INPORT(response[0], "MODBUS RTU Device", 8, return_value)// read response

end macro_command
```

## 18.9 Compiler Error Message

### 1. Error Message Format:

**error c# : error description**

(# is the error message number)

Example: error C37 : undeclared identifier : i

When there are compile errors, the error description can be referenced by the compiler error message number.

## 2. Error Description

### (C1) syntax error : 'identifier'

There are many possibilities to cause compiler error.

For example:

```
macro_command main()
char i, 123xyz // this is an unsupported variable name
end macro_command
```

### (C2) 'identifier' used without having been initialized

Macro must define the size of an array during declaration.

For example:

```
macro_command main()
char i
int g[i] // i must be a numeric constant
end macro_command
```

### (C3) redefinition error : 'identifier'

The name of variable and function within its scope must be unique.

For example:

```
macro_command main()
int g[10] , g // error
end macro_command
```

### (C4) function name error : 'identifier'

Reserved keywords and constant can not be the name of a function

For example :

```
sub int if() // error
```

**(C5) parentheses have not come in pairs**

Statement missing “(“ or “)”

For example :

```
macro_command main ) // missing “(“
```

**(C6) illegal expression without matching ‘if’**

Missing expression in “if” statement

**(C7) illegal expression (no ‘then’) without matching ‘if’**

Missing “then” in “if” statement

**(C8) illegal expression (no ‘end if’)**

Missing “end if”

**(C9) illegal ‘end if’ without matching ‘if’**

Unfinished “If” statement before “End If”

**(C10) illegal ‘else’**

The format of “if” statement is :

```
if [logic expression] then
[ else [if [logic expression] then ] ]

end if
```

Any format other than this format will cause a compile error.

**(C17) illegal expression (no 'for') without matching ‘next’**

“for” statement error : missing “for” before “next”

**(C18) illegal variable type (not integer or char)**

Should be integer or char variable

**(C19) variable type error**

Missing assign statement

**(C20) must be keyword 'to' or 'down'**

Missing keyword "to" or "down"

**(C21) illegal expression (no 'next')**

The format of "for" statement is:

for [variable] = [initial value] to [end value] [step]

next [variable]

Any format other than this format will cause a compile error.

**(C22) 'wend' statement contains no 'while'**

"While" statement error : missing "while" before "Wwnd"

**(C23) illegal expression without matching 'wend'**

The format of "While" statement is :

while [logic expression]

wend

Any format other than this format will cause a compile error.

**(C24) syntax error : 'break'**

"break" statement can only be used in "for", "while" statement

**(C25) syntax error : 'continue'**

"continue" statement can only be used in "for" statement, or "while" statement.

**(C26) syntax error**

expression is error.

**(C27) syntax error**

The mismatch of an operation object in expression causes a compile error.

For example :

```
macro_command main()
```

```
int a, b
for a = 0 to 2
    b = 4 + xyz // illegal : xyz is undefined
next a
end macro_command
```

**(C28) must be 'macro\_command'**

There must be 'macro\_command'

**(C29) must be key word 'sub'**

The format of function declaration is:

```
sub [data type] function_name(...)
.....
end sub
```

For example::

```
sub int pow(int exp)
.....
end sub
```

Any format other than this format will cause a compile error.

**(C30) number of parameters is incorrect**

Mismatch of the number of parameters

**(C31) parameter type is incorrect**

Mismatch of data type of parameter

**(C32) variable is incorrect**

The parameters of a function must be equivalent to the arguments passing to a function to avoid compile error.

**(C33) function name : undeclared function**

**(C34) expected constant expression**

**(C35) invalid array declaration**

**(C36) array index error**

**(C37) undeclared identifier : i 'identifier'**

Any variable or function should be declared before use.

**(C38) un-supported PLC data address**

The parameter of GetData( ... ) , SetData( ... ) should be legal PLC address.

**(C39) 'idenifier' must be integer, char or constant**

The format of array is:

Declaration: array\_name[constant] (constant is the size of the array)

Usage: array\_name[integer, character or constant]

Any format other than this format will cause a compile error.

**(C40) execution syntax should not exist before variable declaration or constant definition**

For example :

```
macro_command main( )
int a, b
for a = 0 To 2
  b = 4 + a
int h , k// illegal – definitions must occur before any statements or expressions
next a
end macro_command
```

**(C41) float variables cannot be contained in shift calculation**

**(C42) function must return a value**

**(C43) function should not return a value**

**(C44) float variables cannot be contained in calculation**

**(C45) PLC address error**

**(C46) array size overflow (max. 4k)**

**(C47) macro command entry function is not only one**

**(C48) macro command entry function must be only one**

The only one main entrance of macro is :

```
macro_command function_name()  
end macro_command
```

**(C49) an extended addressee's station number must be between 0 and 255**

For example :

```
SetData(bits[0] , "PLC 1" , LB , 300#123, 100)
```

```
// illegal : 300#123 means the station number is 300, but the maximum is 255
```

**(C50) an invalid PLC name**

PLC name is not defined in the device list of system parameters.

**(C51) macro command do not control a remote device**

A macro just can control a local machine.

For example :

```
SetData(bits[0] , "PLC 1" , LB , 300#123, 100)
```

"PLC 1" is connected with the remote HMI ,so it is can not work.

## 18.10 Sample Macro Code

### 1. "for" statement and other expressions (arithmetic, bitwise shift, logic and comparison)

```
macro_command main()
int a[10], b[10], i

b[0]= (400 + 400 << 2) / 401
b[1]= 22 *2 - 30 % 7
b[2]= 111 >> 2
b[3]= 403 > 9 + 3 >= 9 + 3 < 4 + 3 <= 8 + 8 == 8
b[4]= not 8 + 1 and 2 + 1 or 0 + 1 xor 2
b[5]= 405 and 3 and not 0
b[6]= 8 & 4 + 4 & 4 + 8 | 4 + 8 ^ 4
b[7]= 6 - (~4)
b[8]= 0x11
b[9]= 409

for i = 0 to 4 step 1
    if (a[0] == 400) then
        GetData(a[0], "Device 1", 4x, 0,9)
        GetData(b[0], "Device 1", 4x, 11,10)
    end If
next i
end macro_command
```

### 2. "while", "if" and "break" statements

```
macro_command main()
int b[10], i
i = 5
while i == 5 - 20 % 3
    GetData(b[1], "Device 1", 4x, 11, 1)

    if b[1] == 100 then
        break
    end if
wend
```

```
end macro_command
```

### 3. Global variables and function call

```
char g
sub int fun(int j, int k)
int y

SetData(j, "Local HMI", LB, 14, 1)
GetData(y, "Local HMI", LB, 15, 1)
g = y

return y
end Sub

macro_command main()
int a, b, i

a = 2
b = 3
i = fun(a, b)
SetData(i, "Local HMI", LB, 16, 1)
end macro_command
```

### 4. "if" statement

```
macro_command main()
int k[10], j

for j = 0 to 10
    k[j] = j
next j

if k[0] == 0 then
    SetData(k[1], "Device 1", 4x, 0, 1)
end if

if k[0] == 0 then
```

```
        SetData(k[1], "Device 1", 4x, 0, 1)
else
        SetData(k[2], "Device 1", 4x, 0, 1)
end if
```

```
if k[0] == 0 then
        SetData(k[1], "Device 1", 4x, 1, 1)
else if k[2] == 1 then
        SetData(k[3], "Device 1", 4x, 2, 1)
end If
```

```
if k[0] == 0 then
        SetData(k[1], "Device 1", 4x, 3, 1)
else if k[2] == 2 then
        SetData(k[3], "Device 1", 4x, 4, 1)
else
        SetData(k[4], "Device 1", 4x, 5, 1)
end If
end macro_command
```

## 5. "while" and wend" statements

```
macro_command main()
char i = 0
int a[13], b[14], c = 4848
```

```
b[0] = 13
```

```
while b[0]
        a[i] = 20 + i * 10

        if a[i] == 120 then
                c = 200
                break
        end if
```

```
        i = i + 1
wend
```

```
SetData(c, "Device 1", 4x, 2, 1)
end macro_command
```

## 6. "break" and "continue" statements

```
macro_command main()
char i = 0
int a[13], b[14], c = 4848

b[0] = 13

while b[0]
    a[i] = 20 + i * 10

    if a[i] == 120 then
        c = 200
        i = i + 1
        continue
    end if

    i = i + 1

    if c == 200 then
        SetData(c, "Device 1", 4x, 2, 1)
        break
    end if
wend
end macro_command
```

## 7. Array

```
macro_command main()
int a[25], b[25], i

b[0] = 13

for i = 0 to b[0] step 1
```


```
    a[i] = 20 + i * 10
next i

SetData(a[0], "Device 1", 4x, 0, 13)
end macro_command
```

# Chapter 19 How to Set HMI as a MODBUS Server

## 19.1 How to Set HMI as MODBUS Device


After setting as MODBUS Server, the data of MT8000 can be read or written via MODBUS protocol.



Refer to the above illustration, it shows MT8000 is set as MODBUS Server. The HMI, PC or other devices can use MODBUS protocol to read or write the data from MT8000 via Ethernet or RS232/485 interface. Please follow the steps as below.

### 19.1.1 Creating a MODBUS Server


First of all, creating a new device “MODBUS Server” in the Device table of System Parameter Settings, the PLC I/F can be set to anyone of RS232, RS485 2W, RS485 4W ,Ethernet.




If PLC I/F is set as RS232 or RS485, please fill in COM Port Settings also.



If PLC I/F is set as Ethernet, the IP is the same as HMI.




For MODBUS Server and HMI use the same port no., please change the MODBUS Server port no. on Model tab of System Parameter Settings.



After finishing the setting, MODBUS Server will be list on Device tab.


You can send MODBUS command to read or write the data from MODBUS Server after downloading the file of XOB to HMI.




### 19.1.2 How to Read From / Write to MODBUS Server

MT8000 (the client) can read from / write to another MT8000 (the server) via MODBUS protocol.


Adding a new device in the client. If client's PLC I/F is set as Ethernet, please select "MODBUS RTU TCP/IP" as PLC type and fill in the correct IP and Port no..



If the client use RS232/485 interface, the PLC type must be set as "MODBUS RTU", please make sure the communication parameter setting is correct.



Set and click OK, a new device "MODBUS RTU" shall be listed in the Device tab.



In the setting page of each object, there is an "MODBUS RTU" in the PLC name selection list, you can then select appropriate device type and address.



The internal memory of MT8000 is mapping to the Modbus address as below :

reading / writing	0x/1x(1~9999)	to	reading / writing	LB(0~9998)
reading / writing	3x/4x/5x(1~9999)	to	reading / writing	LW(0~9998)
reading / writing	3x/4x/5x(10000~75533)	to	reading / writing	RW(0~65533)

## 19.2 How to Change the Station Number of a MODBUS Server in Runtime


Change the content of relative reserved registers to modify the station number of a MODBUS server (HMI).

- [LW9541] The station number of a MODBUS server (COM 1)
- [LW9542] The station number of a MODBUS server (COM 1)
- [LW9543] The station number of a MODBUS server (COM 1)
- [LW-9544] The station number of a MODBUS server (Ethernet)


## Chapter 20 How to Connect a Barcode Device

### 20.1 How to Connect a Barcode Device

The following explains how to create a project for connecting and controlling a barcode device. First, please add a new Barcode device into the device list as follows.




Click the [Settings...], barcode device settings display as below.



<b>COM</b>	Barcode device can be connect to any of COM 1~ COM 3
<b>Baud rate</b>	Set communication parameters accordingly
<b>Data bits</b>	
<b>Parity</b>	
<b>Stop bits</b>	
<b>Read byte limit</b>	
<b>Use a start code</b>	<p>With this function, the MT8000 will identify the start code in reading the input data from bar code reader. All the data include and before start code will be ignored. All the data after start code will be saved in designated address.</p> <p>For example: if the start code is 255(0xff), and original data are “0xff 0x34 0x39 0x31 0x32 0x30 0x30 0x34 0x37”, the data saved in designated device address are “0x34 0x39 0x31 0x32 0x30 0x30 0x34 0x37”</p>
<b>Terminator</b>	<p>Terminator means the end of data, when terminator is detected, it's mean the end of data stream.</p> <p><b>[CR/LF]</b> 0x0a or 0x0d means end of data.</p> <p><b>[STX/ETX]</b> 0x02 or 0x03 means end of data.</p>

	<b>[Other]</b>	User can set the terminator manually.
	<b>[None]</b>	MT8000 will save all data to designated address of barcode device.

After setting completely, a new barcode device will be list in the device tab.



The Barcode device has two device types (Flag and Barcode).

Device type	Address type	Description
FLAG	bit	FLAG 0 indicates the status of data reading. When reading data is complete, the FLAG 0's states will be changed from OFF to ON.
BARCODE	word	BARCODE 0 Number of bytes of reading data. BARCODE 1~n designate bard code data save address.

The following display shows the configuration of barcode reader data. The data from barcode reader is "9421007480830".The BARCODE 0 and BARCODE 1~n represents number of bytes read from barcode and the data.



At present, the data of barcode device corresponding address as below:


<b>Barcode corresponding address</b>	<b>Data</b>
BARCODE 0	13 bytes(decimal) The real data in the address is 14 bytes = 7 words. If the data is odd, will add a byte (0x00) to make it even.
BARCODE 1	3439HEX
BARCODE 2	3132HEX
BARCODE 3	3030HEX
BARCODE 4	3437HEX
BARCODE 5	3038HEX
BARCODE 6	3338HEX
BARCODE 7	0030HEX
BARCODE 8	empty

## Chapter 21 Ethernet Communication and Multi-HMIs Connection


By using the Ethernet network, the EB8000 provides following methods for data transmission:

1. HMI to HMI communication.
2. PC to HMI communication.
3. Operating the PLC connected to other HMIs

There are two ways of the Ethernet communication; one way is to use RJ45 straight through cable with the use of a hub (hubs), and the other way is to use RJ45 crossover cable. In the second way there is no need to use hub(s), and it is limited to the condition of point to point connection (HMI to HMI, or PC to HMI). The following descriptions will show how to set up and perform the Ethernet connection in each way.



## 21.1 HMI to HMI Communication



Different HMIs can monitor and control each other's data through the Ethernet network. By using the system reserved register (LB and LW), one HMI can master performance of other HMI(s). One HMI can handle requests from a maximum of 32 other HMIs simultaneously.

Here is an example of communicating two HMIs (HMI A and HMI B). When HMI A wants to use the set bit object to control the [LB123] node of HMI B, the procedure for setting the Project files (MTP) on HMI A is as follows:

### Step 1


Set the IP address of the two HMIs (Refer to the related chapter for the details). Suppose that the IP address of HMI A and HMI B are set for "192.168.1.1" and "192.168.1.2" respectively.

### Step 2

Running the EB8000, and select the [Device Table] tab on the [System Parameter Setting] menu, then add the IP address and Port number of HMI B. (The picture below shows the content of HMI A's MTP projects.)


The screenshot shows the 'System Parameter Settings' window with the 'Device' tab selected. The 'Device list' table contains the following data:

No.	Name	Location	Device type	Interface	I/F Protocol
Local HMI	Local HMI	Local	MT8121 T (800 x 600)	Disable	N/A
Remote HMI 1	Remote HMI	Remote(IP:192.168.1...	MT8xxx	Ethernet	TCP/IP



### Step 3

Select "HMI B" for [PLC name] on the "Set Bit Object's Attributes" menu, and now HMI A can operate the content of the LB of HMI B.



## 21.2 PC to HMI Communication



By using the simulator Function of the EB8000, PC can catch HMI's data through the Ethernet network and save the data as files on computer.

PC can master HMI by operating the system reserved register (LB and LW) of HMI. On the contrary, HMI can also directly control PC's operation, for example, asking PC save data from HMI or PLC.

The number of HMIs mastered by PC is unlimited.


Suppose that PC is going to communicate with two HMIs (HMI A and HMI B) , the procedure for setting PC's MTP projects is as follows:

**Step 1**

Set the IP address of the two HMIs (Refer to the related chapter for the details). Suppose that the IP address of HMI A and HMI B are set for "192.168.1.1" and "192.168.1.2" respectively.


**Step 2**

Running the EB8000, and select the [Device Table] tab on the [System Parameter Setting] menu, then add the IP addresses and Port numbers of HMI A and HMI B.



### Step 3

Select correct PLC for [PLC name]. In the [General] tab on the [Set Bit Object's Attributes] menu, if you intend to control the LB of HMI A, you have to select "HMI A" for [PLC name]. See the picture below.




#### Step 4

Making use of HMI's MTP projects on PC and performing the simulator function (either online mode or offline mode), and then all HMI's data can be controlled by PC.

It is also available for HMI to control PC's data. Just considering the PC another HMI to add it as a new HMI device to the MTP projects of HMI A or HMI B and set the IP address pointing to the PC.

### 21.3 Operate the PLC Connected with other HMIs.




Through the Ethernet network, PC and HMI can also operate PLC that is connected to other HMI; for example, suppose that there is a Mitsubishi PLC connected to HMI B's COM 1, when PC or HMI A wants to read data of the PLC, the procedure for setting PC or HMI A's MTP projects is as follows:

#### Step 1

Set the IP address of HMI B; suppose the IP address of HMI B is set for "192.168.1.2".

#### Step 2

Running the EB8000, and select the [Device Table] tab on the [System Parameter Setting] menu, then add a PLC device (defined as Mitsubishi FX0n\_FX2 in the example below) and set the correct communication parameters.



### Step 3

In the case of using the set bit object to operate the Mitsubishi PLC connected to HMI B, just need to select “PLC on HMI B” for [PLC name] on the [General] tab on the [Set Bit Object’s Attributes] menu, then it is able to operate the PLC connected to the remote HMI B on PC through the simulator function .

**Set Bit Object's Properties** [X]

General Security Shape Label Profile

Description :

PLC name : PLC on HMI B [v]

Write address

Device type : X [v]

Address :   System tag  User-defined tag

Index register

Write after button is released

Attribute

Switch style : Set ON [v]

Macro

Execute macro

OK Cancel Help

## Chapter 22 System Reserved Words / Bits

Some Local Words and Local Bits are reserved for system usage. Users should not use these reserved words/bits except for the designated purposes. The range of reserved word/bits is listed as follows:

- Local Bits: 9000~9999 are reserved
- Local Words: 9000~9999 are reserved

### 22.1 System Status and Control

Address	Description	Read & Write	Macro	Remote HMI Control
LB-900n (n = 0~9)	When the HMI starts up, the initial states of these bits will be set as ON.	R / W	R / W	R / W
LB-9017	When the state is ON, the return function of [PLC Control] [Change Base Window] will be disable.	R / W	R / W	R / W
LB-9018	Set ON to make mouse cursor invisible	R / W	R / W	R / W
LW-9025	CPU loading (0-100%) indicator	R	R	R
LW-9050	Window number that are currently displayed as base windows on the MT8000.	R	R	R
LW-9100~ LW-9115	File names of the MTP projects used by the MT8000.	R	R	R
LW-9116~ LW-9117	Sizes of MTP projects (unit: byte).	R	R	R
LW-9118~ LW-9119	Sizes of MTP projects (unit: K byte).	R	R	R
LW-9120~ LW-9121	Version of compiler that is used for MTP projects.	R	R	R
LW-9122	Time (year) of MTP project being complied.	R	R	R
LW-9123	Time (month) of MTP project being complied.	R	R	R
LW-9124	Time (day) of MTP project being complied.	R	R	R
LW-9125	IP0 (The IP address format is IP0. IP1. IP2.	R	R	R

	IP3.)			
LW-9126	IP1	R	R	R
LW-9127	IP2	R	R	R
LW-9128	IP3.	R	R	R
LW-9129	gw0. (The IP address of gateway : gw 0. gw 1. gw 2. gw 3.)	R	R	R
LW-9130	gw1	R	R	R
LW-9131	gw2	R	R	R
LW-9132	gw3	R	R	R
LW-9133	Ethernet port no.	R	R	R
LW-9134	Language mode	R/W	R/W	R/W

## 22.2 States of Data Input

Address	Description	Read & Write	Macro	Remote HMI Control
LW-9002~ LW-9003	Maximum value that is allowed to input to the current data input object. The data format is 32-bit (float).	R	R	R
LW-9004~ LW-9005	Minimum value that is allowed to input to the current data input object. The data format is 32-bit (float).	R	R	R
LW-9150~ LW-9181	Data stream input from the keypad, saved in the ASCII format and the length of data is 32 words.	R	R	R
LW-9540	Reserved for the use of the Caps Lock key on the keypad.	R	R	R

## 22.3 Recipe Data

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9010	ON when recipe data is in download operation.	R	R	R
LB-9011	ON when recipe data is in upload operation.	R	R	R
LB-9012	ON when recipe data is in either download or upload operation.	R	R	R

LB-9028	If it is set ON, all recipe data will be clear (set to 0).	W	W	W
LB-9029	The MT8000 will save recipe data (RW and RWA) on the flash memory every 5 minutes. If it is set ON, recipe data will be compulsorily saved on the flash memory.	W	W	W

## 22.4 Task Button and Fast Selection Window

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9013	If it is set ON, the Fast Selection Window is disable.	W	W	W
LB-9014	If it is set ON, the Task Button is disable.	W	W	W
LB-9015	If it is set ON, both the Fast Selection Window and Task Button is disable.	W	W	W

## 22.5 Event Logging

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9021	Clear all event logs of the day when bit is set ON.	W	W	W
LB-9022	The oldest event log message will be deleted when bit is set ON.	W	W	W
LB-9023	Clear all event logs in the MT8000 when bit is set ON.	W	W	W
LB-9024	The MT8000 will recalculate the file sizes of all the event log message when bit is set ON.	W	W	W
LB-9042	Set ON to acknowledge all unacknowledged events	W	W	W
LB-9043	Status ON indicates there are unacknowledged events	R	N/A	N/A
LW-9060	Number of existing event logs.	R	R	R
LW-9061	The file sizes of all event logs (32-bit Unsigned).	R	R	R

## 22.6 Data Logging

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9025	Set ON to delete the oldest data sampling log. (The function can only work for data sampling logs on the MT8000.)	W	W	W
LB-9026	Set ON to delete all the data sampling log. (The function can only work for data sampling logs on the MT8000.)	W	W	W
LB-9027	The MT8000 will recalculate the file sizes of all the data sampling log when bit is set ON.	W	W	W
LW-9063	The number of data sampling logs on the MT8000.	W	W	W
LW-9064	The file sizes of all data sampling logs on the MT8000 (32-bit Unsigned).	W	W	W

## 22.7 Password and Operation Level

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9050	Set ON to logout	W	W	W
LB-9060	ON when a password error occurs.	R	N/A	N/A
LB-9061	When set ON, the MT8000 will copy data stored in [LW9500] to [LW9535] and use it as valid password.	W	N/A	N/A
LW-9219	Show the existing user No. 0 user 1, user 2, or user 3.	R	R	R
LW-9220~ LW-9221	Address for password entering (32-bit).	R / W	R / W	R / W
LW-9222	Level (0~6) of currently entered password.	R	R	R
LW-9500~ LW-9501	A new password for user 1	R / W	R / W	R / W
LW-9502~ LW-9503	A new password for user 2	R / W	R / W	R / W
LW-9504~ LW-9504	A new password for user 3	R / W	R / W	R / W
LW-9506~	A new password for user 4	R / W	R / W	R / W

LW-9505				
LW-9508~ LW-9506	A new password for user 5	R / W	R / W	R / W
LW-9510~ LW-9511	A new password for user 6	R / W	R / W	R / W
LW-9512~ LW-9513	A new password for user 7	R / W	R / W	R / W
LW-9514~ LW-9515	A new password for user 8	R / W	R / W	R / W
LW-9516~ LW-9517	A new password for user 9	R / W	R / W	R / W
LW-9518~ LW-9519	A new password for user 10	R / W	R / W	R / W
LW-9520~ LW-9521	A new password for user 11	R / W	R / W	R / W
LW-9522~ LW-9523	A new password for user 12	R / W	R / W	R / W

## 22.8 Time of HMI

Address	Description	Read & Write	Macro	Remote HMI Control
LW-9010	Local time (second, BCD)	R / W	R / W	R / W
LW-9011	Local time (minute, BCD)	R / W	R / W	R / W
LW-9012	Local time (hour, BCD)	R / W	R / W	R / W
LW-9013	Local time (day, BCD)	R / W	R / W	R / W
LW-9014	Local time (month, BCD)	R / W	R / W	R / W
LW-9015	Local time(year, BCD)	R / W	R / W	R / W
LW-9016	Local time (week, BCD)	R	R	R
LW-9017	Local time (second, BIN)	R / W	R / W	R / W
LW-9018	Local time (minute, BIN)	R / W	R / W	R / W
LW-9019	Local time (hour, BIN)	R / W	R / W	R / W
LW-9020	Local time (day, BIN)	R / W	R / W	R / W
LW-9021	Local time (month, BIN)	R / W	R / W	R / W
LW-9022	Local time (year, BIN)	R / W	R / W	R / W
LW-9023	Local time (week, BIN)	R	R	R
LW-9030~ LW-9031	System time (in units of 0.1 second), timing from the machine starts up.	R	R	R

## 22.9 Hardware of HMI

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9019	Set ON to disable Sound and Buzzer Set OFF to enable Sound and Buzzer	R / W	R / W	R / W
LB-9040	Set OFF to ON increase the brightness of CCFL backlight one step.	W	W	W
LB-9041	Set OFF to ON decrease the brightness of CCFL backlight one step.	W	W	W
LW-9070	free space for event logs (K bytes)	R / W	R / W	R / W
LW-9071	System reserved free space size (K bytes)	R / W	R / W	R / W
LW-9072	MT8000 available free space (K bytes)	R / W	R / W	R / W

## 22.10 The States of Communicating with Remote HMI(s)

Address	Description	Read & Write	Macro	Remote HMI Control
LB-910n	n = 0~31 The registers can be used to indicate the states of communication with remote HMI. .ON indicates the communication is normal, while OFF indicates the communication is disconnected from remote HMI; at this time set the state to ON, the MT8000 will try to connect to remote HMI again.	R / W	R / W	R / W

## 22.11 The States of Communicating with PLC

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9150	When the state is ON, the system will automatically resume connection if the PLC device with COM 1 is disconnected.  When the state is OFF, the disconnection to the PLC device will not be resumed	R / W	R / W	R / W
LB-9151	When the state is ON, the system will automatically resume connection if the PLC device with COM 2 is disconnected.  When the state is OFF, the disconnection to the PLC device will not be resumed.	R / W	R / W	R / W
LB-9152	When the state is ON, the system will automatically resume connection if the PLC device with COM 3 is disconnected.  When the state is OFF, the disconnection to the PLC device will not be resumed.	R / W	R / W	R / W
LB-9153~ LB-9184	When the state is ON, the system will automatically resume connection if the PLC	R / W	R / W	R / W

	<p>device with the Ethernet port is disconnected; n = 0~31.</p> <p>When the state is OFF, the disconnection to the PLC device will not be resumed.</p>			
<p>LB-9200~ LB-9455</p>	<p>The registers can be used to indicate the states of communication with the PLC device on COM 1.</p> <p>LB9200 is to indicate the states of communication with the PLC on the station no. 0, LB9201 is to indicate the states of communication with the PLC on the station no. 1, and so on.</p> <p>When the state is ON, it indicates the communication is normal. When the state is OFF, it indicates the disconnection to the PLC device; at this time set the state at ON, and the system will try to connect the PLC device again.</p>	R / W	R / W	R / W

<p>LB-9500~ LB-9755</p>	<p>The registers can be used to indicate the states of communication with the PLC device on COM 2.</p> <p>LB9500 is to indicate the states of communication with the PLC on the station no. 0, LB9501 is to indicate the states of communication with the PLC on the station no. 1, and so on.</p> <p>When the state is ON, it indicates the communication is normal. When the state is OFF, it indicates the disconnection to the PLC device; at this time set the state at ON, and the system will try to connect to the PLC device again.</p>	R / W	R / W	R / W
-----------------------------	--	-------	-------	-------

LB-9800~ LB-10055	<p>The registers can be used to indicate the states of communication with the PLC device on COM 3.</p> <p>LB9800 is to indicate the states of communication with the PLC on the station no. 0, LB9801 is to indicate the states of communication with the PLC on the station no. 1, and so on.</p> <p>When the state is ON, it indicates the communication is normal. When the state is OFF, it indicates the disconnection to the PLC device; at this time set the state at ON, and the system will try to connect to the PLC device again.</p>	R / W	R / W	R / W
LB-10100~ LB-10131	<p>The registers can be used to indicate the states of communication with the PLC device on the Ethernet port.</p> <p>When the state is OFF, it indicates the disconnection to the PLC device; at this time set the state at ON, and the system will try to connect to the PLC device again.</p>	R / W	R / W	R / W
LW-930n	The number of the driver that is used by local PLC device.	R	R	R
LW-935n	The number of unprocessed commands that are gave to the local PLC device.	R	R	R
LW-940n	The content of the latest connection error when connecting to the local PLC device.	R	R	R

## 22.12 Client Connected to Server

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9016	Set ON when client connects to server.	R / W	R / W	R / W
LW-9006	The number of clients connected to server.	R	R	R

### 22.13 MODBUS Server Station no.

Address	Description	Read & Write	Macro	Remote HMI Control
LW-9541	device station no.(COM 1) if configured as Modbus server	R / W	R / W	R / W
LW-9542	device station no.(COM 2) if configured as Modbus server	R / W	R / W	R / W
LW-9543	device station no. (COM 3) if configured as Modbus server	R / W	R / W	R / W
LW-9544	device station no. (Ethernet) if configured as Modbus server	R / W	R / W	R / W

### 22.14 COM Communication

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9030	Set LB9030 from OFF to ON force the system to use LW9550~LW9554 as new communication parameter of COM1	R / W	R / W	R / W
LW-9550	COM 1 mode 0: RS232 1: RS232 2W 2: RS232 4W	R / W	R / W	R / W
LW-9551	COM 1 baud rate 0: 4800 1: 9600 2: 19200 3: 38400 4: 57600 5: 115200	R / W	R / W	R / W
LW-9552	COM 1 data bits 7 : 7 bits 8: 8 bits	R / W	R / W	R / W
LW-9553	COM 1 parity 0: none 1: even 2: odd	R / W	R / W	R / W

LW-9554	COM 1 stop bits 1: 1 bit 2: 2 bits	R / W	R / W	R / W
LB-9031	Set LB9031 from OFF to ON force the system to use LW9556~LW9559 as new communication parameter of COM2	R / W	R / W	R / W
LW-9556	COM 2 baud rate 0: 4800 1: 9600 2: 19200 3: 38400 4: 57600 5: 115200	R / W	R / W	R / W
LW-9557	COM 2 data bits 7 : 7 bits 8: 8 bits	R / W	R / W	R / W
LW-9558	COM 2 parity 0: none 1: even 2: odd	R / W	R / W	R / W
LW-9559	COM 2 stop bits 1: 1 bit 2: 2 bits	R / W	R / W	R / W
LB-9032	Set LB9032 from OFF to ON force the system to use LW9560~LW9564 as new communication parameter of COM3	R / W	R / W	R / W
LW-9560	COM 3 mode 0: RS232 2: RS232 4W	R / W	R / W	R / W
LW-9561	COM 3 baud rate 0: 4800 1: 9600 2: 19200 3: 38400 4: 57600 5: 115200	R / W	R / W	R / W
LW-9562	COM 3 data bits 7 : 7 bits	R / W	R / W	R / W

	8: 8 bits			
LW-9563	COM 3 parity 0: none 1: even 2: odd	R / W	R / W	R / W
LW-9564	COM 3 stop bits 1: 1 bit 2: 2 bits	R / W	R / W	R / W

### 22.15 File Manager

Address	Description	Read & Write	Macro	Remote HMI Control
LB-9034	Save event/data log to HMI	W	W	W
LB-9035	HMI free space insufficiency alarm	R	N/A	N/A
LB-9036	CF free space insufficiency alarm	R	N/A	N/A
LB-9037	USB1 free space insufficiency alarm	R	N/A	N/A
LB-9038	USB2 free space insufficiency alarm	R	N/A	N/A
LB-9039	Status of file backup activity	R	R	R
LW-9074	CF current free space	R	N/A	N/A
LW-9076	USB1 current free space	R	N/A	N/A
LW-9078	USB2 current free space	R	N/A	N/A

### 22.16 PLC & Remote HMI IP Address Setting

Address	Description	Read & Write	Macro	Remote HMI Control
LW-9600 ~ LW-9629	PLC 4's IP address setting (IP0:IP1:IP2:IP3)	R/W	R/W	R/W
LW-9800 ~ LW-9839	Remote HMI's IP address setting (IP0:IP1:IP2:IP3)	R/W	R/W	R/W

### 22.17 Printer Server Setting

Address	Description	Read & Write	Macro	Remote HMI Control
---------	-------------	--------------	-------	--------------------

LW-9770~ LW-9773	Remote printer server setting (IP0:IP1:IP2:IP3)	R/W	R/W	R/W
LW-9774	Remote printer server user name	R/W	R/W	R/W
LW-9780	Remote printer server password	R/W	R/W	R/W

## 22.18 Address Index Function

Address	Description	Read & Write	Macro	Remote HMI Control
LW-9200~ LW-9260	Address index	R/W	R/W	R/W

## 22.19 The Address Ranges of Local HMI Memory

### 22.19.1 Bits

Memory	Device type	Address Range	Address Format
Local Memory Bits	LB	0~11999	AAAAA
Local Word Bits	LW_BIT	0~9999	AAAAABB  AAAAA: address BB: bit offset (00~15)  Example: 567 <u>12</u> address = 567 bit offset = 12
Retentive Memory Bit Index	RBI	0~65535	AAAAAB  AAAAA: address B: bit offset (0~f)  Example: 567 <u>a</u> RW_Bit address = 567 + [LW9000] bit offset = a

Retentive Memory Word Bits	RW_Bit	0~65535	<b>AAAAAB</b> AAAAA: address B: bit offset (0~f)  Example: 567 <u>a</u> address = 567 bit offset = a
Retentive Memory A Word Bits	RW_A_Bit	0~65535	<b>AAAAAB</b> AAAAA: address B: bit offset (0~f)  Example: 567 <u>a</u> address = 567 bit offset = a

### 22.19.2 Words

Memory	Device type	Address Range	Format
Local Memory Words	LW	0~9999	<b>AAAAA</b> AAAAA: address
Retentive Memory Words	RW	0~65535	<b>AAAAA</b> AAAAA: address
Retentive Memory Word Index	RWI	0~65535	<b>AAAAAB</b> AAAAA: address  Example: 567 <b>RW address = 567 + [LW9000]</b>
Retentive Memory A Word	RW_A	0~65535	AAAAA AAAAA: address
Extended Memory Words	EM0~EM9	<b>AAAAAAAAA</b> Limited by device, Maximum 2 GB	

### 22.20 Touch Screen X and Y Position

<b>Address</b>	<b>Description</b>	<b>Read &amp; Write</b>	<b>Macro</b>	<b>Remote HMI Control</b>
LW-9041	Touch status word (bit 0 ON = user is touching the screen)	R	R/W	R/W
LW-9042	Touch X position	R	R/W	R/W
LW-9043	Touch Y position	R	R/W	R/W
LW-9044	Leave X position	R	R/W	R/W
LW-9045	Leave Y position	R	R/W	R/W

### 22.21 Variable Station no.

<b>Address</b>	<b>Description</b>	<b>Read &amp; Write</b>	<b>Macro</b>	<b>Remote HMI Control</b>
LW-10000~ LW-10015	Var0~Var15 station no. variable (Usage: Var0#address)	R/W	R/W	R/W

## Chapter 23 PLC Connection Guide

### AIBUS

UDIAN Automation AI-501, AI-518, AI-519, AI-701, AI-702M, AI-704M, AI-706M, AI-719  
<http://www.yudian.us>

### HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	AIBUS		
Com port	RS485 2W	RS232	
Baud rate	9600	9600, 19200	
Parity bit	None		
Data Bits	8		
Stop Bits	2		
HMI Station No.	0		
PLC Station No.	1	0-100	

Online Simulator	YES	
Extend address mode	NO	

### PLC Setting:

Communication mode	
--------------------	--

## Device address:

### AI-518

Bit/Word	Device Type		Format	Range	Memo
Word	0	00H	dd		SV/STEP
Word	1	01H	dd	-1999~+9999	HIAL
Word	2	02H	dd	-1999~+9999	LoAL
Word	3	03H	dd	0~9999	dHAL
Word	4	04H	dd	0~9999	dLAL
Word	5	05H	dd	0~2000	dF
Word	6	06H	dd	0~4	Ctrl
Word	7	07H	dd	0~9999	M5
Word	8	08H	dd	1~9999	P
Word	9	09H	dd	0~2000	t
Word	10	0AH	dd	0~125	CtI
Word	11	0BH	dd	0~37	Sn (read only)
Word	12	0CH	dd	0~3	dIP (read only)
Word	13	0DH	dd	-1999~+9999	dIL
Word	14	0EH	dd	-1999~+9999	dIH
Word	15	0FH	dd	0~9999	ALP
Word	16	10H	dd	-1999~+4000 0.1°C	Sc
Word	17	11H	dd	0~48	Op1
Word	18	12H	dd	-110~+110%	oPL
Word	19	13H	dd	0~110%	oPH
Word	20	14H	dd	0~127	CF (read only)
Word	21	15H	dd	0~19.2K	Baud rate ( bAud ) /808Pstatus word: run:0 suspend:4 stop:12 (read only)
Word	22	16H	dd	0~100	ADDR
Word	23	17H	dd	0~20	dL
Word	24	18H	dd	0~127	Run
Word	25	19H	dd	0~9999	Loc

# AI-701

Bit/Word	Device Type		Format	Range	Memo
W	1	01H	dd	-9990~+30000	HIAL
W	2	02H	dd	-9990~+30000	LoAL
W	3	03H	dd	-9990~+30000	HdAL
W	4	04H	dd	-9990~+30000	LdAL
W	5	05H	dd	0~2000	AHYS
W	11	0BH	dd	0~37	InP (read only)
W	12	0CH	dd	0~3	dPt
W	13	0DH	dd	-9999~+30000	SCL
W	14	0EH	dd	-9999~+30000	SCH
W	15	0FH	dd	0~4444	AOP
W	16	10H	dd	-1999~+4000 0.1°C	Scb
W	17	11H	dd	0~48	Opt
W	21	15H	dd	0~19.2K	Baud rate (bAud) /808P status word run:0 suspend:4 stop:12 (read only)
W	22	16H	dd	0~80	ADDR
W	23	17H	dd	0~40	FILt
W	25	19H	dd	0~255	Loc

## Wiring diagram:

RS-485:

MT8000 PLC[485]

9P D-SUB

COM1	COM3
1 RX-	6 Data-
2 RX+	9 Data+
5 GND	5 GND

AI-518/518P

RS485 port

4	COMM A
3	COMM B

# Allen-Bradley CompactLogix / FlexLogix

Allen-Bradley CompactLogix, FlexLogix CH0 DF1


<http://www.ab.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Allen-Bradley CompactLogix/FlexLogix		
Com port	RS232		
Baud rate	19200	9600, 19200, 38400	
Parity bit	None	Even, Odd, None	
Data Bits	8	8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	1-31	

## PLC Setting:

Communication mode	<b>DF1 Full Duplex protocol 19200, None, 8, 1 (default)</b> <b>Error Check: BCC, Station Address: 1</b>
--------------------	--




## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	B_BOOL	fffddd(dd)	File no. ff: 3, 10~255 Element no. ddd: 0~255 Bit no. (dd): 0~15	Bit data file
B	N_BOOL	fffddd(dd)	File no. ff: 7, 10~255 Element no. ddd: 0~255 Bit no. (dd): 0~15	Integer data file bit level (N7, 10~255)
W	Bx_INT	fffddd	File no. fff: 3, 10~255 Element no. ddd: 0~255	Bit data file word level
DW	Tx.PRE	fffddd	File no. fff: 4, 10~255 Element no. ddd: 0~255	Timer Preset Value (T4, T10~255)
DW	Tx.ACC	fffddd	File no. fff: 4, 10~255 Element no. ddd: 0~255	Timer Accumulator Value (T4, T10~255)
DW	Cx.PRE	fffddd	File no. fff: 5, 10~255 Element no. ddd: 0~255	Counter Preset Value (C5, C10~255)
DW	Cx.ACC	fffddd	File no. fff: 5, 10~255 Element no. ddd: 0~255	Counter Accumulator Value (C5, C10~255)
F	F8_REAL	ddd	ddd:0~255	Floating point data file (F8)
DW	Nx_INT	Fffddd	File no. fff:0~255 Element no. ddd:0~255	Integer data file (N7, 10~255)

## Wiring diagram:

RS-232: ControlLogix, CompactLogix CPU CH0





RS Logix 5000 setting


You can configure a mapping table to allow the controller to accept the PLC-2, 3, 5, or SLC/500 messages.

### Configure Mapping for a PLC-3, PLC-5, or SLC/500 Processor


1. From the Logic menu, choose Map PLC Messages.
2. In the Mapping frame, enter the File Number and Tag Name to be mapped.
3. Click on OK to configure the mapping.



ControlLogix, CompactLogix CPU CH0 setting:



Create the Tag:



**New Tag** [X]

Name:

Description:

Tag Type:
 

- Base
- Alias
- Produced  consumers
- Consumed

Data Type:

Scope:

Style:

OK  
Cancel  
Help

**Select Data Type** [X]

Data Types:

- FBD\_TIMER
- FBD\_TRUNCATE
- FILTER\_HIGH\_PASS
- FILTER\_LOW\_PASS
- FILTER\_NOTCH
- FLIP\_FLOP\_D
- FLIP\_FLOP\_JK
- FUNCTION\_GENERATOR
- HL\_LIMIT
- INT**
- INTEGRATOR

Array Dimensions

Dim 0	Dim 1	Dim 2
<input type="text" value="255"/>	<input type="text" value="0"/>	<input type="text" value="0"/>

OK  
Cancel  
Help

# Allen-Bradley DF1

Allen-Bradley MicroLogix 1000, 1100, 1200, 1500, SLC 5/03, 5/04, 5/05

<http://www.ab.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	AB DF1		
Com port	RS232		
Baud rate	19200	9600, 19200, 38400	
Parity bit	None	Even, Odd, None	
Data Bits	8	8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	1-31	

## PLC Setting:

Communication mode	<b>DF1 Full Duplex protocol 19200, None, 8, 1 (default)</b> <b>Error Check: CRC</b>
--------------------	--


## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I1	ddd(dd)	ddd:0~254 (dd): 0~15	Input (I)
B	O0	ddd(dd)	ddd:0~254 (dd): 0~15	Output (O)
B	S_Bit	ddd(dd)	ddd:0~254 (dd): 0~15	Status (S) bit level
B	B3	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B3)
B	B10~13	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B10~13)
B	Bfn	fffddd(dd)	File no. fff: 3, 10~254 Element no. ddd: 0~254 Bit no. (dd): 0~15	Bit data file (B3, 10~254)
B	NfnBit	fffddd(dd)	File no. fff: 7, 10~254 Element no. ddd: 0~254 Bit no. (dd): 0~15	Integer data file bit level (N7, 10~254)
W	S	ddd	ddd:0~254	Status (S)
W	T4SV	ddd	ddd:0~254	Timer Preset Value (T4)
W	TfnSV	fffddd	File no. fff: 4, 10~254 Element no. ddd:0~254	Timer Preset Value
W	T4PV	ddd	ddd:0~254	Timer Accumulator Value (T4)
W	TfnPV	fffddd	File no. fff: 4, 10~254 Element no. ddd:0~254	Timer Accumulator Value
W	C5SV	ddd	ddd:0~254	Counter Preset Value (C5)
W	CfnSV	fffddd	File no. fff: 5, 10~254	Counter Preset Value


Bit/Word	Device Type	Format	Range	Memo
			Element no. ddd:0~254	
W	C5PV	ddd	ddd:0~254	Counter Accumulator Value (C5)
W	CfnPV	fffddd	File no. fff: 5, 10~254 Element no. ddd:0~254	Counter Accumulator Value
W	N7	ddd	ddd:0~254	Integer data file (N7)
W	N10~15	ddd	ddd:0~254	Integer data file (N10~15)
W	F8	ddd	ddd:0~254	Floating point data file (F8)
W	Nfn	fffddd	File no. fff:0~254 Element no. ddd:0~254	Integer data file (N7, 10~254)

## Wiring diagram:

RS-232: MicroLogix 1000, 1100, 1200, 1500



RS-232: SLC5/03, 04, 05 CH0



# Allen-Bradley DH485

Allen-Bradley MicroLogix 1000, 1100, 1200, 1500, SLC 5/03, 5/04, 5/05

<http://www.ab.com>


## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Allen-Bradley DH485		
Com port	RS485 2W	RS232	
Baud rate	19200	9600, 19200	
Parity bit	Even		
Data Bits	8		
Stop Bits	1		
HMI Station NO.	0	2	
PLC Station NO.	1	1-31	

Online Simulator	YES		
Extend address mode	NO		

## PLC Setting:

Communication mode	<b>DH485 protocol 19200 (default)</b> <b>Set the Max. Node Address as exactly how many PLCs you have.</b>
--------------------	--




## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I1	ddd(dd)	ddd:0~254 (dd): 0~15	Input (I)
B	O0	ddd(dd)	ddd:0~254 (dd): 0~15	Output (O)
B	B3	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B3)
B	B10~13	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B10~13)
B	Bfn	fffddd(dd)	File no. fff: 3, 10~254 Element no. ddd: 0~254 Bit no. (dd): 0~15	Bit data file (B3, 10~254)
B	NfnBit	fffddd(dd)	File no. fff: 7, 10~254 Element no. ddd: 0~254 Bit no. (dd): 0~15	Integer data file bit level (N7, 10~254)
B	S_Bit	ddd(dd)	ddd:0~254 (dd): 0~15	Status file
W	T4SV	ddd	ddd:0~254	Timer Preset Value (T4)
W	T4PV	ddd	ddd:0~254	Timer Accumulator Value (T4)
W	C5SV	ddd	ddd:0~254	Counter Preset Value (C5)
W	C5PV	ddd	ddd:0~254	Counter Accumulator Value (C5)
W	TfnSV	fffddd	File no. fff:0~254 Element no. ddd:0~254	Timer Preset Value
W	TfnPV	fffddd	File no. fff:0~254 Element no. ddd:0~254	Timer Accumulator Value
W	CfnSV	fffddd	File no. fff:0~254 Element no. ddd:0~254	Counter Preset Value
W	CfnPV	fffddd	File no. fff:0~254 Element no. ddd:0~254	Counter Accumulator Value
W	N7	ddd	ddd:0~254	Integer data file (N7)
W	N10~15	ddd	ddd:0~254	Integer data file (N10~15)
W	F8	ddd	ddd:0~254	Floating point data file (F8)
W	Nfn	fffddd	File no. fff:0~254 Element no. ddd:0~254	Integer data file (N7, 10~254)
W	S	ddd	ddd:0~254	Status file


## Wiring diagram:

RS-485: SLC500 Fixed type, SLC5/01,02,03 CH1.


MT8000 can't connect to 1747-AIC PERIPHERAL PORT



RS-232: MicroLogix 1000, 1100, 1200, 1500 must set DH485 protocol.



RS-232: SLC5/03,04,05 CH0 must set DH485 protocol.



Caution: AB DH485 supports MT8000 X series only.

# Allen-Bradley EtherNet/IP CompactLogix

Allen-Bradley ControlLogix, CompactLogix, FlexLogix Ethernet

<http://www.ab.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Allen-Bradley EtherNet (CompactLogix)		
Com port	Ethernet		
Port no.	44818		
PLC Station No.	1		

## PLC Setting:

Communication mode	
--------------------	--


## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	Bx_BOOL	ffddd(dd)	File no. ff: 3, 10~99 Element no. ddd: 0~999 Bit no. (dd): 0~15	Bit data file
B	Nx_BOOL	ffddd(dd)	File no. ff: 7, 10~99 Element no. ddd: 0~999 Bit no. (dd): 0~15	Integer data file bit level (N7, 10~99)
W	Bx_INT	fffddd	File no. fff: 3, 10~255 Element no. ddd: 0~255	Bit data file word level
W	Nx_INT	fffddd	File no. fff:0~255 Element no. ddd:0~255	Integer data file (N7, 10~99)
F	F8_REAL	ddd	ddd:0~255	Floating point data file (F8)
F	Fx_REAL	fffddd	File no. fff:0~255 ddd:0~255	Floating point data file (F8)


DW	Tx.PRE	fffddd	File no. fff: 4, 10~255 Element no. ddd: 0~255	Timer Preset Value (T4, T10~255)
DW	Tx.ACC	fffddd	File no. fff: 4, 10~255 Element no. ddd: 0~255	Timer Accumulator Value (T4, T10~255)
DW	Cx.PRE	fffddd	File no. fff: 5, 10~255 Element no. ddd: 0~255	Counter Preset Value (C5, C10~255)
DW	Cx.ACC	fffddd	File no. fff: 5, 10~255 Element no. ddd: 0~255	Counter Accumulator Value (C5, C10~255)

## Wiring diagram:

Ethernet:






Ethernet: Direct connect (crossover cable)



RSLogix 5000 setting

Create the Tag:



# Allen-Bradley EtherNet/IP (DF1)

Allen-Bradley MicroLogix 1100, SLC5/05 Ethernet port.

MicroLogix1000, 1200, 1500, SLC 5/03, 5/04 with 1761-NET-ENI

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Allen-Bradley EtherNet/IP (DF1)		
Com port	Ethernet		
TCP Port no.	44818		
HMI Station No.	0		
PLC Station No.	1		

## PLC Setting:

Communication mode	<b>Port Setting: 10/100 Mbps Full Duplex/Half Duplex</b>
--------------------	--


## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I1	ddd(dd)	ddd:0~254 (dd): 0~15	Input (I)
B	O0	ddd(dd)	ddd:0~254 (dd): 0~15	Output (O)
B	B3	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B3)
B	Bfn	fffddd(dd)	File no. fff: 3, 10~254 Element no. ddd: 0~254 Bit no. (dd): 0~15	Bit data file (B3, 10~254)
B	NfnBit	fffddd(dd)	File no. fff: 7, 10~254 Element no. ddd: 0~254 Bit no. (dd): 0~15	Integer data file bit level (N7, 10~254)
W	T4SV	ddd	ddd:0~254	Timer Preset Value (T4)
W	T4PV	ddd	ddd:0~254	Timer Accumulator Value (T4)
W	C5SV	ddd	ddd:0~254	Counter Preset Value (C5)
W	C5PV	ddd	ddd:0~254	Counter Accumulator Value (C5)
W	N7	ddd	ddd:0~254	Integer data file (N7)
W	Nfn	fffddd	File no. fff:0~254	Integer data file (N7, 10~254)

			Element no. ddd:0~254	
32bit Float	F8	ddd	ddd:0~254	Floating point data file (F8)
32bit Float	Ffn	fffddd	File no. fff:0~254 Element no. ddd:0~254	Floating point data file (F8, 10~254)


## Wiring diagram:

Ethernet: Direct connect (crossover cable)




MT8000 Ethernet RJ45			Wire color	PLC RJ45	
1	TX+	White/Orange		3	RX+
2	TX-	Orange		6	RX-
3	RX+	White/Green		1	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		2	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-

Ethernet:



MT8000 Ethernet RJ45			Wire color	Ethernet Hub or Switch RJ45	
1	TX+	White/Orange		1	RX+
2	TX-	Orange		2	RX-



1 8

RJ45

connector

3	RX+	White/Green		3	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		6	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-

# Allen Bradley PLC5

<http://www.ab.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	AB PLC5		
Com port	RS232		
Baud rate	19200	9600, 19200	
Parity bit	None	Even, Odd, None	
Data Bits	8	8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	1-31	

## PLC Setting:

Communication mode	<b>DF1 Full Duplex protocol 19200, None, 8, 1 (default)</b>
--------------------	---

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I1	ddd(dd)	ddd:0~254 (dd): 0~15	Input (I)
B	O0	ddd(dd)	ddd:0~254 (dd): 0~15	Output (O)
B	B3	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B3)
B	B10~13	ddd(dd)	ddd:0~254 (dd): 0~15	Bit data file (B10~13)
W	T4SV	ddd	ddd:0~254	Timer Preset Value (T4)
W	T4PV	ddd	ddd:0~254	Timer Accumulator Value (T4)
W	C5SV	ddd	ddd:0~254	Counter Preset Value (C5)
W	C5PV	ddd	ddd:0~254	Counter Accumulator Value (C5)
W	N7	ddd	ddd:0~254	Integer data file (N7)
W	N10~15	ddd	ddd:0~254	Integer data file (N10~15)
W	F8	ddd	ddd:0~254	Floating point data file (F8)
W	Nfn	fffddd	File no. fff:7,9~254 Element no. ddd:0~254	Integer data file (V2.5.0 or newer)
W	Ffn	fffddd	File no. fff:8,9~254	Floating point data file (V2.5.0 or newer)

Bit/Word	Device Type	Format	Range	Memo
			Element no. ddd:0~254	newer)

Allen-Bradley PLC-5 Family PLCs using the DF1 Full Duplex protocol.

For the PLC-5/10, PLC-5/15 and PLC-5/25 the MT8000 should be connected to:

- the DF1 port on the 1785-KE module;

for the PLC-5/11, PLC-5/20, PLC-5/30 and PLC-5/40 the MT8000 should be connected to:

- the Channel 0 Port on the PLC.

## Wiring diagram:

RS-232: PLC5 CPU CH0

EasyView MT8000

9P D-SUB

COM1 [RS232]	COM2 [RS232]	COM3 [RS232]
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

AB CPU CH0 RS-232

25P D-SUB

3 RXD
2 TXD
7 GND

# Baumuller Servo

<http://www.baumuller.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Baumuller		
Com port	RS485 4W COM1		
Baud rate	19200	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	8	7 or 8	
Stop Bits	1	1 or 2	
HMI Station No.	0		
PLC Station No.	0	Defaults	

## Baumuller Servo Setting:

Communication mode	<b>RK 512 Protocol, 19200, 8, 1, EVEN</b>
--------------------	---

## Device address:

Bit/Word	Device Type	Format	Range	Device Range
B	DB0_bit	ddd(h)	ddd:0~255 (h): 0~f	DB0_bit~DB29_bit
W	DB0	ddd	ddd:0~255	DB0~DB29

## Wiring diagram:

RS-485 4W:

**MT8000 HMI COM1**


**RS485 4W 9P D-SUB**

Female

1	RX-
2	RX+

Baumuller servo  
RS-422 9P D-SUB  
Female

1	TXD-
9	TXD+



# Copley Controls

Digital Servo Driver & Controllers, Xenus, Xenus Micro, Accelnet, Accelnet Micro, Stepnet series

<http://www.copleycontrols.com/motion/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Copley Controls		
Com port	RS232		
Baud rate	9600	9600~115200	
Parity bit	None	Even, Odd, None	
Data Bits	8	8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	0	0-127	

## PLC Setting:

Communication mode	<b>ASCII format</b>
--------------------	---------------------

## Device address:



Bit/Word	Device Type	Format	Range	Memo
W	Flash INT 16	hhh	0~FFF	For Register is INT16 or U16
W	RAM INT 16	hhh	0~FFF	For Register is INT16 or U16
W	Flash INT 32	hhh	0~FFF	For Register is INT32 or U32
W	RAM INT 32	hhh	0~FFF	For Register is INT32 or U32

## Wiring diagram:

Xenus, Xenus Micro, Accelnet

MT8000 RS232  
9P D-SUB


Xenus Micro Panel  
RS-232 RJ11  
J7 cable connector



### Stepnet

MT8000 RS232  
9P D-SUB

Stepnet  
RS232 RJ11  
J8 cable connector




COM1	COM2	COM3		
3 TX	4 TX	7 TX	2	RXD
2 RX	6 RX	8 RX	5	TXD
5 GND	5 GND	5 GND	3, 4	GND

### Accelnet Micro

MT8000 RS232  
9P D-SUB

Accelnet Micro Panel  
RS-232  
J5 cable connector



COM1	COM2	COM3		
3 TX	4 TX	7 TX	14	RXD
2 RX	6 RX	8 RX	29	TXD
5 GND	5 GND	5 GND	15	GND

# DELTA DVP

DELTA DVP series

<http://www.deltadrivers.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	DELTA DVP		
Com port	RS232	RS232, RS485	
Baud rate	9600	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	7	7, 8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	0-255	

## PLC Setting:



Communication mode	
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0 ~ 23417 (Octal)	Input
B	Y	ooo	0 ~ 23417 (Octal)	Output
B	M	dddd	0 ~ 9999	Auxiliary Relay
B	S	dddd	0 ~ 9999	Step Relay
B	T	dddd	0 ~ 9999	Timer
B	C	dddd	0 ~ 9999	Counter
B	TV	dddd	0 ~ 9999	Timer
W	CV	ddd	0 ~ 127	Counter
W	CV2	ddd	232 ~ 255	Double word counter
W	D	dddd	0 ~ 9999	Data Register


## Wiring diagram:

### 1. RS232: CPU port



8Pin Mini-Din Female

### 2. RS485: CPU port



# FATEK FB series

FATEK FBs series, FB MC series, FB MA series need FB-DTBR converter.

<http://www.fatek.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	FATEK FB Series		
Com port	RS232	RS232/RS485/Ethernet	Must match the PLC's port setting.
Baud rate	9600		Must match the PLC's port setting.
Parity bit	Even		Must match the PLC's port setting.
Data Bits	7		
Stop Bits	1		
HMI Station No.	0		Does not apply to this protocol.
PLC Station No.	1	0-255	Must match the PLC's port setting.

## PLC Setting:

Communication mode	
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ddd	ddd : 0~9999	Input
B	Y	ddd	ddd : 0~9999	Output
B	M	ddd	ddd : 0~9999	Internal Relay
B	S	ddd	ddd : 0~9999	Step Relay
B	T	ddd	ddd : 0~9999	Timer
B	C	ddd	ddd : 0~9999	Counter
W	R	ddd	ddd : 0~9999	Data Register
W	D	ddd	ddd : 0~9999	Data Register
W	RT	ddd	ddd : 0~9999	Timer Register
W	RC	ddd	ddd : 0~9999	Counter Register
DW	DRT	ddd	ddd : 0~9999	Double word Timer Register

DW	DRC	ddd	ddd : 0~9999	Double word Counter Register
----	-----	-----	--------------	------------------------------

## Wiring diagram:

### 1. RS232: CPU port

**MT8000 RS232**

9P D-SUB Male

COM1		COM2		COM3	
3	TX	4	TX	7	TX
2	RX	6	RX	8	RX
5	GND	5	GND	5	GND

FB CPU port

15P D-SUB Male

1	RX
2	TX
6	GND
3	RTS
4	CTS

### 2. RS485: CPU port

**MT8000**

**COM[RS-485] 2w**

9P D-SUB Female

COM1		COM3	
1	RX-	6	Data-
2	RX+	9	Data+

FB CPU port

15P D-SUB Male

7	D-
5	D+

### 3. RS232: FB-DTBR/DTBR-E

**MT8000 RS232**

9P D-SUB Male

COM1		COM2		COM3	
3	TX	4	TX	7	TX
2	RX	6	RX	8	RX
5	GND	5	GND	5	GND

FB-DTBR/DTBR-E

15P D-SUB Male

1	RX
2	TX
6	GND
3	RTS
4	CTS

4. RS485: FB-DTBR/DTBR-E

**MT8000 RS232**

9P D-SUB Male

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

FB-DTBR/DTBR-E

9P D-SUB Male

3	RX
4	TX
1	GND

5. RS485: FB-DTBR/DTBR-E

**MT8000**

**COM[RS-485] 2w**

9P D-SUB Female

COM1	COM3
1 RX-	6 Data-
2 RX+	9 Data+

FB-DTBR/DTBR-E

3P Terminal Block

D-
D+

6. RS232: FBs Port0

**MT8000 RS232**


9P D-SUB Male

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

FB-DTBR/DTBR-E

4P Mini-Din Male

4	RX
3	TX
2	GND



4P Mini-Din Female

# GE Fanuc SNP-X

GE Fanuc 90 & VersaMax series PLC

<http://www.ge.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	GE Fanuc SNP-X		
Com port	RS485 4w	RS232/RS485	
Baud rate	19200	9600,19200,38400,57600,115200	Must same as the PLC setting
Parity bit	Odd	Even, Odd, None	Must same as the PLC setting
Data Bits	8	7,8	Must set as 8 to this protocol
Stop Bits	1	1, 2	Must same as the PLC setting
HMI Station No.	0	0-255	Does not apply to this protocol
PLC Station No.	0	0-255	Does not apply to this protocol

## PLC Setting:

Refer to related PLC manual


## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I	ddd	1-10000	Input relay
B	Q	ddd	1-10000	Output relay
B	M	ddd	1-10000	Auxiliary relay
B	G	ddd	1-7680	
B	T	ddd	1-256	
W	AI	ddd	1-10000	Analog input register
W	AQ	ddd	1-10000	Analog output register
W	R	ddd	1-32640	Data register
B	SA	ddd	1-128	
B	SB	ddd	1-128	
B	SC	ddd	1-128	
B	S	ddd	1-128	



## Wiring diagram:

Memo : 90 VersaMax series PLC of GE FANUC includes such series as 90-30, 90-70, VersaMax Micro, VersaMax Nano and VersaMax,etc., CPU of 90-30series can pass RS485 serial com port on module, utilize SNP serial communication protocol of GE to connect with EasyView MT8000HMI, In addition, CPU331/340/341/350/351/352/360/363/364 can also connect through CMM311 Communication Module, CPU351/352/363/364 also can connect through serial com port on CPU Unit ; 90-70 series CPU can also connect through CMM711 Communication Module or connect through serial com port on CPU Unit ; Relevant software and hardware are set up concretely please consult the technical manual that GE GE Fanuc offered.

### CPU port(90-30/VersaMax)



### CPU port(90-30 series CPU351/352/363/364)



6P RJ-11 Female

MT8000 RS232

9P D-SUB

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

VersaMax series

RS232 port

9P SUB-D Female

3 RX
2 TX
5 GND

CPU port(VersaMax series CPU001/002/005/E05)

MT8000 RS232

9P D-SUB

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

VersaMax series

RS232 port

9P SUB-D Female

3 RX
2 TX
5 GND

# GE Fanuc Series 90-30 (Ethernet)

GE 90-30 series, CPU model 374plus

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	GE fanuc series 90-30 (Ethernet)		
Com port	Ethernet		
PLC station No.	1	1~99	
Port No.	18245		

## Device address:

Bit/Word	Device type	Format	Range	Memo
B	I_bit	dddd	1 ~ 2048	
B	Q_bit	dddd	1 ~ 2048	
B	M_bit	dddd	1 ~ 4096	
B	G_bit	dddd	1 ~ 1280	
B	T_bit	ddd	1 ~ 256	
B	SA_bit	dd	1 ~ 32	Read Only
B	SB_bit	dd	1 ~ 32	Read Only
B	SC_bit	dd	1 ~ 32	Read Only
B	S_bit	dd	1 ~ 32	Read Only
W	I	dddd	1 ~ 2033	Address increases 8 words, ex: I1, I9, I17, I25.....
W	Q	dddd	1 ~ 2033	the rule is same as above, ex:Q1, Q9, Q17...
W	M	dddd	1 ~ 4081	the rule is same as above, ex:M1, M9, M17..
W	G	dddd	1 ~ 1256	the rule is same as above, ex:G1, G9, G17...
W	T	ddd	1 ~ 241	the rule is same as above, ex:T1, T9, T17....
W	SA	dd	1 ~ 17	Read Only, the rule is same as above



W	SB	dd	1 ~ 17	Read Only, the rule is same as above
W	SC	dd	1 ~ 17	Read Only, the rule is same as above
W	S	dd	1 ~ 17	Read Only, the rule is same as above
W	R	dddd	1 ~ 9999	
W	AI	dddd	1 ~ 2048	
W	AQ	ddd	1 ~ 512	

## Wiring diagram:

### Ethernet:

MT8000 Ethernet Wire color  
RJ45

Ethernet Hub or  
Switch RJ45



1 8

RJ45  
connector

### Ethernet: Direct connect (crossover cable)

MT8000 Ethernet Wire color

Modbus TCP Device

RJ45

RJ45

1	TX+	White/Orange	—————	3	RX+
2	TX-	Orange	—————	6	RX-
3	RX+	White/Green	—————	1	TX+
4	BD4+	Blue	—————	4	BD4+
5	BD4-	White/Blue	—————	5	BD4-
6	RX-	Green	—————	2	TX-
7	BD3+	White/Brown	—————	7	BD3+
8	BD3-	Brown	—————	8	BD3-

# HAN YOUNG

Temperature Controller

<http://hynux.com/kor/>


## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Heng Young Seires		
Com port	RS485 4W		Must match the PLC's port setting.
Baud rate	9600		Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	7 or 8	Must match the PLC's port setting.
Stop Bits	1	1 or 2	Must match the PLC's port setting.
PLC Station No.	1	0-255	Must match the PLC's port setting.

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I	ddd	1-699	
W	D	ddd	1-699	

## Wiring diagram:



# Heng Yuan Sensor

EU series, EU5 series, EU10 series.

<http://www.hysensor.com.cn>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Heng Yuan Sensor		
Com port	RS485 2W		
Baud rate	9600		
Parity bit	Even		
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		
PLC Station No.	2	1-31	

Online Simulator	YES	
Extend address mode	YES	

## PLC Setting:

Communication mode	
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
W	Parameter	ddd	ddd:0~1000	


## Wiring diagram:

EU05 series

MT8000 PLC[485]

9P D-SUB

COM1	COM3	RS485 port
1 RX-	6 Data-	7 RX- (Yellow)
2 RX+	9 Data+	5 RX+ (Green)
5 GND	5 GND	4 GND (Black)



## HITACHI H series (CPU port)

Compatible PLCs	
Family	Model
HITACHI H series	EH-150, Micro-EH, H20, H40, H64, H200, H250, H252, H300, H302, H700, H702, H1000, H1002, H2000, H4010

HITACHI Web site: <http://www.hitachi-ies.co.jp/english/products/plc/index.htm>

### HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	HITACHI H-Series		
Com port	RS232	RS232, RS485	Must match the PLC's port setting.
Baud rate	19200	9600, 19200, 38400	Must match the PLC's port setting.
Parity bit	Even	Even	Must match the PLC's port setting.
Data Bits	7	7	Must match the PLC's port setting.
Stop Bits	1	1	Must match the PLC's port setting.
HMI Station No.	0	0-255	Does not apply to this protocol.
PLC Station No.	0	0-255	Does not apply to this protocol.

Online Simulator	YES	Broadcast command	NO
Extend address mode	NO		

### PLC Setting:


Communication mode	<b>19200,E,7,1(default)</b>
Select	

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	hhh(h)	hhh: 0~FFFF (h):0~F	External Input-bit(X)
B	Y	hhh(h)	hhh: 0~FFFF (h):0~F	External Output-bit(Y)
B	M	hhh(h)	hhh: 0~FFFF (h):0~F	Data area-bit(M)
B	T	hhh(h)	hhh: 0~FFFF (h):0~F	Timer(T)
B	R	hhh(h)	hhh: 0~FFFF (h):0~F	Internal Output(R)
B	L	hhh(h)	hhh: 0~FFFF (h):0~F	Link area-bit(L)
W	TC	hhh	hhh: 0~FF	Timer/Counter current value
W	WX	hhh	hhh: 0~270F	External Input-word(X)
W	WY	hhh	hhh: 0~270F	External Output-word(Y)
W	WR	hhh	hhh: 0~270F	Internal Output-word(R)
W	WL	hhh	hhh: 0~270F	Link area-word(L)
W	WM	hhh	hhh: 0~270F	Data area-word(M)


## Wiring diagram:

WARNING: If your communications cable is not wired exactly as shown in our cable assembly instructions, damage to the MT8000 or loss of communications can result.




CPU TYPE	Port 1	Port 2
EH-150/CPU 104A	RS-232	RS-232
EH-150/CPU 208A	RS-232	RS-232
EH-150/CPU 308A	RS-232/RS-485	RS-232
EH-150/CPU 316A	RS-232/RS-485	RS-232
EH-150/CPU 448A	RS-232/RS-485	RS-232

Switch Number					
1	OFF	Normal mode			
2	OFF	TRNS0 operation			
3, 4	3	4	Port1 transmission speed		
	ON	ON	4,800 bps		Doesn't support
	OFF	ON	9,600 bps		
	ON	OFF	19,200 bps		Default
	OFF	OFF	38,400 bps		
5	ON	Dedicated port			



6	6	PHL	Port2 transmission speed	
	ON	Low	9,600 bps	
	ON	High	38,400 bps	
	OFF	Low	4,800 bps	Doesn't support
	OFF	High	19,200 bps	Default
7	OFF	(System mode)		Do not turn on.
8	OFF	(System mode)		Do not turn on.

Toggle-Switch



**EH-150 port1 RS232**

MT8000 RS-232

9P D-SUB


COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

HITACHI EH-150

port1

8pin RJ45 Male

6 RD
5 SD
1 SG
4 PHL
7 DR



Port 1  
8pin RJ45  
Female

**EH150port1 RS485 4wire (RS422) :**

EasyView MT8000 HMI

PLC RS485port

9PinD-SUB FEMALE

1 RX-
2 RX+
3 TX-
4 TX+
5 GND

Hitachi EH-150

port1

8PinRJ45port

5 TX-
4 TX+
6 RX-
7 RX+
1 SG

**EH150port1 RS485 2wire :**

EasyView MT8000 HMI

PLC RS485 port

9PinD-SUB FEMALE

1 RX-
2 RX+
3 TX-
4 TX+
5 GND

Hitachi EH-150 port1

8PinRJ45 port

5 TX-
4 TX+
6 RX-
7 RX+
1 SG

EH-150 port2 RS232


MT8000 PLC[232]

9P D-SUB Male

COM1	COM2	COM3
2 RX	6 RX	8 RX
3 TX	4 TX	7 TX
5 GND	5 GND	5 GND
7 RTS		
8 CTS		

HITACHI EH-150 port2  
8pin RJ45 Male

5 SD
6 RD
1 SG
7 DR
8 RS



Port 2  
8pin RJ45  
Female


MT8000 PLC[232]

9P D-SUB Male

COM2	COM3
6 RX	8 RX
4 TX	7 TX
5 GND	5 GND

HITACHI EH-150 port2  
8pin RJ45 Male

5 SD
6 RD
1 SG
4 PHL
7 DR



Port 2  
8pin RJ45  
Female

H series CPU RS232 port

MT8000 PLC[232]

9P D-SUB Male

COM1
3 TX
2 RX
5 GND
8 CTS

HITACHI H series CPU RS232  
15p D-SUB Male

3 RXD
2 TXD
9 SG
4 RTS
10 SG
5 CTS
7 DSR
8 PHL
14 PV12

MICRO-EH port1 RS232

MT8000 RS-232

9P D-SUB


COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

HITACHI EH-150

port1

8pin RJ45 Male

6 RD
5 SD
1 SG
4 PHL
7 DR



Port 1  
8pin R.J45

# IDEC

IDEC Micro3, Micro3C, MicroSmart, OpenNet Controller series

<http://www.idec.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	IDEC Micro		Support Extend address mode
Com port	RS232	RS232, RS485	
Baud rate	9600	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	7	7, 8	
Stop Bits	1	1	
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	255 (for 1:1 connect)	0-255	255 or same as the PLC setting

Online Simulator	YES	
Extend address mode	YES	Don't set the PLC Station No.= 255

## PLC Setting:

Communication mode	<b>9600,E,7,1(default), Use Computer Link Protocol</b>
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ddd(o)	ddd=0~2047, (o)=0~7	Input(I)
B	Y	ddd(o)	ddd=0~2047, (o)=0~7	Output(Q)
B	M	ddd(o)	ddd=0~2047, (o)=0~7	Internal Relay(M)
W	RT	ddd	ddd=0~9999	Timer(T)
W	RC	ddd	ddd=0~9999	Counter(C)
W	D	ddd	ddd=0~9999	Data Register(D)


# Wiring diagram:

RS232: Micro3C, MicroSmart, OpenNet Controller CPU Ladder Port

MT8000 RS232



CPU port 1 or port2 RS-232

8P mini DIN Male



COM1	COM2	COM3	
3 TX	4 TX	7 TX	4 RXD
2 RX	6 RX	8 RX	3 TXD
5 GND	5 GND	5 GND	7 GND

8Pin mini DIN Female Pin




RS485: Micro3 CPU Port, MicroSmart with FC4A-PC2 RS485 Communication Adapter

MT8000 RS-485

CPU Port RS-485

8P mini DIN Male



COM1	COM3	
1 RX-	6 Data-	2 RXD-
2 RX+	9 Data+	1 RXD+
5 GND	5 GND	7 GND

8Pin mini DIN Female Pin


RS485: Micro3C, OpenNet Controller Data Link Terminals, MicroSmart with FC4A-PC3 RS485 Communication Adapter

MT8000 RS-485

Data Link Terminals

9P D-SUB Female

COM1	COM3	
1 RX-	6 Data-	A RXD-
2 RX+	9 Data+	B RXD+
5 GND	5 GND	SG GND



# KEYENCE KV series

KEYENCE KV series, KV10~80

<http://www.keyence.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	KEYENCE KV-16		
Com port	RS232	RS232	Must match the PLC's port setting.
Baud rate	9600		Must match the PLC's port setting.
Parity bit	Even		Must match the PLC's port setting.
Data Bits	8		
Stop Bits	1		
PLC Station No.	1		Must match the PLC's port setting.

## PLC Setting:

Communication mode	None
--------------------	------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	RLY	ddd(h)0	0~19999	
B	MR	ddd(h)	0~19999	
B	LR	ddd(h)	0~19999	
B	CR	ddd(h)	0~19999	
B	DM_Bit	ddd(h)	0~19999	
W	DM	ddd	0-1999	
W	TM	ddd	0-99	
W	CM	ddd	0~65535	
W	EM	ddd	0~65535	
W	T	ddd	0-999	
W	Timer_Curr	ddd	0-999	Timer_Current
W	Timer_Preset	ddd	0-999	
W	C	ddd	0-999	
W	Counter_Curr	ddd	0-999	Counter_Current

W	Counter_Preset	ddd	0-999	
---	----------------	-----	-------	--

**Precaution:**

If you use the Relay(bit) register, Please place zero behind address. For example, If you want to read Relay(bit)100, you just set the address as “1000”.

## Wiring diagram:

RS232: CPU port

MT8000 RS-232 9P D-SUB

KEYENCE PLC

OP-26486

COM1	COM2	COM3		
3 TX	4 TX	7 TX	—	2 RXD
2 RX	6 RX	8 RX		3 TXD
5 GND	5 GND	5 GND		5 GND

# KEYENCE KV-1000

<http://www.keyence.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	KEYENCE KV-1000		
Com port	RS232	RS232	Must match the PLC's port setting.
Baud rate	9600		Must match the PLC's port setting.
Parity bit	Even		Must match the PLC's port setting.
Data Bits	8		
Stop Bits	1		
PLC Station No.	0		Must match the PLC's port setting.

## PLC Setting:

Communication mode	None
--------------------	------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	RLY	ddd(h)0	0~19999	
B	MR	ddd(h)	0~19999	
B	LR	ddd(h)	0~19999	
B	CR	ddd(h)	0~19999	
B	DM_Bit	ddd(h)	0~19999	
W	DM	ddd	0-1999	
W	TM	ddd	0-99	
W	CM	ddd	0~65535	
W	EM	ddd	0~65535	
W	T	ddd	0-999	
W	Timer_Curr	ddd	0-999	Timer_Current
W	Timer_Preset	ddd	0-999	
W	C	ddd	0-999	

W	Counter_Curr	ddd	0-999	Counter_Current
W	Counter_Preset	ddd	0-999	

Precaution:

If you use the Relay(bit) register, Please place zero behind address. For example, If you want to read Relay(bit)100, you just set the address as “1000”.

## Wiring diagram:

RS232: CPU port

MT8000 RS-232 9P D-SUB

KEYENCE PLC

OP-26486

COM1	COM2	COM3		
3 TX	4 TX	7 TX	—	2 RXD
2 RX	6 RX	8 RX		3 TXD
5 GND	5 GND	5 GND		5 GND

# Korenix 6550 / 6520

<http://www.korenix.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Korenix 6550/ 6520		Modbus protocol
COM port	Ethernet		
PLC station No.		0	
Port No.	502		

## Device address:

Bit/Word	Device type	Format	Range	Memo
W	3X	dddd	1~65535	
W	4X	dddd	1~65535	
W	5X	dddd	1~65535	
W	6X	dddd	1~65535	
B	0X	dddd	1~65535	
B	1X	dddd	1~65535	
B	3x_Bit	dddd	1~65535	
B	4x_Bit	dddd	1~65535	
B	6x_Bit	dddd	1~65535	


## Wiring diagram:

Ethernet:

MT8000 Ethernet Wire color  
RJ45

Ethernet Hub or  
Switch RJ45

1	TX+	White/Orange		1	RX+
2	TX-	Orange		2	RX-
3	RX+	White/Green		3	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		6	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-



1 8  
RJ45

Ethernet: Direct connect (crossover cable)

MT8000 Ethernet Wire color

Modbus TCP Device

RJ45

RJ45

1	TX+	White/Orange	—————	3	RX+
2	TX-	Orange	—————	6	RX-
3	RX+	White/Green	—————	1	TX+
4	BD4+	Blue	—————	4	BD4+
5	BD4-	White/Blue	—————	5	BD4-
6	RX-	Green	—————	2	TX-
7	BD3+	White/Brown	—————	7	BD3+
8	BD3-	Brown	—————	8	BD3-

# KOYO DirectLogic

KOYO DirectLogic series PLC DL05, DL06, DL105, DL205, DL305 and DL405 series

<http://www.automationdirect.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	KOYO DIRECT		
Com port	RS232	RS232, RS485	
Baud rate	9600	9600, 19200, 38400	
Parity bit	Odd	Even, Odd, None	
Data Bits	8	7, 8	
Stop Bits	1	1	
HMI Station No.	0		Does not apply to this protocol.
PLC Station No.	1	1-90	

## PLC Setting:

	<ol style="list-style-type: none"> <li>1. The PLC must not have a password.</li> <li>2. PLC must be set for Full Duplex operation.</li> <li>3. PLC must be set for No Hardware Handshaking.</li> <li>4. The PLC must be set to use the 'K' Sequence Protocol.</li> <li>5. Set the mode switch to the TERM mode</li> <li>6. When using the D4-440 CPU, you must set the station number to 1.</li> </ol>
--	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	0000	0 ~ 4000	Input Bits
B	Y	0000	0 ~ 4000	Output Bits
B	C	00000	0 ~ 10000	Control Relays
B	T	0000	0 ~ 1000	Timer Status Bits
B	CT	0000	0 ~ 1000	Counter Status Bits
B	S	0000	0 ~ 2000	
B	SP	0000	0 ~ 2000	
B	GX	00000	0 ~ 10000	


B	GY	00000	0 ~ 10000	
W	Timer	0000	0 ~ 1000	
W	Counter	0000	0 ~ 1000	
W	V	0000	0 ~ 77777	V Memory

## Wiring diagram:


### 1. CPU unit: DL05/DL06/DL105/DL230/DL240/DL250/DL350/DL450 RS232 port



### 2. CPU unit: DL06/DL250 CPU Port2 RS232





### 3. CPU unit: DL06/DL250 CPU Port2 RS422





12	RTS-
15	CTS-

Note: DL06/DL250 CPU Port2 include RS232 and RS422


4. CPU unit: DL430/DL440/DL450 CPU unit Port0 RS232




5. CPU unit: DL430/DL440/DL450 CPU unit Port1 & DL350 CPU unit Port2 RS232



6. CPU unit: DL430/DL440/DL450 CPU unit Port1 & DL350 CPU unit Port2 RS422





7. CPU unit: DL450 CPU unit Port3 RS422

MT8000

KOYO DirectLogic PLC  
DL405 CPU RS422 Port3  
25P D-SUB Female

COM1[RS-485]4w

9P D-SUB




8. Communication unit: DL205 series D2-DCM and DL405 series D4-DCM RS232

MT8000 RS232

KOYO DirectLogic PLC  
DL205/405 DCM RS232 Port

9P D-SUB

25P D-SUB Female



# LS MASTER-K Cnet

LS MASTER-K series: K80S, K200S, K300S, K1000S

<http://www.lgis.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	LS MASTER-K Cnet		
Com port	RS232	RS232/RS485	Must match the PLC's port setting.
Baud rate	38400	9600, 19200, 38400	Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	8	Must match the PLC's port setting.
Stop Bits	1	1	Must match the PLC's port setting.
HMI Station No.	0		Does not apply to this protocol.
PLC Station No.	0	0-31	Must match the PLC's port setting.

Online Simulator	YES	
Extend address mode		

## PLC Setting:


Communication mode	<b>38400, None, 8, 1</b>
--------------------	--------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	P	ddd(h)	0~255F	I/O Relay (P)
B	K	ddd(h)	0~255F	Keep Relay (K)
B	M	ddd(h)	0~255F	Auxiliary Relay (M)
B	L	ddd(h)	0~255F	Link Relay (L)
B	F	ddd(h)	0~255F	Special Relay (F)
W	TV	ddd	0~255	Timer Present Value
W	CV	ddd	0~255	Counter Present Value
W	D	dddd	0~9999	Data Register (D)

d: Decimal h: Hexadecimal

## Wiring diagram:



If connect with Cnet module please refer Cnet module's document.

# LS MASTER-K300S CPU

LS MASTER-K series: K80S, K120S, K200S, K300S, K1000S

<http://www.lgis.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	LG MASTER-K300S		
Com port	RS232	RS232/RS485	Must match the PLC's port setting.
Baud rate	38400	9600, 19200, 38400	Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	8	Must match the PLC's port setting.
Stop Bits	1	1	Must match the PLC's port setting.
HMI Station No.	0		Does not apply to this protocol.
PLC Station No.	0	0-31	Must match the PLC's port setting.

Online Simulator	YES	
Extend address mode		

## PLC Setting:

Communication mode	<b>38400, None, 8, 1</b>
--------------------	--------------------------


## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	P	ddd(h)	0~255F	I/O Relay (P)
B	K	ddd(h)	0~255F	Keep Relay (K)
B	M	ddd(h)	0~255F	Auxiliary Relay (M)
B	L	ddd(h)	0~255F	Link Relay (L)
B	F	ddd(h)	0~255F	Special Relay (F)
W	TV	ddd	0~255	Timer Present Value
W	CV	ddd	0~255	Counter Present Value

W	D	dddd	0~9999	Data Register (D)
---	---	------	--------	-------------------

d: Decimal h: Hexadecimal

### Wiring diagram:



# LS XGB/XGT

LS XGB/XGT Series

<http://www.lgis.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	LS XGB/XGT		
Com port	RS232	RS232/RS485	Must match the PLC's port setting.
Baud rate	115200	9600~115200	Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	7, 8	Must match the PLC's port setting.
Stop Bits	1	1	Must match the PLC's port setting.
HMI Station No.	0		
PLC Station No.	1	0-31	Must match the PLC's port setting.

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	P	ddd(h)	0~127F	I/O device_2,048 points
B	M	ddd(h)	0~255F	Internal device_4,096 points
B	L	dddd(h)	0~1279F	Communication device_20,480 points
B	K	dddd(h)	0~2559F	Preservation device_4,096 points
B	F	ddd(h)	0~255F	Special device_4,096 point
B	T	ddd	0~255	Timer device_256 point
B	C	ddd	0~255	Counter device_256 point
B	S	ddd(dd)	0~127(99)	Relay for step control
B	D_Bit	dddd(h)	0~5120F	Data register_Bit expression (D0000.0)
W	D	dddd	0~5119	Data register_5120 words
W	U	d(dd)	0~7(0~31)	Analog data register_256 words
W	N	dddd	0~3935	Communication data register_3,936 words
W	Z	ddd	0~127	Index register_128 words
W	T	ddd	0~255	Timer current value register_256 words
W	C	ddd	0~255	Counter current value register_256 words

d:Decimal h:Hexadecimal

## Wiring diagram:

RS-232:



MT8000 RS232  
9P D-SUB

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

XGB main unit  
RS232 6pin

2	RXD
6	TXD
3	GND

6pin female pinout



# LS XGB/XGT TCP/IP series

LS XGB/XGT TCP/IP Series

<http://www.lgis.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	XBL-EMTA		
Com port	Ethernet		
PLC Station no.	0	0~255	
TCP/IP port	2004		

## PLC Setting:

Communication mode	Fenet Potocol
--------------------	---------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	P	ddd(h)	0~127F	I/O device_2,048 points
B	M	ddd(h)	0~255F	Internal device_4,096 points
B	L	dddd(h)	0~1279F	Communication device_20,480 points
B	K	dddd(h)	0~2559F	Preservation device_4,096 points
B	F	ddd(h)	0~255F	Special device_4,096 point
B	T	ddd	0~255	Timer device_256 point
B	C	ddd	0~255	Counter device_256 point
B	S	ddd(dd)	0~127(99)	Relay for step control
B	D_Bit	dddd(h)	0~5120F	Data register_Bit expression (D0000.0)
W	D	dddd	0~5119	Data register_5120 words
W	U	d(dd)	0~7(0~31)	Analog data register_256 words
W	N	dddd	0~3935	Communication data register_3,936 words
W	Z	ddd	0~127	Index register_128 words
W	T	ddd	0~255	Timer current value register_256 words
W	C	ddd	0~255	Counter current value register_256 words

d:(Decimal) h:(Hexadecimal)

# Wiring diagram:

## Ethernet:


MT8000 Ethernet Wire color

Ethernet Hub or Switch

RJ45

RJ45

1	TX+	White/Orange		1	RX+
2	TX-	Orange		2	RX-
3	RX+	White/Green		3	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		6	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-



1 8  
RJ45

## Ethernet: Direct connect (crossover cable)

MT8000

Wire color

TCP Device

Ethernet RJ45

RJ45

1	TX+	White/Orange		3	RX+
2	TX-	Orange		6	RX-
3	RX+	White/Green		1	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		2	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-

# LIYAN EX series

LIYAN PLC Ex/Ex1s/Ex1n/Ex2n series

<http://www.liyanplc.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Mitsubishi FX0n/FX2		
Com port	RS232	RS232	Must match the PLC's port setting.
Baud rate	9600	9600~115200	Must match the PLC's port setting.
Parity bit	Even	Even, Odd, None	Must match the PLC's port setting.
Data Bits	7	7,8	Must match the PLC's port setting.
Stop Bits	1	1,2	Must match the PLC's port setting.
HMI Station No.	0	0-255	Does not apply to this protocol.
PLC Station No.	0	0-255	Must match the PLC's port setting.

## PLC Setting:

Communication mode	<b>9600,7,1,Even</b>
--------------------	----------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0-377	Input relay
B	Y	ooo	0-377	Output relay
B	M	ddd	0-9999	Internal bit memory
B	T	ddd	0-255	Timer bit memory
B	C	ddd	0-255	Counter bit memory
W	TV	ddd	0-255	Timer register
W	CV	ddd	0~199	Counter Register
W	D	ddd	0-9999	data Register
W	CV2	ddd	200-255	Counter Register(Double word)
W	SD	ddd	8000-9999	Special data register


# Wiring diagram:

Ex,Ex1s,Ex1n,Ex2n series RS232

MT8000 RS232  
9P D-SUB

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

LIYAN Ex series  
CPU RS232 Port  
8P miniDin Female



8Pin miniDin  
Female


4	RXD
7	TXD
8	GND

# Master (Master-Slave Protocol)

MT500 series


## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Master (Master-Slave Protocol)		
Com port	RS232		
Baud rate	115200	38400, 115200	
Parity bit	Even		
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		
PLC Station No. Parameter 1	0 MT500 PLC ID		Use PLCAddressView.exe find PLC ID.



## PLC Setting:

Communication mode	MT500 Multiple HMI set Slave
--------------------	------------------------------



PLC/Address Type ID	Bit/Word	Address Type	Addressing Format	Max	Min
MITSUBISHI FX0n/FX2	PLC ID=10				
0	Bit(HMI)	LB	ddd	9999	0
1	Bit(PLC)	X	ooo	377	0
2	Bit(PLC)	Y	ooo	377	0
3	Bit(PLC)	M	ddd	9999	0
4	Bit(PLC)	T	ddd	255	0
5	Bit(PLC)	C	ddd	255	0
8	Word(HMI)	LW	ddd	9999	0
9	Word(PLC)	TV	ddd	255	0
10	Word(PLC)	CV	ddd	199	0
11	Word(PLC)	D	ddd	9999	0
12	D/Word(PLC)	CV2	ddd	255	200
13	Word(PLC)	SD	ddd	9999	0000
121	Word(HMI)	RW	ddd	32767	0
120	Bit(HMI)	RjB	ddd(h)	2047	0
140	Bit(HMI)	RB	ddd(h)	2047	0
141	Word(HMI)	RW	ddd	65535	0
160	Bit(HMI)	Ms_RB	ddd(h)	4095	0
161	Bit(HMI)	Ms_LB	ddd	9999	0
100	Word(HMI)	Ms_RW	ddd	65535	0

## Device address:

Bit/Word	MT500	MT8000	Range	Memo
B	Ms_RB	RW_Bit	ddd:0~4095 (h): 0~f	
B	Ms_LB	LB	dddd:0~9999	

W	Ms_RW	RW	ddd:0~65535	
W	Ms_LW	LW	ddd:0~9999	

# Memobus (YASKAWA MP Series controllers)

YASKAWA MP2200, MP2300, MP9xx communication module

<http://www.yaskawa.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Memobus		
Com port	RS485	RS232/RS485 2w,4w	Must match the PLC's port setting.
Baud rate	19200	9600~57600	Must match the PLC's port setting.
Parity bit	Even		Must match the PLC's port setting.
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		Dose not apply to this protocol.
PLC Station No.	1	1-31	Must match the PLC's port setting.

## PLC Setting:

Communication mode	MEMOBUS, Slave, RTU
Select	

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	MB_1	ddddh	dddd:0~9999, h: 0~f	MB 0~9999
B	MB_2	ddddh	dddd:10000~65535, h: 0~f	MB 10000~65535
B	IB	hhhh	hhhh : 0~A7FF	Read only
W	IW	hhhh	hhhh : 0~A7FF	Read only
DW	IL	hhhh	hhhh : 0~A7FE	Read only
F	IF	hhhh	hhhh : 0~A7FE	Read only
W	MW	dddd	dddd:0~65534	Holding Register
DW	ML	dddd	dddd:0~65533	Double word
F	MF	dddd	dddd:0~65533	Floating point

## Wiring diagram:

### 1. RS-232: 217IF-01, 218IF-01

MT8000 RS232


217IF-01 RS232  
9P D-SUB Female



### 2. RS-485 2w: 217IF-01

MT8000 RS-485 2w


217IF-01 RS422/485



### 3. RS485 4w: 217IF-01

MT8000 RS-485 2w

217IF-01 RS422/485



# mitsubishi AJ71

Mitsubishi A series PLC with AJ71C24 communication module using the Computer Link protocol.

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MITSUBISHI AJ71	MITSUBISHI AJ71(AnA/AnU CPU) MITSUBISHI AJ71[format4] pds driver	
Com port	RS485 4W	RS485 4W, RS232	
Baud rate	19200	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	8	8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	0		

## PLC Setting:

Communication mode	Computer Link protocol 9600, Even, 8, 1 (default)
Mode Setting Switch	<b>Format 1</b>
Parity Check	<b>Enable</b>
Sum Check	<b>Enable</b>

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	hhh	hhh: 0~270F (hex-decimal)	Input Bits
B	Y	hhh	hhh: 0~270F (hex-decimal)	Output Bits
B	M	dddd	dddd:0~9999	Internal Relays
W	TV	ddd	ddd:0~255	Timer Preset Value
W	CV	ddd	ddd:0~255	Counter Preset Value
W	D	dddd	ddd:0~9999	Data Registers

# Wiring diagram:


RS-485 4W:

MT800 Com1

AJ71C24

RS-422


RS-485]



RS-232: A1SJ71UC24-R2

MT8000 RS232

RS232 port  
9P D-SUB Female



# mitsubishi FX0n/FX2

Mitsubishi FX0s/FX0n/FX1s/FX1n/FX2 PLC

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Mitsubishi FX0n/FX2	Mitsubishi FX0n/FX2	
Com port	RS485	RS232/RS485	
Baud rate	9600	9600/19200/38400/57600/ 115200	must same as the PLC setting
Parity bit	Even	Even, Odd, None	must same as the PLC setting
Data Bits	7	7,8	must same as the PLC setting
Stop Bits	1	1,2	must same as the PLC setting
HMI Station No.	0	0-255	Does not apply to this protocol
PLC Station No.	0	0-255	must same as the PLC setting



## PLC Setting:

Communication mode	9600,Even,7,1
--------------------	---------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0-377	Input Relay
B	Y	ooo	0-377	Output Relay
B	M	ddd	0-9999	Auxiliary Relay
B	T	ddd	0-255	Timer Relay
B	C	ddd	0-255	Counter Relay
W	TV	ddd	0-255	Timer Memory
W	CV	ddd	0-199	Counter Memory
W	D	ddd	0-9999	Data Register
DW	CV2	ddd	200-255	Counter Memory(D Word)
W	SD	ddd	8000-9999	Special Data Register

# Wiring diagram:



8Pin miniDin Female

# mitsubishi FX2n

Mitsubishi FX2n series PLC

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Mitsubishi FX2n	Mitsubishi FX2n	
Com port	RS485	RS232/RS485	
Baud rate	9600	9600/19200/38400/5760 0/115200	
Parity bit	Even		
Data Bits	7		
Stop Bits	1		
HMI Station No.	0		
PLC Station No.	0		

Online Simulator	YES	Extend address mode	NO
Broadcast command	NO		

## PLC Setting:


Communication mode	9600,Even,7,1
--------------------	---------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0-377	Input Relay
B	Y	ooo	0-377	Output Relay
B	M	dddd	0-7999	Auxiliary Relay
B	T	ddd	0-255	Timer Relay
B	C	ddd	0-255	Counter Relay
B	SM	dddd	8000-9999	Special Auxiliary Relay
B	D_Bit	dddd(dd)	0~7999(0~15)	Data Register Bit (D)
B	S	dddd	0~4095	State Relay (S)

Bit/Word	Device Type	Format	Range	Memo
W	TV	ddd	0-255	Timer Memory
W	CV	ddd	0-199	Counter Memory
W	D	ddd	0-7999	Data Register
DW	CV2	ddd	200-255	Counter Memory(D Word)
W	SD	ddd	8000-9999	Special Data Register

## Wiring diagram:



# mitsubishi FX232/485BD

Mitsubishi FX0n/FX2/FX2n COM For Communication Module BD  
 FX2N-485-BD, FX2N-232-BD, FX1N-485-BD and FX1N-232-BD

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	mitsubishi FX232/485BD		
Com port	RS232/RS485	RS232/RS485 2w/4w	in accordance with the BD module
Baud rate	19200	9600/19200	must same as the PLC setting
Parity bit	Even	Even, Odd, None	must same as the PLC setting
Data Bits	7	7,8	must same as the PLC setting
Stop Bits	1	1,2	must same as the PLC setting
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	1	0-15	must same as the PLC setting

Online Simulator	YES	Extend address mode	YES
Broadcast command			

## PLC Setting:

Communication mode	Must set PLC station when use the BD Module
--------------------	---


Register D8120 setting: set b9 and b8 of BFM#0 as 0

### Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0-377	Input Relay
B	Y	ooo	0-377	Output Relay
B	M	ddd	0-9999	Auxiliary Relay
B	T	ddd	0-255	Timer Relay
B	C	ddd	0-255	Counter Relay
W	TV	ddd	0-255	Timer Memory
W	CV	ddd	0-199	Counter Memory
W	D	ddd	0-9999	Data Register
W	CV2	ddd	200-255	Counter Memory(D Word)

### Wiring diagram:

Communication Module RS232BD:



Communication Module RS485BD:



Communication Module RS485BD:

MT8000 RS-485 2Wire


9P D-SUB

COM1	COM3
1 RX-	6 Data-
2 RX+	9 Data+
3 TX-	
4 TX+	
5 GND	5 GND

**RS485BD Module**

5P terminal

SDB
SDA
RDB
RDA
SG



# mitsubishi fx3u

Mitsubishi FX3U/FX3UC

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	mitsubishi fx3u		
Com port	RS485 4w	RS232/RS485 2w/4w	
Baud rate	9600	9600/19200	must same as the PLC setting
Parity bit	Even		must same as the PLC setting
Data Bits	7		must same as the PLC setting
Stop Bits	1		must same as the PLC setting
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	0		Does not apply to this protocol

Online Simulator	YES	Extend address mode	NO

## PLC Setting:


Communication mode	9600,Even,7,1
--------------------	---------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0~377	Input Relay
B	Y	ooo	0~377	Output Relay
B	M	dddd	0~7679	Auxiliary Relay
B	SM	dddd	8000~9999	Special Relay (M)
B	S	dddd	0~4095	State Relay (S)
B	T	ddd	0~511	Timer Relay (T)
B	C	ddd	0~199	Counter Relay (C)

Bit/Word	Device Type	Format	Range	Memo
B	D_Bit	dddd(dd)	dddd=0~7999 (dd)=0~15	Data Register Bit (D)
W	TV	ddd	0~511	Timer Memory (T)
W	CV	ddd	0~199	Counter Memory (C)
DW	CV2	ddd	200~255	Counter Memory(D Word)
W	D	dddd	0~7999	Data Register (D)
W	SD	dddd	8000~9999	Special Data Register (D)
W	R	dddd	0~32767	Extended Register (R)

## Wiring diagram:



# MITSUBISHI FX3U-ETHERNET

MITSUBISHI FX SERIES, Module: FX3U-ENET

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MITSUBISHI FX3u (Ethernet)		
Com port	Ethernet		
PLC Station No.	0 (default)		Refer Module Setting
TCP/IP port	5001(default)		Refer Module Setting

## Device address:


Bit/Word	Device type	Format	Range	Memo
B	X	ooo	0 ~ 377	Input
B	Y	ooo	0 ~ 377	Output Relay
B	M	dddd	0 ~ 7679	Internal Relay
B	S	dddd	0 ~ 4095	Step Relays
B	T	ddd	0 ~ 511	Timer Contacts
B	C	ddd	0 ~ 255	Counter Contacts
B	SM	dddd	8000 ~ 8511	Special Int. Relays
B	D_Bit	dddd(dd)	0-799915	Data Register Bit Access
W	TV	ddd	0 ~ 511	Timer Value
W	R	dddd	0 ~ 32767	File Register
W	CV	ddd	0 ~ 199	Counter Value
W	D	dddd	0 ~ 7999	Data Registers
W	CV2	ddd	200 ~255	Counter Value
W	SD	dddd	8000 ~ 8511	Special Data Registers

ddd: (Decimal), hhh:(Hexadecimal), ooo:(Octal).

## Wiring diagram:

Ethernet:

MT8000 Ethernet RJ45			Wire color	Ethernet Hub or Switch RJ45		
1	TX+	White/Orange		1	RX+	
2	TX-	Orange		2	RX-	
3	RX+	White/Green		3	TX+	
4	BD4+	Blue		4	BD4+	
5	BD4-	White/Blue		5	BD4-	
6	RX-	Green		6	TX-	
7	BD3+	White/Brown		7	BD3+	
8	BD3-	Brown		8	BD3-	




Ethernet: Direct connect (crossover cable)

MT8000 Ethernet RJ45			Wire color	Modbus TCP Device RJ45		
1	TX+	White/Orange		3	RX+	
2	TX-	Orange		6	RX-	
3	RX+	White/Green		1	TX+	
4	BD4+	Blue		4	BD4+	
5	BD4-	White/Blue		5	BD4-	
6	RX-	Green		2	TX-	
7	BD3+	White/Brown		7	BD3+	
8	BD3-	Brown		8	BD3-	

Fx3u-ENET module setting:

Before using Ethernet module, using GX Developer / FX Configurator-EN to set the Ethernet module, the FX3u-ENET module settings as below steps.


1. Open GX Developer, select "Read from PLC" in Online list.




2. Select "FXCPU" in PLC series.




3. Users have to connect PLC via series port for setting IP address at first time.




4. After finishing the PLC settings, select Tools/FX special function utility/FX Configurator-EN



- Select "Module 0" in Ethernet Module settings.  
(If more than one module, please setting modules step by step)




- In Ethernet operational settings, select the related parameters and IP address and then press "End" to finish the settings.




7. In Ethernet open settings, press “End” after setting the below parameters.

1	TCP	MELSOFT connection							
2	TCP	Unpassive	Send	Procedure exist(MC)	Disable	No confirm	5001		
3	TCP	Unpassive	Send	Procedure exist(MC)	Disable	No confirm	5001		
4	TCP	Unpassive	Send	Procedure exist(MC)	Disable	No confirm	5001		

(The first Protocol means using GX Developer to communicate with module, The max. “Fixed buffer communication procedure” is 4 units.)



8. After setting the parameters to PLC, restart for using Ethernet communication.



# MITSUBISHI Q02H

Mitsubishi Q02H CPU port.

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MITSUBISHI Q02H		
Com port	RS232	RS485 4W, RS232	
Baud rate	115200	115200 only	
Parity bit	Odd		
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		
PLC Station No.	0		

Online Simulator	YES	Extend address mode	NO
Broadcast command	NO		

## PLC Setting:

Communication mode	
--------------------	--

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X	hhh	0~1FFF	Input Relay
B	Y	hhh	0~1FFF	Output Relay
B	M	dddd	0~8191	Internal Relay
B	L	dddd	0~8191	Latch Relay
B	F	dddd	0~2047	Annunciator
B	V	dddd	0~2047	Edge Relay
B	B	hhh	0~1FFF	Link Relay
B	TC	ddd	0~2047	Timer Coil
B	SS	ddd	0~2047	Retentive Timer Contact
B	SC	ddd	0~2047	Retentive Timer Coil

Bit/Word	Device Type	Format	Range	Memo
B	CS	ddd	0~1023	Counter Contact
B	CC	ddd	0~1023	Counter Coil
B	SB	hhh	0~7FF	Special Link Relay
B	S	dddd	0~8191	Step Relay
B	DX	hhh	0~1FFF	Direct Input
B	DY	hhh	0~1FFF	Direct Output
B	TS	ddd	0~2047	Timer Contact
W	W	hhh	0~1FFF	Link Register
W	TN	ddd	0~2047	Timer Current Value
W	SN	ddd	0~2047	Retentive Timer Current Value
W	CN	ddd	0~1023	Counter Current Value
W	R	dddd	0~32767	File Register
W	SW	hhh	0~7FF	Special Link Register
W	Z	d	0~9	Index Register
W	ZR	hhhh	0~FFFF	File Register
W	D	dddd	0~12287	Data Register

ddd: Decimal, hhh: Hexadecimal, ooo: Octal.

## Wiring diagram:

RS-232:



# MITSUBISHI Q06H

Mitsubishi Q06H CPU port.

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MITSUBISHI Q06H		
Com port	RS232	RS485 4W, RS232	
Baud rate	115200	115200 only	
Parity bit	Odd		
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		
PLC Station No.	0		

Online Simulator	YES	Extend address mode	NO
Broadcast command	NO		

## PLC Setting:

Communication mode	
--------------------	--

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X	hhh	0~1FFF	Input Relay
B	Y	hhh	0~1FFF	Output Relay
B	M	dddd	0~8191	Internal Relay
B	L	dddd	0~8191	Latch Relay
B	F	dddd	0~2047	Annunciator
B	V	dddd	0~2047	Edge Relay
B	B	hhh	0~1FFF	Link Relay
B	TC	ddd	0~2047	Timer Coil
B	SS	ddd	0~2047	Retentive Timer Contact
B	SC	ddd	0~2047	Retentive Timer Coil

Bit/Word	Device Type	Format	Range	Memo
B	CS	ddd	0~1023	Counter Contact
B	CC	ddd	0~1023	Counter Coil
B	SB	hhh	0~7FF	Special Link Relay
B	S	dddd	0~8191	Step Relay
B	DX	hhh	0~1FFF	Direct Input
B	DY	hhh	0~1FFF	Direct Output
B	TS	ddd	0~2047	Timer Contact
W	W	hhh	0~1FFF	Link Register
W	TN	ddd	0~2047	Timer Current Value
W	SN	ddd	0~2047	Retentive Timer Current Value
W	CN	ddd	0~1023	Counter Current Value
W	R	dddd	0~32767	File Register
W	SW	hhh	0~7FF	Special Link Register
W	Z	d	0~9	Index Register
W	ZR	hhhh	0~FFFF	File Register
W	D	dddd	0~12287	Data Register

ddd: Decimal, hhh: Hexadecimal, ooo: Octal.

## Wiring diagram:

RS-232:



# mitsubishi QJ71

Mitsubishi Q series PLC with QJ71C24 communication module, Q00, Q01 CPU port.

<http://www.mitsubishi-automation.com>

## HMI Setting:


Parameters	Recommend	Option	Notes
PLC type	MITSUBISHI Melsec_QJ71		
Com port	RS232	RS485 4W, RS232	
Baud rate	9600		
Parity bit	Odd		
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		
PLC Station No.	0		

Online Simulator	YES
Extend address mode	NO

## PLC Setting:

Communication mode	
--------------------	--


Q00, Q01 CPU port setting:



1. In the GX Developer “PLC data list” click the “PLC parameter”
2. In the “PLC parameter” select “Serial” page.
3. Select “Use serial communication”
4. Set the “Transmission speed”. 9600~115200.
5. Select “Sum check”
6. Select “Transmission wait time” to 10ms.
7. Select “RUN write setting”
8. Click “End” close the dialog.

9. Write the PLC Parameter to PLC.

10. RESET the PLC, the parameter will active.



## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X	hhh	0~1FFF	Input Relay
B	Y	hhh	0~1FFF	Output Relay
B	M	dddd	0~8191	Internal Relay
B	L	dddd	0~8191	Latch Relay
B	F	dddd	0~2047	Annunciator
B	V	dddd	0~2047	Edge Relay
B	B	hhh	0~1FFF	Link Relay
B	TC	ddd	0~2047	Timer Coil
B	SS	ddd	0~2047	Retentive Timer Contact
B	SC	ddd	0~2047	Retentive Timer Coil
B	CS	ddd	0~1023	Counter Contact
B	CC	ddd	0~1023	Counter Coil
B	SB	hhh	0~7FF	Special Link Relay
B	S	dddd	0~8191	Step Relay
B	DX	hhh	0~1FFF	Direct Input
B	DY	hhh	0~1FFF	Direct Output
B	TS	ddd	0~2047	Timer Contact
W	W	hhh	0~1FFF	Link Register
W	TN	ddd	0~2047	Timer Current Value

Bit/Word	Device Type	Format	Range	Memo
W	SN	ddd	0~2047	Retentive Timer Current Value
W	CN	ddd	0~1023	Counter Current Value
W	R	dddd	0~32767	File Register
W	SW	hhh	0~7FF	Special Link Register
W	Z	d	0~9	Index Register
W	ZR	hhhh	0~FFFF	File Register
W	D	dddd	0~12287	Data Register


ddd: Decimal, hhh: Hexadecimal, ooo: Octal.

## Wiring diagram:

RS-485 4W:



RS-232:




Q00, Q01 CPU port RS-232:

**MT8000 RS232**

9P D-SUB

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND



**Q00, Q01**  
CPU port  
Mini-DIN 6pin

3	RXD
4	TXD
5	GND



MINI-DIN 6Pin  
Female

# mitsubishi QJ71E71

Mitsubishi Q type, QJ71E71-100 Ethernet module.

<http://www.mitsubishi-automation.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MITSUBISHI QJ71E71 [V1.00]		
Com port	Ethernet		
PLC Station No.	2	1~99	
TCP/IP port	5002		

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	hhhh	0~1FFF	Input Relay
B	Y	hhhh	0~1FFF	Output Relay
B	M	dddd	0~8191	Internal Relay
B	L	dddd	0~8191	Latch Relay
B	F	dddd	0~2047	Annunciator
B	V	dddd	0~2047	Edge Relay
B	B	hhhh	0~1FFF	Link Relay
B	SB	hhhh	0~2047	Special Link Relay
B	DX	hhhh	0~1FFF	Direct Input
B	DY	hhhh	0~1FFF	Direct Output
W	W	hhhh	0~2FFF	Link Register
W	R	dddd	0~32767	File Register
W	SW	hhh	0~7FF	Special Link Register
W	Z	dd	0~15	Index Register
W	ZR	hhhh	0~FFFF	File Register
W	D	dddd	0~12287	Data Register

Ddd: Decimal, hhh: Hexadecimal


## Wiring diagram:

Ethernet:

MT8000 Ethernet Wire color  
RJ45

Ethernet Hub or  
Switch RJ45

1	TX+	White/Orange		1	RX+
2	TX-	Orange		2	RX-
3	RX+	White/Green		3	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		6	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-



Ethernet: Direct connect (crossover cable)


MT8000 Ethernet Wire color  
RJ45

Modbus TCP Device  
RJ45


1	TX+	White/Orange		3	RX+
2	TX-	Orange		6	RX-
3	RX+	White/Green		1	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		2	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-

QJ71E71-100 Ethernet module settings:

1. Use Q-CPU's USB or RS232 setting PLC parameters.




2. Click Operational setting to set IP information.



	Module 1	Module 2
Network type	Ethernet	None
Starting I/O No.	0040	
Network No.	1	
Total stations		
Group No.	1	
Station No.	1	
Mode	On line	
	Operational settings	
	Initial settings	
	Open settings	
	Router relay parameter	
	Station No.<->IP information	
	FTP Parameters	
	E-mail settings	
	Interrupt settings	

3. Select Ethernet (2.0) for communicating with HMI.



4. Click “Open settings” to set the system.


	Module 1	Module 2
Network type	Ethernet	None
Starting I/O No.	0040	
Network No.	1	
Total stations		
Group No.	1	
Station No.	1	
Mode	On line	
	Operational settings	
	Initial settings	
	Open settings	
	Router relay parameter	
	Station No.<->IP information	
	FTP Parameters	
	E-mail settings	
	Interrupt settings	

Network parameter Ethernet open setting. Module No.1


	Protocol	Open system	Fixed buffer	Fixed buffer communication procedure	Pairing open	Existence confirmation	Host station Port No.	Transmission target device IP address	Transmission target device Port No.
1	TCP	MELSOFT connection							
2	TCP	MELSOFT connection							
3	TCP	MELSOFT connection							
4	TCP	MELSOFT connection							
5									
6									
7									
8									
9									
10									
11									
12									
13									
14									
15									
16									

End Cancel


5. Press END to finish settings.




- Restart PLC software and select [READ FROM PLC], click QCPU (Qmode) and press OK.




- Select “Ethernet board” in PC Side I/F to set Network and Station no..(the Station no.1 is PC’s station no. not Ethernet module’s, range from 2~64, the Network no. can not the same as PC’s number)



- Select “Ethernet module” in PLC Side I/F to set QJ71E71’s IP address.(IP address = Network Parameter’s IP address)



- In "Other station", click "Other station(Single network)" setting "Check at communication time" and "Retry times".



After finishing settings as above, click "Connection test" for testing the communication and sending the PLC's program.

# MODBUS ASCII

## MODBUS ASCII CONTROLLER

<http://www.modbus.org>

### HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Modbus ASCII		
Com port	RS485	RS232/RS485	
Baud rate	9600	9600/19200/38400/57600/ 115200	
Parity bit	Even	Even, Odd, None	
Data Bits	8	7,8	
Stop Bits	1	1,2	
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	1	0-255	

Online Simulator	YES	Broadcast command	YES
Extend address mode	YES		

### PLC Setting:

Communication mode	Modbus ASCII protocol
--------------------	-----------------------

### Device address:


Bit/Word	Device Type	Format	Range	Memo
B	0x	dddd	1-65535	Output bit
B	1x	dddd	1-65535	Input bit (read only)
B	3x_Bit	dddd(dd)	100-6553515	Input Register bit (read only)
B	4x_Bit	dddd(dd)	100-6553515	Output Register bit
W	3x	dddd	1-65535	Input Register (read only)
W	4x	dddd	1-65535	Output Register

Modbus RTU function code:



- |    |      |                       |      |                         |
|----|------|-----------------------|------|-------------------------|
| 0x | 0x01 | Read coil             | 0x05 | write single coil       |
| 1x | 0x02 | Read discrete input   | N/A  | for write operation     |
| 3x | 0x04 | Read input register   | N/A  | for write operation     |
| 4x | 0x03 | Read holding register | 0x10 | write multiple register |
- 3xbit is equivalent to 3x  
4xbit is equivalent to 4x

## Wiring diagram:

### MODBUS RS232 PORT



### MODBUS RS422/485 PORT



# MODBUS RTU

## MODBUS RTU CONTROLLER

<http://www.modbus.org>

### HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Modbus RTU		
Com port	RS485	RS232/RS485	
Baud rate	9600	9600~115200	
Parity bit	Even	Even, Odd, None	
Data Bits	8	7,8	
Stop Bits	1	1,2	
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	1	0-255	

Online Simulator	YES	Broadcast command	YES
Extend address mode	YES		

### PLC Setting:

Communication mode	Modbus RTU protocol
--------------------	---------------------

### Device address:

Bit/Word	Device Type	Format	Range	Memo
B	0x	dddd	1-65535	Output bit
B	1x	dddd	1-65535	Input bit (read only)
B	3x_Bit	dddd(dd)	100-6553515	Input Register bit (read only)
B	4x_Bit	dddd(dd)	100-6553515	Output Register bit
B	6x_Bit	dddd(dd)	100-6553515	Output Register bit
W	3x	dddd	1-65535	Input Register (read only)
W	4x	dddd	1-65535	Output Register
DW	5x	dddd	1-65535	4x double word swap
W	6x	dddd	1-65535	4x single word write

NOTE:

Address type “5x” are mapping to Hold Reg. The communication protocol of 5x is almost same as “4x” except “5x”making double word swap.

If 4x has following information

Address	1	2	3	4	5	6	...
Data in word	0x1	0x2	0x3	0x4	0x5	0x6	
Data	0x20001		0x40003		0x60005		

For 5x, it become

Address	1	2	3	4	5	6	...
Data in word	0x2	0x1	0x4	0x3	0x6	0x5	
Data	0x10002		0x30004		0x50006		

Modbus RTU function code:

0x	0x01 Read coil	0x05 write single coil
1x	0x02 Read discrete input	N/A for write operation
3x	0x04 Read input register	N/A for write operation
4x	0x03 Read holding register	0x10 write multiple register
5x	0x03 Read holding register	0x10 write multiple register

( note: reverse word order in double word format)

3xbit is equivalent to 3x


4xbit is equivalent to 4x

6x	0x03 Read holding register	0x06 write single register
----	----------------------------	----------------------------



( note: use 6x device is limited to device of one word only )

## Wiring diagram:

MODBUS RS232 PORT



# MODBUS RS422/485 PORT



# MODBUS RTU (zero-based addressing)

## MODBUS RTU CONTROLLER

<http://www.modbus.org>

### HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Modbus RTU		
Com port	RS485	RS232/RS485	
Baud rate	9600	9600~115200	
Parity bit	Even	Even, Odd, None	
Data Bits	8	7,8	
Stop Bits	1	1,2	
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	1	0-255	

Online Simulator	YES	Broadcast command	YES
Extend address mode	YES		

### PLC Setting:

Communication mode	Modbus RTU protocol
--------------------	---------------------

### Device address:

Bit/Word	Device Type	Format	Range	Memo
B	0x	dddd	0-65535	Output bit
B	1x	dddd	0-65535	Input bit (read only)
B	3x_Bit	dddd(dd)	0-6553515	Input Register bit (read only)
B	4x_Bit	dddd(dd)	0-6553515	Output Register bit
W	3x	dddd	0-65535	Input Register (read only)
W	4x	dddd	0-65535	Output Register
DW	5x	dddd	0-65535	4x double word swap
W	6x	dddd	0-65535	4x single word write

NOTE:

Address type “5x” are mapping to Hold Reg. The communication protocol of 5x almost same as “4x” except “5x”making double word swap.

If 4x have following information

Address	1	2	3	4	5	6	...
Data in word	0x1	0x2	0x3	0x4	0x5	0x6	
Data	0x20001		0x40003		0x60005		

For 5x, it become

Address	1	2	3	4	5	6	...
Data in word	0x2	0x1	0x4	0x3	0x6	0x5	
Data	0x10002		0x30004		0x50006		

Modbus RTU function code:

0x	0x01 Read coil	0x05 write single coil
1x	0x02 Read discrete input	N/A for write operation
3x	0x04 Read input register	N/A for write operation
4x	0x03 Read holding register	0x10 write multiple register
5x	0x03 Read holding register	0x10 write multiple register

(Note: reverse word order in double word format)

3xbit is equivalent to 3x


4xbit is equivalent to 4x

6x	0x03 Read holding register	0x06 write single register
----	----------------------------	----------------------------



(Note: use 6x device is limited to device of one word only)

## Wiring diagram:

MODBUS RS232 PORT




## MODBUS RS422/485 PORT



Note: MODBUS RTU (adjustable) usage

Users can decide the address range via setting value on Parameter 1. For example, when users set 5 to Parameter 1, the address range become 5~65535.



# MODBUS SERVER (Modbus RTU Slave)

## HMI Setting:

Parameters	Recommend	Option	Option	Notes
PLC type	Modbus Server			
Com port	RS232	RS232, RS485	Ethernet	
Baud rate	9600	9600~115200		
Parity bit	Even	Even, Odd, None		
Data Bits	8	8		
Stop Bits	1	1		
HMI Station No.	0		0	
PLC Station No.	1	1-31	0	<b>HMI Modbus station No.</b>
Port no.			502	

Online Simulator	YES	Extend address mode	NO
Broadcast command	NO		

## PLC Setting:

Communication mode	<b>Modbus RTU protocol</b>
--------------------	----------------------------

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	LB	dddd	0~9998	Mapping to 0x/1x 1~9999
W	LW	dddd	0~9998	Mapping to 3x/4x 1~9999
W	RW	dddd	0~55536	Mapping to 3x/4x 10000~65536

LB0 = 0x0001, LB1 = 0x0002, LW0 = 3x0001, LW1 = 3x0002


Modbus RTU Server doesn't support function Code 06(to preset single register), please use function code 16(0x10, preset multiple register).

## Wiring diagram:

RS-232:



RS-485:



Precaution: Setting more than one Modbus server in HMI device list is useless.

# MODBUS TCP/IP

Modbus RTU TCP/IP device.

<http://www.modbus.org>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MODBUS TCP/IP		
Com port	Ethernet		
HMI Station No.	0	Does not apply	
PLC Station No.	0	0~255	
TCP/IP port	502		

## PLC Setting:


Communication mode	
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	0x	dddd	1-65535	Output bit
B	1x	dddd dd	1-65535	Input bit (read only)
B	3x_bit	dddd dd	100-6553515	Input Register bit (read only)
B	4x_bit	dddd dd	100-6553515	Output Register bit
B	6x_bit	dddd dd	100-6553515	Output Register bit
W	3x	Dddd	1-65535	Input Register (read only)
W	4x	Dddd	1-65535	Output Register
DW	5x	Dddd	1-65535	4x double word swap
W	6x	Dddd	1-65535	4x single word write

# Wiring diagram:

Ethernet::



1 8  
RJ45

Ethernet: Direct connect (crossover cable)



# MODBUS TCP/IP (zero-based)

Modbus RTU TCP/IP device.

<http://www.modbus.org>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	MODBUS TCP/IP		
Com port	Ethernet		
HMI Station No.	0	Does not apply	
PLC Station No.	0	0~255	
TCP/IP port	502		

## PLC Setting:


Communication mode	
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	0x	dddd	0-65535	Output bit
B	1x	dddd dd	0-65535	Input bit (read only)
B	3x_bit	dddd dd	0-6553515	Input Register bit (read only)
B	4x_bit	dddd	0-6553515	Output Register bit
W	3x	dddd	0-65535	Input Register (read only)
W	4x	dddd	0-65535	Output Register
DW	5x	dddd	0-65535	4x double word swap

## Wiring diagram:

Ethernet::



3	RX+	White/Green		3	TX+
4	BD4+	Blue		4	BD4+
5	BD4-	White/Blue		5	BD4-
6	RX-	Green		6	TX-
7	BD3+	White/Brown		7	BD3+
8	BD3-	Brown		8	BD3-

Ethernet: Direct connect (crossover cable)

<b>MT8000 Ethernet</b>				<b>Modbus TCP Device</b>		
<b>RJ45</b>				<b>RJ45</b>		
1	TX+	White/Orange		3	RX+	
2	TX-	Orange		6	RX-	
3	RX+	White/Green		1	TX+	
4	BD4+	Blue		4	BD4+	
5	BD4-	White/Blue		5	BD4-	
6	RX-	Green		2	TX-	
7	BD3+	White/Brown		7	BD3+	
8	BD3-	Brown		8	BD3-	

# Modicon Twido

<http://www.modicon.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Modbus RTU		Support Extended Address mode.
Com port	RS485	RS232/RS485	Must match the PLC's port setting.
Baud rate	19200	19200	Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	8	Must set 8 for RTU mode
Stop Bits	1	1	Must set 8 for RTU mode
HMI Station No.	0		Does not apply to this protocol.
PLC Station No.	1	0-247	Must match the PLC's port setting.


## PLC Setting:

Communication mode	<b>19200, None, 8, 1</b>
Select	<b>Modbus RTU Slave</b>

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	0x or 1x	dddd	0~9999	%Mi
W	3x or 4x	dddd	0~9999	%MWi

## Wiring diagram:




MT8000 RS-485  
9P D-SUB

COM1	COM3
1 RX-	6 Data-
2 RX+	9 Data+
5 GND	5 GND

Port2 RS485 port  
3Pin Terminal

B(-)
A(+)
GND




MT8000 RS232  
9P D-SUB Female

COM1	COM2	COM3
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

Port2 RS232  
9P D-SUB Female

2	RX
3	TX
5	GND



# OMRON C/CQM1 series

OMRON C, CPM, CQM Series (Host Link Protocol),

<http://oeiweb.omron.com/oei/Products-PLC.htm>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	OMRON C/CQM1 Series		
Com port	RS232	RS232, RS422, RS485	
Baud rate	9600	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	7	7 or 8	
Stop Bits	2	1 or 2	
HMI Station No.	0		
PLC Station No.	0	0-31	<b>Host Link Station No.</b>

Online Simulator	YES	Broadcast command	YES
Extend address mode	YES		

## PLC Setting:

Communication mode	<b>Host Link protocol</b>
--------------------	---------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	IR	ddd(dd)	0-409515	I/O and internal Relay
B	HR	ddd(dd)	0-409515	Hold Relay
B	AR	ddd(dd)	0-409515	Auxiliary Relay
B	LR	ddd(dd)	0-409515	Link Relay
B	TC	ddd	0-519	Timer/Counter Register
W	DM	dddd	0-6659	Data register


## Wiring diagram:

CPU Port(CPM2A,CQM1/1H,C200H/HS/ALPHA series)

Communication Module:


CPM1-CIF01 adapter(for CPM1/CPM1A/CPM2A series,CQM1/CQM1H series)

CPM1H-SCB41 communication module(for CQM1H-CPU51/61)



C200h-LK201,3G2A6-LK201 communication module

C200HW-COM02/03/04/05/06 communication module



# OMRON CJ1/CS1

OMRON CJ1M, CJ1H, CJ1G, CS1H and CS1G. (Host Link Protocol FINS command),

This driver supports Extend Addressing mode.

<http://oeiweb.omron.com/oei/Products-PLC.htm>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	OMRON CJ1/CS1		
Com port	RS232	RS232, RS422, RS485	
Baud rate	9600	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	7	7 or 8	
Stop Bits	2	1 or 2	
HMI Station No.	0		
PLC Station No.	0	0-31	<b>Host Link Station No.</b>

Online Simulator	YES	Extend address mode	YES
Broadcast command	NO		

## PLC Setting:

Communication mode	<b>Host Link protocol</b>
--------------------	---------------------------


## Device address:

Bit/Word	Device Type	Format	Range	Memo
Bit	D_bit	ddd(dd)	ddd:0~32767 (dd): 0~15	Data Memory (DM)
Bit	H_bit	ddd(dd)	ddd:0~511 (dd): 0~15	Holding Area (HR)
Bit	W_bit	ddd(dd)	ddd:0~511 (dd): 0~15	Work Area (WR)
Bit	CIO_bit	ddd(dd)	ddd:0~6143 (dd): 0~15	Channel I/O (CIO)
Bit	A_bit	ddd(dd)	ddd:0~959 (dd): 0~15	Auxiliary Relay (AR)
Bit	T_bit	ddd	ddd:0~4095	Timer (TIM)
Bit	C_bit	ddd	ddd:0~4095	Counter (CNT)
Word	D	ddd	ddd:0~32767	Data Memory (DM)

Bit/Word	Device Type	Format	Range	Memo
Word	H	ddd	ddd:0~511	Holding Area (HR)
Word	W	ddd	ddd:0~511	Work Area (WR)
Word	CIO	ddd	ddd:0~6143	Channel I/O (CIO)
Word	A	ddd	ddd:0~959	Auxiliary Relay (AR)
Word	T	ddd	ddd:0~4095	Timer (TIM)
Word	C	ddd	ddd:0~4095	Counter (CNT)
Word	EM0~EMC	dddd	dddd:0~6149	Extend Memory

## Wiring diagram:

RS-232:



# OMRON CJ1/CS1 Ethernet

OMRON CJ1M, CJ1H, CJ1G, CS1H and CS1G. (Ethernet FINS),

<http://oeiweb.omron.com/oei/Products-PLC.htm>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	OMRON CJ1/CS1 (Ethernet)		
Com port	Ethernet		
TCP port	9600		
HMI Station No.	0		
PLC Station No.	0		

## PLC Setting:

Communication mode	<b>FINS Ethernet protocol</b>
--------------------	-------------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	D_bit	dddd(dd)	ddd:0~32767 (dd): 0~15	Data Memory (DM)
B	H_bit	ddd(dd)	ddd:0~511 (dd): 0~15	Holding Area (HR)
B	W_bit	ddd(dd)	ddd:0~511 (dd): 0~15	Work Area (WR)
B	CIO_bit	ddd(dd)	ddd:0~6143 (dd): 0~15	Channel I/O (CIO)
B	A_bit	ddd(dd)	ddd:0~959 (dd): 0~15	Auxiliary Relay (AR)
B	T_bit	dddd	ddd:0~4095	Timer (TIM)
B	C_bit	dddd	ddd:0~4095	Counter (CNT)
W	D	dddd	ddd:0~32767	Data Memory (DM)
W	H	ddd	ddd:0~511	Holding Area (HR)
W	W	ddd	ddd:0~511	Work Area (WR)
W	CIO	dddd	ddd:0~6143	Channel I/O (CIO)
W	A	ddd	ddd:0~959	Auxiliary Relay (AR)
W	T	dddd	ddd:0~4095	Timer (TIM)

W	C	dddd	ddd:0~4095	Counter (CNT)
---	---	------	------------	---------------

## Wiring diagram:

Ethernet:

**MT8000 Ethernet** Wire color


**RJ45**

1	TX+	White/Orange
2	TX-	Orange
3	RX+	White/Green
4	BD4+	Blue
5	BD4-	White/Blue
6	RX-	Green
7	BD3+	White/Brown
8	BD3-	Brown

**Ethernet Hub or Switch**

**RJ45**

1	RX+
2	RX-
3	TX+
4	BD4+
5	BD4-
6	TX-
7	BD3+
8	BD3-



1 8

RJ45  
connector

Ethernet: Direct connect (crossover cable)

**MT8000 Ethernet** Wire color

**RJ45**

1	TX+	White/Orange
2	TX-	Orange
3	RX+	White/Green
4	BD4+	Blue
5	BD4-	White/Blue

**OMRON Ethernet**

**RJ45**

3	RX+
6	RX-
1	TX+
4	BD4+
5	BD4-

6	RX-	Green	2 TX-
7	BD3+	White/Brown	7 BD3+
8	BD3-	Brown	8 BD3-

# OMRON E5CN

OMRON E5CN series Temperature controller with communication option.

E5EN/CN/GN series

<http://oeiweb.omron.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	OMRON E5CN		
Com port	RS485 2W		
Baud rate	9600	9600/19200/38400/57600 /115200	
Parity bit	Even	Even, Odd, None	
Data Bits	7	7,8	
Stop Bits	2	1,2	
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	0	0-99	

Online Simulator	YES	Broadcast command	YES
Extend address mode	YES		

## PLC Setting:


Communication mode	9600, Even, 7, 2 (default)
--------------------	----------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	Status	dd	0-31	Page40
DW	C0	hhhh	0-5	Read only (Hex) Page34
DW	C1	hhhh	0-1C	Read/Write (Hex) Page35
DW	C3	hhhh	0-1D	Read/Write (Hex) Page36
W	Operation00_00	hh	0	Communications writing OFF (disabled)
W	Operation00_01	hh	0	Communications writing ON(Enabled)
W	Operation01_00	hh	0	Run
W	Operation01_01	hh	0	Stop

Bit/Word	Device Type	Format	Range	Memo
W	Operation02_00	hh	0	Multi-SP Set point 0
W	Operation02_01	hh	0	Multi-SP Set point 1
W	Operation02_02	hh	0	Multi-SP Set point 2
W	Operation02_03	hh	0	Multi-SP Set point 3
W	Operation03_00	hh	0	AT cancel
W	Operation03_01	hh	0	AT execute
W	Operation04_00	hh	0	Write mode (Backup)
W	Operation04_01	hh	0	Write mode (Ram)
W	Operation05_00	hh	0	Save RAM data
W	Operation06_00	hh	0	Software reset
W	Operation07_00	hh	0	Move to setup area 1
W	Operation08_00	hh	0	Move to protect level

## Wiring diagram:



# Panasonic FP

NAIS (Matsushita) FP series include FP-X, FP-Σ, FP0, FP1, FP2, FP2SH, FP10SH and FP3 Ethernet support FP-X with AFPX-COM5.

<http://pewa.panasonic.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Matsushita FP		
Com port	RS232	RS232/RS485 Ethernet	Must match the PLC's port setting.
Baud rate	9600	9600, 19200, 38400, 57600, 115200	Must match the PLC's port setting.
Parity bit	Odd	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	7 or 8	Must match the PLC's port setting.
Stop Bits	1	1 or 2	Must match the PLC's port setting.
HMI Station No.	0	0-255	Does not apply to this protocol.
PLC Station No.	1	0-255	Must match the PLC's port setting. <b>FP3 must set 0.</b>

## PLC Setting:




Communication mode	<b>9600,O,8,1(default)</b>
--------------------	----------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	dddd(h)	0~9999F	Input(X)
B	Y	dddd(h)	0~9999F	Output(Y)
B	R	dddd(h)	0~9999F	Internal Relay(R)
B	L	dddd(h)	0~9999	Link Relay(L)
B	T	ddd	0~9999	Timer(T)
B	C	ddd	0~9999	Counter(C)
W	SV	ddd	0~9999	Timer/Counter set value(SV)

W	EV	ddd	0~9999	Timer/Counter elapse value(EV)
W	DT	ddd	0~32767	Data Register(DT)



## Wiring diagram:



MT8000  
COM1[RS-485]4w

FP1 CPU RS422 port  
Hirose 8Pin Port


9P D-SUB




Hirose 8Pin Port

MT8000  
COM1[RS-485]4w 9P  
D-SUB

FP3 CPU RS422 port  
15P D-SUB Female



Ethernet connect  
TCP port: 9094



**Device Properties**

Name : Panasonic FP

HMI  PLC

Location : Local

PLC type : Panasonic FP

V.1.00, MATSUSHITA\_FP.so

PLC I/F : Ethernet  PLC default station no. : 1

IP : 192.168.1.15, Port=9094

Use broadcast command

Interval of block pack (words) : 5

Max. read-command size (words) : 24

Max. write-command size (words) : 24

# Parker Compax3

Parker Compax3 Servo Drive

<http://www.parker.com>

## HMI Setting:

### RS232

Parameters	Recommend	Option	Notes
PLC type	Parker Compax3 [V1.50]		
Com port	RS-232		Must match the PLC's port setting.
Baud rate	115200		Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	7 or 8	Must match the PLC's port setting.
Stop Bits	1	1 or 2	Must match the PLC's port setting.
PLC Station No.	0	0	Must be 0 for RS232

### RS485

Parameters	Recommend	Option	Notes
PLC type	Parker Compax3 [V1.50]		
Com port	RS-485 2W		Must match the PLC's port setting.
Baud rate	9600		Must match the PLC's port setting.
Parity bit	None	Even, Odd, None	Must match the PLC's port setting.
Data Bits	8	7 or 8	Must match the PLC's port setting.
Stop Bits	1	1 or 2	Must match the PLC's port setting.
PLC Station No.	1	1-99	Range from 1 to 99 for RS485, according to the PLC's setting.

## Device address:

Bit/Word	Device Type	Format	Range	Memo
DW	Register_Int	DDD(dd)	0-9999(99)	Integer register
DW	Register_Float	DDD(dd)	0-9999(99)	Floating point register

Note: D (Decimal).

About device address range details, please refer to the PLC manual.

Example: read/write address:1901.2, please input 190101.

read/write address: 400.1, please input 40001.


When select the Register\_Float, be sure set data format to 32 bit float, or it will ignore the read/write of point.

## Wiring diagram:

RS232:

EasyView MT8000


RS232 9P D-SUB



RS485:


EasyView MT8000

RS-485 2w D-SUB




How to setting Compax 3 servo to RS485 mode?

1. Open C3 ServoManager2, select “Communication”=> “RS-485 Settings”.



2. Click to Configure “RS-485/POP Settings”.



3. Setting parameters as below

The diagram shows an RS-485 communication setup. On the left, a blue dashed box contains a circuit diagram with TxD, RE, and RxD pins connected to a differential pair of lines labeled A and B. On the right, three yellow boxes represent devices connected to the same A and B lines. Below the diagram is the 'RS-485 Settings' table.

Master		General
Multicast Address		98
Device Address		11
Baud rate		9600
Connection Type		Two wire
Parity		No
Stop bits		1
Data bits		8

4. Downloading settings to Compax3 Servo.

5. Setting EB8000 system parameter and connecting with PLC for communication of HMI and Servo.

# SAIA PCD PGU mode

SAIA PCD series PGU mode.

<http://www.saia-burgess.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	SAIA PCD PGU mode	SAIA PCD S-BUS mode	PDS driver
Com port	RS232	RS232, RS485	
Baud rate	9600	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	7	7,8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	0-255	

## PLC Setting:


Communication mode	<b>9600,E,7,1(default)</b>
--------------------	----------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	Flag	ddd	ddd=0~8191	
B	Input	ddd	ddd=0~511	
B	Output	ddd	ddd=0~511	
D	Register	ddd	ddd=0~4095	
D	Counter	ddd	ddd=0~1599	
D	Timer	ddd	ddd=0~450	
D	Reg_Float	ddd	ddd=0~4095	support single float point

# Wiring diagram:

RS232:



6 DSR (Of PGU Port):PGU connected

# SAIA PCD S-Bus mode

SAIA PCD series S-Bus mode.

<http://www.saia-burgess.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	SAIA PCD S-BUS mode	SAIA PCD PGU mode	PDS driver
Com port	RS232	RS232, RS485	
Baud rate	9600	9600, 19200, 38400	
Parity bit	None	Even, Odd, None	
Data Bits	8	7,8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	0-255	

## PLC Setting:


Communication mode	<b>9600,N,8,1(default)</b>
RS232	<b>Port 0-Type:RS232</b>
RS485 2W	<b>S-BUS Mode:Data(S2),Port 1-Type:RS485</b>

## Device address:



Bit/Word	Device Type	Format	Range	Memo
B	Flag	ddd	ddd=0~8191	
B	Input	ddd	ddd=0~511	
B	Output	ddd	ddd=0~511	
D	Register	ddd	ddd=0~4095	
D	Counter	ddd	ddd=0~1599	
D	Timer	ddd	ddd=0~450	
D	Reg_Float	ddd	ddd=0~4095	support single float point

# Wiring diagram:

RS232:



RS485:



# SEW Eurodrive MOVITRAC

SEW Eurodrive series, model MOVITRAC-07 inverter

<http://sg.sew-eurodrive.com/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	SEW Eurodrive MOVITRAC		
Com port	RS-485		
PLC Station No.	0	0~255	
Baud rate	9600		
Data bit	8		
Parity bit	Even		
Stop bit	1		

## Device address:

Bit/Word	Device Type	Format	Range	Memo
W	INDEX	SSSAAAAA	S(000~255) A(08000~25000)	S: Sub index A: Index

- The MOVITRAC-07 doesn't support Sub index ( other series maybe support ) , please fixed to input 000.
- When input S and A, the correct format example as follow : Sub index 15, Index 8359, Format is 01508359


## Wiring diagram:

EasyView MT8000

RS-485 2W (COM 1)

MOVITRAC-07

RS-485



# SIEMENS S7/200

Siemens S7/200 series PLC (CPU212/214/215/216/221/222/224/226/226XM)

<http://www.ad.siemens.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	SIEMENS S7/200		
Com port	RS485	RS485	
Baud rate	9600	9600, 19200	Must same as the PLC setting
Parity bit	Even	Even, Odd, None	Must same as the PLC setting
Data Bits	8	7,8	Must same as the PLC setting
Stop Bits	1	1, 2	Must same as the PLC setting
HMI Station No.	0	0-255	
PLC Station No.	2	0-255	Must same as the PLC setting
Turn around delay (ms)	5		
Reserved 1	30		ACK delay time

Online Simulator	YES	Extend address mode	NO
Broadcast command	NO		

## PLC Setting:

Communication mode	<b>Set station number as 2</b>
--------------------	--------------------------------


## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I	dddd(o)	0-40957	Input (I)
B	Q	dddd(o)	0-40957	Output (O)

B	M	dddd(o)	0-40957	Bit Memory
B	VW.Bit	dddd(o)	0-102397	V Memory bit address
W	VW	dddd	0-10238	V memory
DW	VD	dddd	0-10236	V memory double word

\* Double word and Floating point value must use VD device type.

## Wiring diagram:



# SIEMENS S7/200 Ethernet

Siemens S7/200 Ethernet Series PLC (CPU212/214/215/216/221/222/224/226/226XM)

<http://www.ad.siemens.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Siemens S7/200 (Ethernet)		Must match the PLC's port setting.
Com port	Ethernet		Must match the PLC's port setting.
Port no.	102		Must match the PLC's port setting.
PLC station no.	1	0-31	Must match the PLC's port setting.

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I	dddd(o)	0-40957	Input (I)
B	Q	dddd(o)	0-40957	Output (O)
B	M	dddd(o)	0-40957	Bit Memory
B	VW.Bit	dddd(o)	0-102397	V Memory bit address
W	VW	dddd	0-10238	V memory
DW	VD	dddd	0-10236	V memory double word

- Double word and Floating point value must use VD device type.

## Wiring diagram:

MT8000 Ethernet Wire color

Ethernet Hub or Switch RJ45

RJ45

1	TX+	White/Orang	1	RX+
2	TX-	Orange	2	RX-
3	RX+	White/Green	3	TX+
4	BD4+	Blue	4	BD4+
5	BD4-	White/Blue	5	BD4-
6	RX-	Green	6	TX-
7	BD3+	White/Brow	7	BD3+
8	BD3-	Brown	8	BD3-



1 8 RJ45 connector

Ethernet: Direct connect (crossover cable)

**MT8000 Ethernet** Wire color

Ethernet Device

**RJ45**

**RJ45**

1	TX+	White/Orange	3	RX+
2	TX-	Orange	6	RX-
3	RX+	White/Green	1	TX+
4	BD4+	Blue	4	BD4+
5	BD4-	White/Blue	5	BD4-
6	RX-	Green	2	TX-
7	BD3+	White/Brown	7	BD3+
8	BD3-	Brown	8	BD3-

# SIEMENS S7/300

Siemens S7/300 series PLC

<http://www.ad.siemens.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	SIEMENS S7/300		
Com port	RS232		
Baud rate	19200, 38400	9600~115200	Must same as the PLC setting
Parity bit	Odd		
Data Bits	8		
Stop Bits	1		
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	2		Must same as the PLC setting

## PLC Setting:



Communication mode	
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I	dddd(o)	0-40957	Input (I)
B	Q	dddd(o)	0-40957	Output (O)
B	M	dddd(o)	0-40957	Bit Memory
B	DB0Bit-DB99Bit	dddd(o)	0-81927	Data register bit
W	DB0-DB99	dddd	0-8192	Data register(must be even)
W	IW	dddd	0-4095	Input (I)
W	QW	dddd	0-4095	Output (O)
W	MW	dddd	0-4095	Bit Memory
W	DBn	dddddd	000000-998192	Data register(must be even)
DW	DBDn	ffdddd	ff:0-99, dddd:0-8192	Data register double word (must be multiple of 4)

\* Double word and Floating point value must use DBDn device type.

# Wiring diagram:



# SIEMENS S7/300 Ethernet

Siemens S7/300 Ethernet Series PLC

<http://www.ad.siemens.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Siemens S7/300 (Ethernet)		Must match the PLC's port setting.
Com port	Ethernet		Must match the PLC's port setting.
Port no.	102		Must match the PLC's port setting.
PLC station no.	1	0-31	Must match the PLC's port setting.

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	I	dddd(o)	0-40957	Input (I)
B	Q	dddd(o)	0-40957	Output (O)
B	M	dddd(o)	0-40957	Bit Memory
B	DB0Bit-DB99Bit	dddd(o)	0-81927	Data register bit
W	DB0-DB99	dddd	0-8192	Data register(must be even)
W	IW	dddd	0-4095	Input (I)
W	QW	dddd	0-4095	Output (O)
W	MW	dddd	0-4095	Bit Memory
W	DBn	dddddd	000000-998192	Data register(must be even)
DW	DBDn	ffdddd	ff:0-99, dddd:0-8192	Data register double word (must be multiple of 4)

\* Double word and Floating point value must use DBDn device type.

## Wiring diagram:


MT8000 Ethernet Wire color

Ethernet Hub or Switch RJ45

RJ45

1 TX+	White/Orang	1 RX+
2 TX-	Orange	2 RX-
3 RX+	White/Green	3 TX+
4 BD4+	Blue	4 BD4+

5	BD4-	White/Blue		5	BD4-
6	RX-	Green		6	TX-
7	BD3+	White/Brow		7	BD3+
8	BD3-	Brown		8	BD3-



1 8 RJ45 connector

Ethernet: Direct connect (crossover cable)

**MT8000 Ethernet** Wire color

Ethernet Device

**RJ45**

**RJ45**

1	TX+	White/Orange	—————	3	RX+
2	TX-	Orange	—————	6	RX-
3	RX+	White/Green	—————	1	TX+
4	BD4+	Blue	—————	4	BD4+
5	BD4-	White/Blue	—————	5	BD4-
6	RX-	Green	—————	2	TX-
7	BD3+	White/Brown	—————	7	BD3+
8	BD3-	Brown	—————	8	BD3-

# SIMATIC TI505

SIMATIC TI505 Series PLCs: TI520, TI525, TI530, TI535, TI545, TI555, TI560, TI565, TI575

Using the NITP protocol in a point-to-point single master, single slave format.

[http://www.ad.siemens.de/simatic/controller/index\\_76.htm](http://www.ad.siemens.de/simatic/controller/index_76.htm)

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	SIMATIC TI505		
Com port	RS232	RS232, RS485(4W)	
Baud rate	19200	19200	
Parity bit	Odd	Odd	
Data Bits	7	7	
Stop Bits	1	1	
PLC Station No.	0	Does not apply	

## PLC Setting:

Communication mode	NITP protocol
--------------------	---------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	CR	dddd	dddd:1~65535	Internal Relay
B	X	dddd	dddd:1~65535	Discrete input coils
B	Y	dddd	dddd:1~65535	Discrete output coils
W	V	dddd	dddd:1~65535	User data registers
W	STW	dddd	dddd:1~65535	Status word registers
W	TCP	dddd	dddd:1~65535	Timer/counter preset values
W	TCC	dddd	dddd:1~65535	Timer/counter current values
W	WX	dddd	dddd:1~65535	Word discrete inputs
W	WY	dddd	dddd:1~65535	Word discrete outputs

## Wiring diagram:

RS-232:

MT8000 HMI

9P D-SUB

COM1 [RS232]	COM2 [RS232]	COM3 [RS232]
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

SIMATIC TI505  
25Pin D-SUB

3 RXD
2 TXD
7 GND
4 RTS
5 CTS
6 DSR
8 DCD
20 DTR

RS-232:

MT8000 HMI

9P D-SUB

COM1 [RS232]	COM2 [RS232]	COM3 [RS232]
3 TX	4 TX	7 TX
2 RX	6 RX	8 RX
5 GND	5 GND	5 GND

SIMATIC TI505  
9Pin D-SUB

2 RXD
3 TXD
5 GND
7 RTS
8 CTS
1 DCD
4 DTR
6 DSR

RS485 4W:

MT8000HMI

COM1 RS-485/4w

9P D-SUB

1 RX-		7 DO(-)
2 RX+		1 DO(+)
3 TX-		8 DI(-)
4 TX+		5 DI(+)
5 GND		6 GND

SIMATIC TI505  
9Pin D-SUB

# Telemecanique UniTelWay

Modicon TSX Micro&Nano&Neza series PLC

<http://www.modicon.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Telemecanique UniTelWay		
Com port	RS485	RS232/RS485	
Baud rate	9600	9600~115200	Must same as the PLC setting
Parity bit	Odd	Even, Odd, None	Must same as the PLC setting
Data Bits	8	7,8	Must set as 8 to this protocol
Stop Bits	1	1, 2	Must same as the PLC setting
HMI Station No.	5	4-7	<b>Must set by manual</b>
PLC Station No.	0	0-3	

Online Simulator	YES	Extend address mode	YES
Broadcast command	NO		

## PLC Setting:

Communication mode	<b>UniTelWay protocol, set PLC as master</b>
--------------------	--

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	S	ddd	0-32767	Internal relay
B	M	ddd	0-32767	Auxiliary relay
B	MW.B	ddd(dd)	0-999915	Data register bit
W	MW	ddd	0-9999	Data register

# Wiring diagram:

TSX37-XX/TSX07-XX CPU

MT8000 RS-485


9P D-SUB

COM1	COM3
1 RX-	6 Data-
2 RX+	9 Data+
5 GND	5 GND

TSX series CPU port

8P mini-din Female

2 D-
1 D+
7 GND



8Pin miniDin Female

# TOSHIBA T series

Toshiba T series, S2E

<http://www.tic.toshiba.com>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Toshiba T Serial		
Com port	RS232	RS232/RS485	In accordance with plc port
Baud rate	9600	9600, 19200,38400,57600,115200	Must same as the PLC setting
Parity bit	Odd	Even, Odd, None	Must same as the PLC setting
Data Bits	8	7,8	Must same as the PLC setting
Stop Bits	1	1, 2	Must same as the PLC setting
HMI Station No.	0	0-255	Does not apply to this protocol
PLC Station No.	0	0-255	In accordance with PLC setting

Online Simulator	YES	Extend address mode	YES
Broadcast command			

## PLC Setting:

Communication mode	<b>Must set PLC node ID</b>
--------------------	-----------------------------



## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ddd(h)	0-9999f	Input Bit
B	Y	ddd(h)	0-9999f	Output Bit
B	R	ddd(h)	0-9999f	Auxiliary Bit
B	S	ddd(h)	0-9999f	Special Bit
W	T	ddd	0-9999	Timer Register
W	C	ddd	0-9999	Counter Register
W	D	ddd	0-9999	Data Memory
W	SW	ddd	0-9999	Special Register


Bit/Word	Device Type	Format	Range	Memo
W	XW	ddd	0-9999	Input Register
W	YW	ddd	0-9999	Output Register
W	RW	ddd	0-9999	Auxiliary Register

## Wiring diagram:

### RS232



### RS485



# TOSHIBA TC mini series

TOSHIBA MACHINE CO., JAPAN

Web Site: <http://www.toshiba-machine.co.jp>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Provisor TC200	Provisor TC200	
Com port	RS232	RS232	In accordance with plc port
Baud rate	9600	9600, 19200	Must same as the PLC setting
Parity bit	None	Even, Odd, None	Must same as the PLC setting
Data Bits	8	7,8	Must same as the PLC setting
Stop Bits	1	1, 2	Must same as the PLC setting
HMI Station No.	0		Does not apply to this protocol
PLC Station No.	0		Does not apply to this protocol

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X_Bit	hhh(h)	0-fff(f)	(h) : Bit no.(0~f)
B	Y_Bit	hhh(h)	0-fff(f)	(h) : Bit no.(0~f)
B	R_Bit	hhh(h)	0-fff(f)	(h) : Bit no.(0~f)
B	L_Bit	hhh(h)	0-fff(f)	(h) : Bit no.(0~f)
W	V	hhh	0-fff	
W	P	hhh	0-fff	
W	D	hhh	0-fff	
W	R	hhh	0-fff	
W	L	hhh	0-fff	

## Wiring diagram:

RS232

MT8000 HMI

RS232 9P D-SUB



# TOSHIBA VF-S11

Toshiba Invertor Protocol(ASCII code)

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Toshiba VF-S11		
Com port	RS485(2 wire)	RS422, RS485	
Baud rate	9600	9600, 19200	
Parity bit	Even	Even, Odd, None	
Data Bits	8	7 or 8	
Stop Bits	1	1 or 2	
HMI Station No.	0		
PLC Station No.	0	0-99	

Online Simulator	YES	Extend address mode	YES
Broadcast command	YES		

## PLC Setting:

Communication mode	9600 E,8,1, Station No=0
--------------------	--------------------------

## Device address:

Bit/Word	Device Type	Format	Range	Memo
Word	Communication No.	HHH	HHH:0~ 0FFF	Parameters and data memory
Bit	Comm.No.Bit	HHH(DD)	HHH(DD):0-FFF(15)	

## Wiring diagram:

### Pay Attention:

Before you connect the VF-A11, Make sure you have put two switch on of sw1.(SW1: Wiring method selector switch)

# RS-485


**MT8000 PLC[RS485]**

9P D-SUB male

1	RX-
2	RX+
5	GND

Toshiba VF-S11  
communication port

RXB
RXA
SG



# VIGOR

VIGOR M Series

<http://www.vigorplc.com.tw/>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	VIGOR		
Com port	RS232	RS232, RS485 4wires,	
Baud rate	19200		
Parity bit	Even		
Data Bits	7		
Stop Bits	1		
HMI Station No.	0		
PLC Station No.	1		

## PLC Setting:


Communication mode	None

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X	ooo	0~177	
B	Y	ooo	0~177	
B	M	dddd	0~4095	
B	S	ddd	0~999	
B	T	ddd	0~255	
B	C	ddd	0~255	
W	TV	ddd	0~255	
W	CV	ddd	0~255	
W	D	dddd	0~4095	
W	DL	dddd	0~4095	Double word

## Wiring diagram:

RS-485 4wire:



RS-232:



# Yokogawa FA-M3

FA-M3 CPU SP35-5N, SP55-5N CPU port, F3LC11 Computer Link module.

<http://www.yokogawa.com/itc/itc-index-en.htm>

## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Yokogawa FA-M3		
Com port	RS232		
Baud rate	19200	9600, 19200	
Parity Bit	Even	Even, Odd, None	
Data Bits	8	8	
Stop Bits	1	1	
HMI Station No.	0		
PLC Station No.	1	1-31	

## PLC Setting:

Communication mode	<b>Use Personal Communication Link</b> <b>Use checksum</b> <b>Use End Character</b>
--------------------	---

## Device address:

Bit/Word	Device Type	Format	Range	Memo
B	X	ddd	201-71664(discontinuous)	
B	Y	ddd	201-71664(discontinuous)	
B	I	ddd	1-16384	
B	L	ddd	1-71024(discontinuous)	
B	M	ddd	1-9984	
W	D	ddd	1-8192	
W	B	ddd	1-32768	
W	V	ddd	1-64	
W	W	ddd	1-71024(discontinuous)	

W	Z	ddd	1-512	
---	---	-----	-------	--

## Wiring diagram:


RS-232: CPU port

MT8000 RS232

9P D-SUB

CPU port cable

KM11 RS-232




RS-232: LC11

MT8000 RS232

9P D-SUB Female


LC11 Computer

Link module RS232



## How to get the WideField communication setting

If you want get the WideField communication setting, select [Tool]->[Set Environment] default is Automatic. Using the Automatic Recognition, Wide Field software will connect the Current PLC and get the PLC communication setting. If you have know the PLC communication configuration, you also can select the Fixed mode ,It will connect the PLC quickly.




P.S Because use Personal computer link, when you connecting to PLC it will delay about 20sec for test communication.

## How to Setting YOKOGAWA PLC Communcation configuration.


YOKOGAWA FA-M3


CPU SP55-5N (same SP35-5N)


[File]->[New Project] to create a new project



click "Configuration" for setup communication.







# Yokogawa FA-M3 (Ethernet)

FA-M3 CPU SP35-5N, SP55-5N with F3LE01-5T/F3LE11-0T Ethernet module.

<http://www.yokogawa.com/itc/itc-index-en.htm>


## HMI Setting:

Parameters	Recommend	Option	Notes
PLC type	Yokogawa FA-M3 (Ethernet)		
Com port	Ethernet		
TCP port no.	12289		
HMI Station No.	0		
PLC Station No.	1		

## PLC Setting:

Communication mode	<b>Set IP Address</b> <b>Set all condition setup switch OFF.</b>
--------------------	---

Right-side View



Operating Condition Setup Switch

IP Address Setup Switch

Example: Setting the IP address to 192.168.250.210

C ←	A ↙	F ↘	D ↗
0 ↑	8 ↓	A ↙	2 ↗

Hexa	C0	A8	FA	D2
decimal	↑	↑	↑	↑
Decimal	192	168	250	210

## Device address:


Bit/Word	Device Type	Format	Range	Memo
B	X	ddd	201-71664(discontinuous)	
B	Y	ddd	201-71664(discontinuous)	
B	I	ddd	1-16384	
B	L	ddd	1-71024(discontinuous)	
B	M	ddd	1-9984	
W	D	ddd	1-8192	
W	B	ddd	1-32768	
W	V	ddd	1-64	

W	W	ddd	1-71024(discontinuous)	
W	Z	ddd	1-512	

## Wiring diagram:

Ethernet:

MT8000 Ethernet			Wire color	Ethernet Hub or Switch		
RJ45				RJ45		
1	TX+	White/Orange		1	RX+	
2	TX-	Orange		2	RX-	
3	RX+	White/Green		3	TX+	
4	BD4+	Blue		4	BD4+	
5	BD4-	White/Blue		5	BD4-	
6	RX-	Green		6	TX-	
7	BD3+	White/Brown		7	BD3+	
8	BD3-	Brown		8	BD3-	



1 8  
RJ45

Ethernet: Direct connect (crossover cable)

MT8000 Ethernet			Wire color	FA-M3 Ethernet module		
RJ45				RJ45		
1	TX+	White/Orange		3	RX+	
2	TX-	Orange		6	RX-	
3	RX+	White/Green		1	TX+	
4	BD4+	Blue		4	BD4+	
5	BD4-	White/Blue		5	BD4-	
6	RX-	Green		2	TX-	
7	BD3+	White/Brown		7	BD3+	
8	BD3-	Brown		8	BD3-	

## Chapter 24 MT8000 Supports Printers

MT8000 print function supports EPSON ESC/P2, HP PCL and SP Printer.

### 1. EPSON ESC/P2

#### **Impact Printers:**

LQ-300, LQ-300+, LQ-300K+ (RS232)

LQ-300+II (RS232, USB)

#### **Inkjet Printer:**

Stylus Photo 750 (USB)

#### **Laser Printer: (USB)**

EPL-5800

### 2. HP PCL Series

USB port, conform to HP PCL level 3 protocol.

#### **Laser Printer**

HP LaserJet P1505n: HP PCL 5e

- PCL 5 was released on the HP LaserJet III in March 1990, adding Intellifont font scaling (developed by Compugraphic, now part of Agfa), outline fonts and HP-GL/2 (vector) graphics.
- PCL 5e (PCL 5 enhanced) was released on the HP LaserJet 4 in October 1992 and added bi-directional communication between the printer and the PC and Windows fonts.

**Caution:** For HP printer, we do not support

1. HP LaserJet P1005 which is not PCL 5.
2. HP LaserJet P1006
3. HP LaserJet 1000 which is support HostBase Printing language
4. HP LaserJet 1010 which is support HostBase Printing language
5. HP Color LaserJet 1500 which is support HostBase Printing language
6. HP Color LaserJet 3500 which is support HostBase Printing language

**Please ensure the HP printer has supported PCL5 before connect with MT8000 series.**

**Inkjet Printer:**

HP DeskJet 920C, 930C, D2360

**3. SP-M, D, E, F**

EPSON ESC protocol 9-pin printer.

RS232 port

SIUPO

<http://www.siuipo.com>

SP-M, D, E, F series

SP-E1610SK (paper width: 45mm)

SP-E400-4S (paper width: 57.5mm)



SP-MDEF




Recommended SP printer type for customers outside China


## Appendix A. Recipe Editor


RecipeEditor is a Win32 application and only can run on MS Windows 2000, XP and Vista. It allows users to create, view and modify recipe (\*.rcp) and EMI (\*.emi) files. Additionally, it can convert recipe and EMI files to CSV format and vice versa.

### A.1 Introduction


In [Menu] → [File], select [Open...] and choose a recipe or EMI file, you will see the following dialogue appears:



<b>[Address range]</b>	To fill the range of the address users want to examine.  
<b>[Add...]</b>	Add a column to the current data format template.
<b>[Delete]</b>	Delete the selected column.

<b>[Clear All]</b>	Delete all columns.
<b>[Modify...]</b>	Modify the description and data type for the selected column.
<b>[Save Format]</b>	Save the settings of the current data format template so that users can load it every time when needed without recreating it repeatedly. The template data will be stored in “data.fmt” file in the EasyBuilder8000 installation directory.
<b>[Delete Format]</b>	Delete an existed data format template.
<b>[Select your data format]</b>	Select an existed data format template for examining the recipe or EMI data.  

After clicking [Add...], [Data Type] dialogue will appear as follow:




First, you can assign a readable name as [Description] for the column. And select the correct data type for the column. If [String] is selected as data type, you must specify the length of the string in addition.


## A.2 Setting of Recipe Editor

### How to Add a Recipe / EMI File


(1) In [Menu] → [File], select [New] and the following dialogue will appear:



(2) Click [Add...] and select [16-bit Unsigned] as data format type.



(3) After all the settings finish, a new document appears as follow



(4) Users can view and modify the data in the sheet.

(5) In [Menu] → [File] → [Save As], select the correct format and file name to create a recipe or EMI file.

### Export to CSV File

After opening a recipe or EMI file, select [Menu] → [File] → [Save As] and choose file format as CSV.

### Import CSV File


In [Menu] → [File], select [Import CSV File] and choose a CSV file to open. After editing, users can save it as a recipe or EMI file so that it can be downloaded to MT8000 series.

## Appendix B. EasyConverter

This application program is utilized when the history record of data sampling (dtl) or event log (evt) is uploaded to PC, which can be transferred to Excel (csv).

### B.1 Introduction

In Project Manager, clicking the “EasyConverter” will pop up the application program.



There are four function introductions as follows:

- Export to Excel
- Scaling function
- Multi-File Conversion
- Command line

### B.2 Setting of EasyConverter

#### B.2.1 How to Export to Excel

When open the file, it will pop up setting dialog as follow:




There are four options of time format which can be selected.

<b>No millisecond information</b>	Ex: <input type="text" value="HH:MM:SS"/>
<b>Separated by a COMMA sign</b>	Ex: <input type="text" value="HH:MM:SS,###"/>
<b>Separated by a DOT sign</b>	Ex: <input type="text" value="HH:MM:SS.###"/>
<b>Parenthesized</b>	Ex: <input type="text" value="HH:MM:SS(###)"/>


If checking “Don’t ask me again”, the pop-up window will not appear next time.

If you need to modify the time format, please go to Options / Time Format to call up the setting dialog.

After setting, click OK. And next setting dialog pops up, as follow:



Click OK.




Export to Microsoft Excel.

	A	B	C
1	[Creation time]		
2	Thu Nov 27 10:51:06 2008		
3	[Data]		
4	"Time"	"16-bit Unsigned"	
5	10:51:06	0	
6	10:51:07	0	
7	10:51:08	1	
8	10:51:23	0	
9	10:51:24	0	
10	10:51:25	1	
11	10:51:26	1	
12	10:51:27	2	
13	10:51:28	3	
14	10:51:29	3	
15	10:51:30	4	

## B 2.2 How to Use Scaling Function

The **scaling** is utilized to offset data.




new value =  $\{(value+A) \times B\} + C$ , users can set a value on A, B, and C.

### Why do we need the Scaling function?

For example, here is a data of voltage and data format is 16-bit unsigned (rang: 0~4096). Users want to map those data to volt whose range is from -5 to +5.


new value =  $\{(value+0) \times 0.0024\} + (-5)$ , as follow:




Above sampling data of setting can be saved and loaded next time.

After the scaling

Original file




After utilizing scaling function file



### B.2.3 How to Use Multi-File Conversion

**Step1:** Clicking the File / Multi-File will pop up the setting dialog.


**Step2:** Click “Add File...” to add files into “List”.



**Step3:** After adding files, check the “**Combine to a file**” to export those files to a single Excel file (xls).

	A	B	C
1	[Creation time]		
2	Thu Nov 27 10:51:06 2008		
3	[Data]		
4	"Time"	"16-bit Unsigned"	
5	10:51:06		0
6	10:51:07		0
7	10:51:08		1
8	10:51:23		0
9	10:51:24		0
10	10:51:25		1
11	[Creation time]		
12	Fri Nov 28 17:05:09 2008		
13	[Data]		
14	"Time"	"16-bit Unsigned"	
15	17:05:09		0
16	17:05:10		0
17	17:05:11		0
18	17:05:12		0
19	17:05:13		0


Note: If you don't check the box, the files will be exported to Excel individually.




### B.3 Enable Setting File

A user can load an existent Setting file to apply to a data log file(s).


**Step1:** Save the setting to test.lgs after filling out "scaling & offset"



**Step2:** In a new data sampling, click “Load Setting” to load test.lgs.




**Step3:** Press “Export to Microsoft Excel” button to examine the data.




### B.3.1 For “Combination” and “Enable Setting File”


**Step1:** Click Multi-File




**Step2:** Select “Add File...”



**Step3:** Select the files that you would like to combine and check both of “Enable Setting file” and “Combine to a file” boxes. With “Combine to a file” edit, please indicate a file name for the new outcome.



**Step4:** After pressing OK, the data will display on the dialog.



**Step5:** Open the new combined file to examine the data in Microsoft Excel.

## B.4 Command Line

For EasyConverter, users can run in a command mode.


EasyConverter[/c]/s]/t[num]] setting source destination

setting	Indicate the setting file.(*.lgs)
source	Indicate the source file.(*.dtl or *.evt)
destination	Indicate the destination file.(*.csv or *.xls)
/c	Output file type. If set the flag, output a CSV file, or the output file will be an Excel file.
/s	Weather involving a setting file or not. If set the flag, it indicates that users utilize a setting file.
/t[num]	Time format. For example: t2 indicates “Separated by a DOT sign”.

For example: EasyConverter.exe /c /s /t3 "E:\Work\20080625.lgs" "E:\Work\ 20080625.dtl"  
"E:\Work\"

## Appendix C. EasyPrinter


EasyPrinter is a Win32 application and only can run on MS Windows 2000, XP and Vista. It enables MT8000 Series to output screen hardcopies on a remote PC via Ethernet. Please see the following illustration:




Here are some advantages of using EasyPrinter:

- EasyPrinter provides two modes of hardcopy output: Print-Out and Save-to-File. Users can use either way or both ways.
- Since EasyPrinter is running on the MS Windows system, it supports most of the available printers on the market.
- Multiple MT8000 HMIs can share one physical printer via EasyPrinter. Users do not have to prepare printers for each MT8000 HMI.

Additionally, EasyPrinter can also be a backup server. Users can use backup objects on MT8000 HMIs to copy history files such as Data-Sampling's and Event-Log's histories onto a remote PC via Ethernet. Please see the following illustration:




## C.1 Using EasyPrinter as a Printer Server



Users can make screen hardcopies with a Function-Key object. The hardcopies will be transferred to the MT Remote Printer Server via Ethernet and then printed out.

### C.1.1 Setup Procedure in EasyPrinter


In [Menu] → [Options], select [Settings...] and the following dialogue box will appear:



1. In [Server], assign [Port number of the server socket] to “8005”, [User name] to “admin” and [Password] to “111111”. (Note: These are default values.)

2. In [Naming Convention for HMI Folder], select [Use IP address] and assign “IP\_” as the [Prefix].
3. In [Properties], select [Minimize to system tray].


Click [Hardcopy] tab at the left side in the dialogue box as follows:



4. In [Output], select [Print out to] and choose a printer as the output device for screen hardcopies. (Note: You can only choose from the printers available in your system, so it is normal if you do not see “hp LaserJet 3380 PCL 5” on your list as the example.)
5. Click [OK] to apply the settings.
6. In [Menu] → [File], select [Enable Output] to allow EasyPrinter to output any incoming print request, i.e. screen hardcopy.


### C.1.2 Setup Procedure in EasyBuilder8000

In [Menu] → [Edit] → [System Parameters], click [Printer Server] tab and select [Use MT Remote Printer Server], the following dialogue box will appear:



7. In [Output settings], assign appropriate values for left/top/right/bottom margins. (Note: The margins are all assigned to 15mm in the example.)
8. In [Communication settings], fill in the IP address of the printer server and same as step 1, assign the port number to “8005”, [User name] to “admin” and [Password] to “111111”.

In [Menu] → [Objects] → [Buttons], select [Function Key] and assign [Screen hardcopy] to [MT Remote Printer Server].




9. Place the Function-Key object in the common window (window no. 4), and you will be able to make screen hardcopies anytime when needed.
10. Compile and download your project to the MT8000 HMI. Press the Function-Key

object set in step 9 to make a screen hardcopy.

#### NOTE

- You can also use a PLC-Control object to make screen hardcopies.
- You cannot print alarm information via EasyPrinter.
- EasyPrinter can only communicate with HMI via Ethernet, so this feature is unavailable in MT6000 Series.


## C.2 Using EasyPrinter as a Backup Server



Users can upload historical data such as Data-Sampling and Event-Log history files onto the MT remote backup server with Backup objects.


### C.2.1 Setup Procedure in EasyPrinter

In [Menu] → [Options], select [Settings...] and the following dialogue box will appear:



1. In [Server], assign [Port number of the server socket] to “8005”, [User name] to “admin” and [Password] to “111111”. (Note: These are default values.)
2. In [Naming Convention for HMI Folder], select [Use IP address] and assign “IP\_” as the [Prefix].
3. In [Properties], select [Minimize to system tray].

Click [Backup] tab at the left side in the dialogue box as follows:




4. In [Output], click the  button to browse and select a path for storage of the incoming history files.
5. Click [OK] to apply the settings.

6. In [Menu] → [File], select [Enable Output] to allow EasyPrinter to store any incoming backup request in the location specified in step 4.


## C.2.2 Setup Procedure in EasyBuilder8000

In [Menu] → [Edit] → [System Parameters], click [Printer Server] tab and select [Use MT Remote Printer Server], the following dialogue box will appear:



7. In [Communication settings], fill the IP address of the printer server and same as step 1, assign port number to “8005”, [User name] to “admin” and [Password] to “111111”.

In [Menu] → [Objects], select [Backup] and the following dialogue box will appear:




8. In [Source], select [Event log].
9. In [Backup position], select [Remote printer server].
10. In [Range], select [Today] and [All].
11. In [Attribute], select [Touch trigger].
12. Place the Backup object in the common window (window no. 4), and you will be able to make backups anytime when needed.
13. Compile and download your project to the MT8000 HMI. Press the Backup object set in step 12 to make a backup of the Event-Log history data.

**NOTE**

- The Backup object can be triggered via a bit signal.
- Users can arrange a Scheduler object, which turns a bit ON at the end of week, to trigger a Backup object to automatically back up all history data.

## C.3 EasyPrinter Operation Guide

### C.3.1 Appearance



Area	Name	Description
1	Job List	This window lists all incoming tasks, i.e. screen hardcopy and backup requests.
2	Property Window	This window shows the information about the task selected from “Job List.”
3	Preview Window	This window shows the preview image of the screen hardcopy task selected from “Job List.”
4	Download Progress Window	This window shows the download progress of incoming requests.
5	Message Window	This window shows the time and message of events such as incoming request, incorrect password, etc.


### C.3.2 Operation Guide

The following tables describe the meaning and explain how to use all EasyPrinter menu items.

Menu → File	Description
Enable Output	<ul style="list-style-type: none"> <li>• <b>Select</b> EasyPrinter processes the tasks one by one.</li> <li>• <b>Unselect</b> EasyPrinter arranges the incoming tasks in memory.</li> </ul>

**NOTE**

- EasyPrinter can only reserve up to 128 MB of task data in memory. If the memory is full, any request coming in afterwards will be rejected and users must either operate [Enable Output] or delete some tasks to make room for new tasks.

Menu → Edit	Description
Edit	<p>To edit a screen hardcopy task.</p>  <p>Users can freely change the properties of [Orientation], [Scaling] and [Margins] here.</p>
Delete	To delete the selected tasks permanently.
Select All	To select all tasks from “Job List.”


**NOTE**

- The backup task is not editable.
- [Edit] is available only when a task is selected.
- [Delete] is available when at least one task is selected.

Menu → View	Description
Properties Bar	To show or hide the Property Window.
Preview Bar	To show or hide the Preview Window.
Download Bar	To show or hide the Download Progress Window.
Logger Bar	To show or hide the Message Window.


**NOTE**

- In Download Progress Window, users can select the mode to show download progress by clicking the header of the progress column. Please see the following illustration:




- EasyPrinter can reserve up to 10,000 messages in Message Window. If a new message comes in, the oldest message will be deleted.

Menu → Options	Description
Toolbars	To show or hide toolbars.
Status Bar	To show or hide the status bar.
Settings	<p>Configuration for EasyPrinter. Please refer to the following illustrations:</p> <p><b>[General]</b></p>



- **[Server] → [Port number of the server socket]**  
Set the Ethernet socket number for HMIs to connect to. The range goes from 1 to 65535 and 8005 is the default value.
- **[Server] → [User name] & [Password]**  
Set the user name and password to restrict that only the authorized HMIs can send requests to EasyPrinter.
- **[Naming Convention for HMI Folder]**  
EasyPrinter creates different folders to store files (e.g. hardcopy bitmap files, backup files) from different HMIs. There are two ways to name the folders:
  - a. **Use IP address**  
EasyPrinter names the folder after the IP address of the HMI sending the request. (i.e. [Prefix] + [IP address]) Please see the following illustration:



### b. Use HMI name

EasyPrinter names the folder after the name of the HMI sending the request. (i.e. [Prefix] + [HMI name])


- **[Properties] → [Minimize to system tray]**

Select this option to minimize EasyPrinter to system tray instead of task bar. Users can double-click the icon in system tray to restore the EasyPrinter window.

- **[Properties] → [Detailed message]**

Select this option to display more detailed messages about events in the message window.

### [Hardcopy]



- **[Output]**

EasyPrinter provides two modes to output hardcopy results: Print-Out and Save-to-File.

#### a. Print-Out

Select this option to inform EasyPrinter to print out the hardcopy result on specified printers.


#### b. Save-to-File

Select this option to inform EasyPrinter to convert the hardcopy result into a bitmap file and save it in the specified directory.

Users can find the bitmap files at:

[Specified Path] →  
[HMI Folder] →  
yymmdd\_hhmm.bmp

For example, when a hardcopy request is given at 17:35:00 12/Jan/2009, the bitmap file will be named “090112\_1735.bmp”. And if there is another bitmap file generated in the same minute, it will be named “090112\_1735\_01.bmp” and so on.



- **[Output]**

EasyPrinter stores the backup files to the specified path.

**For Event-Log historical data files:**

[Specified Path] →  
[HMI Folder] →  
[eventlog] →  
EL\_yyyymmdd.evt

**For Data-Sampling historical data file:**

[Specified Path] →  
[HMI Folder] →


	<p>[datalog] → [Folder name of the Data-Sampling object] → yyyymmdd.dtl</p> <p><b>For Recipe:</b> [Specified Path] → [HMI Folder] → [recipe] → recipe.rcp or recipe_a.rcp</p> <ul style="list-style-type: none"><li>• <b>[Convert Batch File]</b> Select [Enable] and assign a Convert Batch File for automatically converting uploaded history files to CSV or MS Excel format. Please refer to the next section for the details of Convert Batch File.</li></ul>
--	--

**NOTE**

- Users can assign HMI names from LW9032 to LW9039.
- EasyPrinter names the folder after IP address if HMI name is not set.

## C.4 Convert Batch File

EasyPrinter provides a mechanism for converting the uploaded Data-Sampling and Event-Log history files stored in binary mode to CSV files automatically. Users requesting this function have to prepare a **Convert Batch File** to provide EasyPrinter with the information of how to convert the history files.



As shown in the above illustration, the conversion is actually carried out by **EasyConverter**. EasyPrinter simply follows the criteria in Convert Batch File and activates EasyConverter with proper arguments to achieve the conversion.

### NOTE

- EasyConverter is another Win32 application converting history data into CSV or MS Excel (\*.xls) files. Users can find it in the EasyBuilder 8000 installation directory.
- Users requesting this function must ensure EasyPrinter and EasyConverter are placed in the same directory.

### C.4.1 The Default Convert Batch File

The following is the default Convert Batch File included in the EasyBuilder 8000 software package:

#### The default Convert Batch File (convert2csv.def)

- ```
1:    "dtl", "EasyConverter /c $(PathName)"
2:    "evt", "EasyConverter /c $(PathName)"
```

There are two lines of text in the file. Each line has two arguments separated by a comma and forms a criterion of how to deal with a specific type of files, e.g. Data-Sampling and Event-Log history files. The first argument specifies the extension name for the type of the files to be

processed and the second one specifies the exact command to execute in console mode. Please note “\$(PathName)” is a key word to tell EasyPrinter to replace it with the real name of the backup file in conversion. For example, if a Data-Sampling history file named **20090112.dtl** is uploaded and stored, EasyPrinter will send out the following command to a console window:

```
EasyConverter /c 20090112.dtl
```

And then the CSV file named **20090112.csv** is created.

Therefore, the criteria of the default Convert Batch File are:

1. Convert all Data-Sampling history files (\*.dtl) into CSV files.
2. Convert all Event-Log history files (\*.evt) into CSV files.

#### NOTE

- Actually, the “\$(PathName)” in the second argument stands for the full path name of the file. In the previous case, EasyPrinter replaces it with:  

```
[Specified Path] \ [HMI Folder] \ [datalog] \  
[Folder name of the Data-Sampling object] \ 20090112.dtl
```
- EasyPrinter interprets the Convert Batch File on a line basis, i.e. each line forms a criterion.
- Any two arguments should be separated by a comma.
- Every argument should be put in double quotes.
- Do not put any comma inside an argument.
- For further information about how to use EasyConverter, please refer to the manual -- **Appendix EasyConverter.**

### C.4.2 Specialized Criteria

Sometimes users may need a special handling for the files uploaded from a specific HMI. Here is an example:

```
Specialized Criterion for the HMI with IP = 192.168.1.26  
3:      "dtl", "EasyConverter /c $(PathName)", "192.168.1.26"
```

Or users can also specify the HMI with its name.

```
Specialized Criterion for the HMI with name = Weintek_01  
4:      "dtl", "EasyConverter /c $(PathName)", "Weintek_01"
```

Or in the case of needing special handling for different Data-Sampling history files.

### Specialized Criterion for the Data-Sampling object's folder name = Voltage

5: "dtl", "EasyConverter /s Voltage.lgs \$(PathName)", "\*", "Voltage"

The 5<sup>th</sup> criterion can be only performed on the history files uploaded from the Data-Sampling objects with the folder name of “Voltage”. The 3<sup>rd</sup> argument (“\*”) indicates this criterion accepts the qualified Data-Sampling files from any HMI. Users can also change the 3<sup>rd</sup> argument to “192.168.1.26”, “192.168.1.\*”, HMI name, etc. for narrowing the target HMIs.

### C.4.3 The Format of a Convert Batch File

The following table explains all arguments in a criterion.

| No | Argument                         | Description                                                                                                                                                                                                             |
|----|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | File Type                        | This argument specifies the extension name of the uploaded files this criterion targets. (e.g. “dtl” for Data-Sampling history files, “evt” for Event-Log history files)                                                |
| 2  | Command Line                     | The exact command EasyPrinter sends to a console window if the uploaded file is qualified.                                                                                                                              |
| 3  | a. HMI IP address<br>b. HMI name | This argument specifies the HMI this criterion targets.                                                                                                                                                                 |
| 4  | Condition 1                      | <ul style="list-style-type: none"><li>• <b>If the file type is “dtl”</b><br/>This argument specifies the folder name of the Data-Sampling objects this criterion targets.</li><li>• <b>Others</b><br/>No use.</li></ul> |
| 5  | Condition 2                      | No use. (reserved for further use)                                                                                                                                                                                      |

### C.4.4 The Order of Examining Criteria

EasyPrinter examines criteria in ascending order every time a file is uploaded. Once the file is qualified for a criterion, it stops the examination and starts over for next file. Therefore, **users should place the criteria with more specification upward in the Convert Batch File and place the less-specific criteria downward**. Take the 5 criteria mentioned in the previous sections for example, the correct order is:

## Correct order for the previous criteria

"dtl", "EasyConverter /s Voltage.lgs \$(PathName)", "\*", "Voltage"

"dtl", "EasyConverter /c \$(PathName)", "EasyView"

"dtl", "EasyConverter /c \$(PathName)", "192.168.1.26"

"dtl", "EasyConverter /c \$(PathName)"


"evt", "EasyConverter /c \$(PathName)"

## Appendix D. EasySimulator

EasySimulator enables users to perform Online/Offline simulation without installing EasyBuilder8000 software. To achieve that, users have to prepare the following files in one folder.

### D.1 Prepare Files


1. [driver] → [win32]
2. 320x234.bmp
3. 480x234.bmp
4. 640x480.bmp
5. 800x480.bmp
6. 800x600.bmp
7. 1024x768.bmp
8. com.exe
9. gui.exe
10. xob\_pos.def
11. EasySimulator.exe



Users can find all the above files in EasyBuilder8000 installation directory, which means users have to install EasyBuilder8000 software package on a PC and copy the files to the target PC.

### D.2 Modify the Content of xob\_pos.def


Step1. Open xob\_pos.def using a text editing tool (e.g. Notepad).



```
File Edit Format View Help
"0" //operation mode, 0 : off-line, 1 : on-line
"c:\Easysimulator" // define the directory of com.exe and gui.exe
"c:\Easysimulator\MT8000_Demo_800x600.xob" //define the directory of xob file
```

| Line No. | Description                                                                                    |
|----------|------------------------------------------------------------------------------------------------|
| 1        | <p>["0"]<br/>Perform Offline simulation</p> <p>["1"]<br/>Perform Online simulation</p>         |
| 2        | Specify the full path where the files (e.g. com.exe, gui.exe, EasySimulator.exe, etc.) locate. |
| 3        | Specify the full path of the project file (*.xob)                                              |

Step2. Double click EasySimulator.exe to start the simulation



Step3. ON-Line/OFF-Line simulation is display on the screen.



## Appendix E. Multi-HMIs Intercommunication (Master-Slave Mode)

Multi-HMIs intercommunication means that HMI uses COM port to connect a remote HMI, and read/write data from/to a remote PLC as below:



Above shows the PLC connects HMI 1, and HMI 1 connects HMI 2 via COM port, so that the HMI 2 can control the PLC by way of HMI 1.

An example describes how to use EB8000 to create projects used on HMI 1 and HMI 2.

### E.1 How to Create a Project of Master HMI

Below show the content of HMI 1's [System Parameter Settings] / [Device list]

| No.          | Name                | Location | Device type            | Interface          | I/F P |
|--------------|---------------------|----------|------------------------|--------------------|-------|
| Local HMI    | Local HMI           | Local    | MT6056T/MT8056T (32... | Disable            | N/A   |
| Local PLC 1  | FATEK FB Series     | Local    | FATEK FB Series        | COM1(9600,E,7,1)   | RS23  |
| Local Server | Master-Slave Server | Local    | Master-Slave Server    | COM2(115200,E,8,1) | RS23  |

1. Due to HMI 1's COM 1 connects PLC, the device list must include [Local PLC 1]. This example's [Local PLC 1] is "FATEK FB Series" and PLC's communication parameter is "9600, E, 7, 1".
2. Users must add a new device - "Master-Slaver Server" for setting COM 2's communication properties. Because HMI 1's COM 2 is used to receive commands from HMI 2. Above picture shows the COM 2's parameters are "115200, E, 8, 1", and uses RS232. These parameters have

not been restricted to be the same as COM 1, but the “data” bits must set to 8. In general, COM 2 is set to use a higher baud rate for more efficient communication.

## E.2 How to Create a Project of Slave HMI

| No.           | Name            | Location                 | Device type   | Interface           |
|---------------|-----------------|--------------------------|---------------|---------------------|
| Local HMI     | Local HMI       | Local                    | MT6056T/M...  | Disable             |
| *Remote PLC 1 | FATEK FB Series | COM 1 (master-slave m... | FATEK FB S... | COM1 (115200,E,8,1) |


Above picture shows HMI 2’s content of [Device list]. HMI 2 wants to control PLC via HMI 1, thus HMI 2 recognizes this PLC as a remote PLC. So it is necessary that add a [\*Remote PLC 1] into the device list. This example shows the remote PLC is “FATEK FB Series”. How to create [\*Remote PLC 1] is described below:

### Step 1

Create a new device and select ”FATEK FB Series” for [PLC type]. [PLC default station no.] must be set correctly.


### Step 2

Correctly set the parameters. HMI 2’s COM 1 connects HMI 1’s COM 2, so they both must have the same communication parameters and interfaces, ignoring the PLC parameters. As below, HMI 1’s COM 2 and HMI 2’s COM 1 use RS232 and the parameters are [115200, E, 8, 1].



### Step 3

Change [Location] to [Remote], and select [COM port] to connect remote HMI 1.



Device list :

| No.           | Name            | Location                  | Device type        | Interface    |
|---------------|-----------------|---------------------------|--------------------|--------------|
| Local HMI     | Local HMI       | Local                     | MT6056T/MT8056T... | Disable      |
| *Remote PLC 1 | FATEK FB Series | COM 1 (master-slave mode) | FATEK FB Series    | COM1(115200) |

After completing all settings described above, users can find a new device named [\*Remote PLC 1] on the device table. This device has the “\*” symbol to mean that HMI uses a COM port (not ethernet) to control a remote PLC via other HMI.

Users can check HMI’s local registers to view the communication status.



|                |                                            |
|----------------|--------------------------------------------|
| <b>LB-9150</b> | When ON, auto. connection for PLC1 (COM 1) |
| <b>LB-9151</b> | When ON, auto. connection for PLC2 (COM 2) |
| <b>LB-9152</b> | When ON, auto. connection for PLC3 (COM 3) |

|                              |                                                                                                                                                                                                                                                                                                                                                                             |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>LB-9200~<br/>LB-9455</b>  | <p>This local registers indicate the connection states between COM 1 and PLC<br/>LB9200 indicates the state between COM 1 and PLC SN0 (station no. 0), and LB9201 indicates the state between COM 1 and PLC SN1.....</p> <p>When ON, it means that connection is normal.<br/>When OFF, it means that disconnect with PLC, and set on to retry connecting activity once.</p> |
| <b>LB-9500~<br/>LB-9755</b>  | <p>This local registers indicate the connection states between COM 1 and PLC<br/>LB9500 indicates the state between COM 1 and PLC SN0 (station no. 0), and LB9501 indicates the state between COM 1 and PLC SN1.....</p> <p>When ON, it means that connection is normal.<br/>When OFF, it means that disconnect with PLC, and set on to retry connecting activity once.</p> |
| <b>LB-9800~<br/>LB-10055</b> | <p>This local registers indicate the connection states between COM 1 and PLC<br/>LB9800 indicates the state between COM 1 and PLC SN0 (station no. 0), and LB9801 indicates the state between COM 1 and PLC SN1.....</p> <p>When ON, it means that connection is normal.<br/>When OFF, it means that disconnect with PLC, and set on to retry connecting activity once.</p> |

## Appendix F. Pass-Through Function

The pass-through function allows the PC application to connect PLC via HMI, and the HMI acts as a converter at this moment.

The pass-through function provides two modes: Ethernet and COM port. To click [Pass-through] on Project Manager will display the application.




### F.1 Ethernet Mode

#### [How to install virtual serial port driver]

Before using ethernet mode, please check whether virtual serial port driver is installed as described below:


If [Virtual COM port (PC<->PLC)] displays [Please install weintek virtual serial port driver], please click [Install].



If install processing pops up a dialog as follows, please click [Continue Anyway].




After processing is completed, the virtual COM port is displayed as follows.




## F.1.1 How to Change the Virtual Serial Port



Open [System Properties]->[Device Manager] to check if the virtual serial port is installed successfully.




If users want to change the number of virtual serial port, please click [Weintek Virtual Serial Port] to open [Port Settings] / [Advanced...], as follows:




For example, users change virtual serial port from COM 3 to COM 9.



Select COM 9 and click [OK], the virtual serial port will be changed to COM 9.



It can be found that the virtual COM port be changed to COM 9 on Project Manager.



## F.1.2 How to Use Ethernet Mode

After installing virtual serial port driver, users should follow four steps to use ethernet mode of pass-through.

### Step 1


Set HMI IP connecting PLC. For example, HMI IP is 192.168.1.206

### Step 2

Assign HMI's serial port properties and this port is used to connect PLC. For example, COM2 RS232 is used to connect PLC.


### Step 3

Click [Apply], and these settings will be update.




#### Step 4


On the PC application, the serial port's number must be same as virtual serial port. For example, using a Mitsubishi application, if the virtual serial port is COM 7, please open [PC side I/F Serial setting] / [COM port] to select COM 7, as follows:



After completing all settings, when users execute PC's PLC application, the HMI will be switched automatically to pass-through mode (the communication between HMI and PLC will be suspended just now and it will be resumed if the application closes), as follows:



## F.2 COM Port Mode



### Source COM Port

The port is used between HMI and PC.

### Destination COM Port

The port is used between HMI and PLC.

When using COM port mode of pass-through, users should select the source and destination com port first.

### F.2.1 Settings of COM Port Mode

There are two ways to enable COM port mode of pass-through function.

#### (1) Use Project Manager


#### (2) Use LW-9901 and LW9902

LW-9901: source COM port (1~3: COM1~COM3)

LW-9902: destination COM port (1~3: COM1~COM3)

#### Start pass-through on project manager.

Click [Pass-through] button on the Project Manager to set the communication parameters.



**[HMI IP]**

Assign HMI's IP address.

**[Get HMI Communication Parameters]**

To get the settings of source and destination COM port, that parameters come from reserved addresses, the details of addresses as follow.

**Source COM port and Destination COM port**

|                               |           |           |           |
|-------------------------------|-----------|-----------|-----------|
| LW9901 (Source COM port)      | 1 : COM 1 | 2 : COM 2 | 3 : COM 3 |
| LW9902 (Destination COM port) | 1 : COM 1 | 2 : COM 2 | 3 : COM 3 |

**COM 1 mode settings**

|                    |            |              |              |           |
|--------------------|------------|--------------|--------------|-----------|
| LW9550 (PLC I/F)   | 0 : RS232  | 1 : RS485/2W | 2 : RS485/4W |           |
| LW9551 (baud rate) | 0 : 4800   | 1 : 9600     | 2 : 19200    | 3 : 38400 |
|                    | 4 : 57600  | 5 : 115200   |              |           |
| LW9552 (data bits) | 7 : 7 bits | 8 : 8 bits   |              |           |
| LW9553 (parity)    | 0 : none   | 1 : even     | 2 : odd      |           |
| LW9554 (stop bits) | 1 : 1 bit  | 2 : 2 bits   |              |           |

### COM 2 mode settings

|                    |                       |                        |           |           |
|--------------------|-----------------------|------------------------|-----------|-----------|
| LW9556 (baud rate) | 0 : 4800<br>4 : 57600 | 1 : 9600<br>5 : 115200 | 2 : 19200 | 3 : 38400 |
| LW9557 (data bits) | 7 : 7 bits            | 8 : 8 bits             |           |           |
| LW9558 (parity)    | 0 : none              | 1 : even               | 2 : odd   |           |
| LW9559 (stop bits) | 1 : 1 bit             | 2 : 2 bits             |           |           |

### COM 3 mode setting

|                    |                       |                        |           |           |
|--------------------|-----------------------|------------------------|-----------|-----------|
| LW9560 (PLC I/F)   | 0 : RS232             | 1 : RS485/2W           |           |           |
| LW9561 (baud rate) | 0 : 4800<br>4 : 57600 | 1 : 9600<br>5 : 115200 | 2 : 19200 | 3 : 38400 |
| LW9562 (data bits) | 7 : 7 bits            | 8 : 8 bits             |           |           |
| LW9563 (parity)    | 0 : none              | 1 : even               | 2 : odd   |           |
| LW9564 (stop bits) | 1 : 1 bit             | 2 : 2 bits             |           |           |

Click [Get HMI Communication Parameters] to update HMI current states and communication parameters.

## F.2.2 HMI Work Mode

There are three work modes in the pass-through function,

|                     |                                                                                                             |
|---------------------|-------------------------------------------------------------------------------------------------------------|
| <b>Unknown</b>      | Before getting the settings of HMI, the work mode is displayed “Unknown”.                                   |
| <b>Normal</b>       | The work mode “Normal” means that PC can't control PLC via HMI.                                             |
| <b>Pass-through</b> | HMI is working on pass-through state; at this time, the PC application can control PLC via source com port. |


### [Source COM Port] 、 [Destination COM Port]

The communication parameters of source and destination COM port are displayed on these two areas. **The settings will be used when pass-through is enabled. The “Baud rate”, “Data bits”, “Parity”, and “Stop bits” of [Source COM Port] and [Destination COM Port] have to be the same.**


[Source COM Port] connects PC, so select RS232 mode; [Destination COM Port] connects PLC, so settings of the COM port depend on the PLC's requirement.

For an example, the illustration below shows the setting when HMI connects SIEMENS S7/200.

The HMI COM 1 (RS232) connects PC;COM 3 (RS485 2W) connects PLC. The communication parameter of PLC is "9600, E, 8, 1". Before starting pass-through, users must use the parameters in MTP project and download the project to HMI.



After the project is downloaded to HMI, open the same project and change the PLC I/F and COM port to COM 1 RS232 (PC uses COM 1 to connect HMI) as follows:



After that, press [Pass-through] to assign HMI IP address; for a example, 192.168.1.37. Finally, press [Get HMI Communication Parameters], as follows:



Press [**Start Pass-through**] and HMI's work mode is switched into "Pass-through". Users can execute on-line Simulation. Now PC application can control PLC via HMI, and HMI is acting as a converter at this moment.

Note: The communication between HMI and PLC will be paused when pass-through is active.. If users want to resume communication between HMI and PLC, please press [Stop Pass-through] to disable this function.

### **F.3 Using System Reserved Addresses to Enable Pass-Through Function**

Other way to enable pass-through is to use LW9901/LW9902 to set source COM port and destination COM port directly. When the values of LW9901 and LW9902 match conditions as below, HMI will start pass-through automatically:

- a. The values of LW9901 and LW9902 has to be 1 or 2 or 3  
(1: COM 1 2: COM 2 3: COM 3).
- b. The values of LW9901 and LW9902 should be not the same.

**Note:** If users want to stop pass-through, just change the values of LW9901 and LW9902 to 0.

If users need to change the communication parameters, just change the relative reserved addresses (Please refer to the section above or the relevant chapters to understand how to use these addresses) and set ON to LB9030, LB9031 and LB9032, the HMI will be forced to accept new settings.

|        |                                               |
|--------|-----------------------------------------------|
| LB9030 | Update COM1 communication parameters (set ON) |
| LB9031 | Update COM2 communication parameters (set ON) |
| LB9032 | Update COM3 communication parameters (set ON) |